


GENERAC®

POWER SYSTEMS, INC.

Operator's Manual

“C” Option Control Panel



This manual should remain with the unit.



Important Safety Instructions

"C" Option Control Panel

SAVE THESE INSTRUCTIONS – *The manufacturer suggests that these rules for safe operation be copied and posted in potential hazard areas. Safety should be stressed to all operators and potential operators of this equipment.*

Study these SAFETY RULES carefully before installing, operating, or servicing this equipment. Become familiar with this manual and all literature pertaining to the generator set and related equipment. This equipment can operate safely, efficiently, and reliably only if it is properly installed, operated, and maintained. Many accidents are caused by failing to follow simple and fundamental rules or precautions.

Generac cannot possibly anticipate every possible circumstance that might involve a hazard. The warnings in this manual, and on tags and decals affixed to the equipment, are, therefore, not all-inclusive. If using a procedure, work method, or operating technique Generac does not specifically recommend, you must satisfy yourself that it is safe for you and others. Also must make sure the procedure, work method, or operating technique that is used does not render the equipment unsafe.

GENERAL HAZARDS

- For safety reasons, Generac recommends that this equipment be installed and serviced by a Generac Authorized Service Dealer or other qualified electrician or installation technician who is familiar with applicable codes, standards, and regulations. The operator also must comply with all such codes, standards, and regulations.
- When working on this equipment, remain alert at all times. Never work on the equipment when physically or mentally fatigued.
- Inspect the equipment regularly, and promptly repair or replace all worn, damaged or defective parts, using only factory-approved parts.
- Before performing any maintenance on the generator or any related equipment, disconnect the generator's battery cables and remove panel fuse to prevent accidental startup. Disconnect the cable from the battery post, indicated by a NEGATIVE, NEG, or (-) first. Reconnect that cable last.

ELECTRICAL HAZARDS

- Generators produce dangerous electrical voltages and can cause fatal electrical shock. Avoid contact with bare wires, terminals, connections, etc., while the generator and related equipment are running. Ensure all appropriate covers, guards, and barriers are in place before operating the equipment. If working around an operating unit, stand on an insulated, dry surface to reduce potential shock hazards.

- Do not handle any kind of electrical device while standing in water, while barefoot, or while hands or feet are wet. DANGEROUS ELECTRICAL SHOCK MAY RESULT.
- If people must stand on metal or concrete while installing, operating, servicing, adjusting, or repairing this equipment, place insulative mats over a dry wooden platform. Work on the equipment only while standing on such insulative mats.
- Wire gauge sizes of electrical wiring, cables, and cord sets must be adequate to handle the maximum electrical current (amperage) to which they will be subjected to.
- Before installing or servicing this equipment, make sure that all power voltage supplies are positively TURNED OFF at their source. Failure to do so will result in hazardous and possibly fatal electrical shock.
- When installed with an automatic transfer switch, the generator may crank and start anytime, without warning. To prevent injuries caused by sudden start-up, disable the generator's automatic start circuit before working on, or around, the unit. Then, place a "Do Not Operate" tag on the generator control panel and on the transfer switch.
- In case of an accident caused by electric shock, immediately shut down the source of electrical power. If this is not possible, attempt to free the victim from the live conductor. AVOID DIRECT CONTACT WITH THE VICTIM. Use a nonconducting implement, such as, a rope or board, to free the victim from the live conductor. If the victim is unconscious, apply first aid and get immediate medical help.
- Never wear jewelry when working on this equipment. Jewelry can conduct electricity, resulting in electric shock, or may get caught in moving components, causing injury.

FIRE HAZARDS

- For fire safety, the generator and related equipment must be installed and maintained properly. Installation always must comply with applicable codes, standards, laws, and regulations. Adhere strictly to local, state, and national electrical and building codes. Comply with regulations the Occupational Safety and Health Administration (OSHA) has established. Also, ensure that the equipment is installed in accordance with the manufacturer's instructions and recommendations. Following proper installation, do nothing that might alter a safe installation and render the unit in noncompliance with the aforementioned codes, standards, laws, and regulations.

Part I - C Option Control Panel

Safety RulesInside Front Cover

Section 1 – General Information2

1.1 Overview2

1.2 Control Panel Components2

1.3 Optional Equipment2

1.3.1 Remote Annunciator Panel.....2

1.3.2 Remote Relay Panel2

1.3.3 Additional Options.....2

1.4 Panel Face Components2

1.4.1 AC Voltmeter2

1.4.2 AC Ammeter2

1.4.3 Frequency Meter2

1.4.4 Line-Phase Selector Switch3

1.4.5 Voltage Adjust Potentiometer3

1.4.6 Coolant Temperature Gauge3

1.4.7 Oil Pressure Gauge3

1.4.8 DC Voltmeter3

1.4.9 Hourmeter3

1.4.10 Start/Stop Switch.....4

1.4.11 Auto/Off/Manual Switch4

1.4.12 Panel Fuse4

1.5 Engine Monitor Panel4

1.5.1 Not in Automatic Start Mode Lamp4

1.5.2 Overcrank Lamp4

1.5.3 High Coolant Temperature Lamp.....4

1.5.4 Overspeed Lamp4

1.5.5 Low Oil Pressure Lamp5

1.5.6 RPM Sensor Loss Lamp.....5

1.5.7 Test/Reset Switch5

1.6 Optional Annunciator Panel5

1.7 Optional Remote Annunciator6

1.8 Optional Alarm Relay6

1.9 Preparation Before Startup6

1.9.1 Prior to Initial Startup6

1.9.2 Startup Inspection7

Section 2 – Operation7

2.1 Operating Unit with Manually-Operated Transfer Switch7

2.2 Operating Unit with Automatic Transfer Switch ..7

2.2.1 Manual Startup and Transfer7

2.2.2 Manual Retransfer and Engine Shutdown7

2.2.3 Preventing Automatic Startup8

Appendix 1 – Electrical Data9

Appendix 2 – Exploded Views and Parts Lists16

Appendix 3 – Interconnection Diagrams24

Part II - Remote Annunciator Panels

Section 1 – General Information29

1.1 Three Light Remote Annunciator29

1.1.1 Installation.....29

1.2 Five Light Remote Annunciator29

1.2.1 Operation.....30

1.2.2 Customer Connections.....30

1.2.3 Parts Included with Remote Panel30

1.3 18 Light Remote Annunciator30

1.3.1 Generator Stop Signals31

1.3.2 Latchable Signals.....31

1.3.3 Other Lamps31

1.3.4 Panel Wiring Interconnections31

1.4 Troubleshooting31

1.5 Annunciated Signals32

1.6 Pre-Alarms32

Appendix 4 – Electrical Data33

Appendix 5 – Exploded Views and Parts Lists41


Appendix 6 – Notes47

**AUTHORIZED SERVICE
DEALER LOCATION**

To locate the nearest GENERAC AUTHORIZED SERVICE DEALER, please call this number:

1-800-333-1322

DEALER LOCATION INFORMATION
CAN BE OBTAINED AT THIS NUMBER.



1.1 OVERVIEW

The “C” option control panel is an analog generator set control panel designed for Generac’s range of standby generators. It allows for either manual or automatic startup and shutdown.

The panel is housed in a steel sheet metal enclosure that meets NEMA 1 specifications. The front face of the panel includes a number of analog meters and gauges that indicate generator operating conditions, several indicator lamps for annunciation of engine fault shutdowns, and various other generator set controls.

1.2 CONTROL PANEL COMPONENTS

The control panel contains one main printed-circuit board (PCB), the automatic voltage regulator (AVR), optional components, such as battery monitor, dry contact boards, run relay, etc., and terminal blocks for external connections.

To find locations of the circuit board, refer to Appendix 2 for the control panel exploded view.



Remove the 15-amp fuse from the front of the panel during all engine maintenance to guard against accidental or remote startup.

1.3 OPTIONAL EQUIPMENT

1.3.1 REMOTE ANNUNCIATOR PANEL

When connected to the generator via a 19 wire connection link, this multi-light remote indicator panel will display the generator’s status.

1.3.2 DRY CONTACTS

This panel is similar to the remote annunciator, but, in addition to indicator lights, it provides relay contact closures for status (e.g., alarms). The dry contact boards are form C rated contacts. The five function dry contacts are normally open (N.O.). The six function dry contacts are either normally open (N.O.) or normally closed (N.C.).

1.3.3 ADDITIONAL OPTIONS

The following are some of the more frequently requested optional accessories for the “C” option control panel:

- Emergency stop button
- Oil temperature gauge
- Engine run relay
- 100 dBa alarm horn
- Over/Under voltage relay
- Pre-alarm kit
- Control panel heater(s)
- Voltage change over switch (special)
- Battery monitor
- Over/Under frequency relay
- Over/Under current relay

1.4 PANEL FACE COMPONENTS

(FIGURE 1.1, PAGE 3)

1.4.1 AC VOLTMETER

This meter indicates the generator AC output voltage. (Also see “Line-phase Selector Switch” and “Voltage Adjust Potentiometer” in this section). To determine the nominal rated AC voltage of the unit, refer to the unit’s data plate.

NOTE:

Some generators are reconnectable to a variety of voltages. Some units may be equipped with a rotary “Voltage Selector Switch.” Be sure to read the “Generator AC Lead Connections” section in the Owner’s Manual.


1.4.2 AC AMMETER

This meter indicates the current draw of connected electrical loads, in amps. (Also see “Line-phase Selector Switch”). For continuous operation, never exceed the rated maximum continuous current capacity of the generator.

1.4.3 FREQUENCY METER

This meter indicates the generator’s AC output frequency in “Hertz” (cycles per second).

Figure 1.1 – "C" Option Panel Components



◆ 1.4.4 LINE-PHASE SELECTOR SWITCH

This four-position switch permits selection of either line-to-line or line-to-neutral readings on the panel voltmeter and ammeter. Switch positions are as follows:

| Switch | Single-phase Units | Three-phase units |
|--------|--------------------|-------------------|
| 1 | Line E1 to Neutral | Line E1 to E2 |
| 2 | Line E3 to Neutral | Line E2 to E3 |
| 3 | Line E1 to E3 | Line E3 to E1 |
| O | No Reading | No Reading |

◆ 1.4.5 VOLTAGE ADJUST POTENTIOMETER

This potentiometer permits the operator to "fine-adjust" the generator's AC output voltage. Adjustment range is plus or minus five percent from the mid-point. Turn the knob clockwise to increase voltage, counterclockwise to decrease voltage.

◆ 1.4.6 COOLANT TEMPERATURE GAUGE

This gauge indicates the engine coolant temperature. Normal operating temperature should read between 185° to 215°F (85° to 102°C). If coolant temperature exceeds a safe level, the engine shuts down automatically.

NOTE:

Actual coolant temperature reading may vary due to variables, such as, ambient temperature, applied load, or cooling system condition.

◆ 1.4.7 OIL PRESSURE GAUGE

This gauge indicates oil pressure during operation. After warm-up, oil pressure should be about 25-90 psi. Generac recommends that the operator record the normal oil pressure during initial startup. Sudden changes in oil pressure after first starting indicate a possible engine problem.

NOTE:


Engine oil pressure may vary, depending on oil viscosity, oil temperature, engine speed, ambient temperature, etc. The engine automatically shuts down if oil pressure drops below a safe level. (10 psi.)

◆ 1.4.8 DC AMMETER

The engine is equipped with a belt-driven DC alternator, which charges the battery while the unit is running. This ammeter indicates the rate of charge to the battery during operation. If the needle drops to the left of zero, the battery is discharging. Investigate and correct this problem immediately. Erratic movement of the needle should also be corrected immediately.

◆ 1.4.9 HOURMETER

The hourmeter provides a continuous indication of engine/generator operating time, in hours and tenths of hours. Use the hourmeter with the periodic maintenance schedule.



◆ 1.4.10 START/STOP SWITCH

Use this switch to crank and start the engine manually, or to shut down an operating engine.

- To crank and start engine, first set the Auto/Off/Manual switch to its "Manual" position.
- Hold the Start/Stop switch at "Start." When the engine starts, release the switch to its center (run) position.
- To shut engine down, move the switch to its "Stop" position.

◆ 1.4.11 AUTO/OFF/MANUAL SWITCH

This safety switch should be used to prevent automatic startup of the engine when working on the engine/generator. Use the switch as follows:

▶ Auto Position

Always set switch to AUTO for automatic system operation. This means that, when this generator is installed with a GTS-type automatic transfer switch, the generator automatically cranks and starts when the utility source voltage drops below a preset level, or the unit exercises, if programmed to do so.

▶ Off Position

The engine cannot be started either automatically or manually. Always set switch to OFF before working on, or around, the engine-generator.

▶ Manual Position

The engine can be cranked and started manually using the panel Start/Stop switch. The engine will not start automatically.

NOTE:

Also see "Engine Monitor Panel." With switch set to either OFF or MANUAL, a "Not in Automatic Start Mode" lamp lights up on the panel.

◆ 1.4.12 PANEL FUSE

This fuse protects the control console's DC circuits against overload. If the fuse element melts open due to an overload, engine cranking and startup will not be possible. Should fuse replacement become necessary, use only an identical fuse (part number 022676).

1.5 ENGINE MONITOR PANEL

This panel has five advisory shutdown lamps for separate engine fault conditions, plus a "Not in Automatic Start Mode" lamp. Cranking and starting will not be possible while any one, or more, of engine fault conditions lamps is lit, with the exception of "Not in Auto" illuminated in the manual mode. The following apply:

- A "lamp ON" condition indicates that fault condition has been "latched" by DC control/latch-crank circuit board.
- If any one of the lamps is ON (fault condition latched), the engine cannot be cranked either manually or automatically.
- To unlatch a fault (that is, to turn a lamp OFF) and permit cranking, push the Test/Reset switch in. The lamp will then go OFF, allowing for additional cranking.

◆ 1.5.1 NOT IN AUTOMATIC START MODE LAMP

This lamp comes ON to indicate that automatic startup of the engine is not possible. The lamp lights up whenever the Auto/Off/Manual switch is set to OFF or MANUAL.

◆ 1.5.2 OVERCRANK LAMP

The control console houses a DC control/latch-crank circuit board (the "C" board) that controls engine startup and shutdown. During automatic startup, the engine cranks for about 14 seconds, rests for about eight seconds, and so on, until eight crank-rest cycles have occurred. At the end of eight attempts, cranking stops, and the overcrank lamp goes ON.


◆ 1.5.3 HIGH COOLANT TEMPERATURE LAMP

This lamp comes ON if coolant temperature is too high or coolant level is too low. The engine shuts down automatically when such unsafe conditions occur. The following apply:

- If the engine is started with an existing high coolant temperature or low coolant level condition, the engine shuts down, and the lamp comes ON when engine speed reaches about 1000 rpm.
- If the engine starts normally but high temperature/low coolant level develops later, the engine shuts down, and the light comes ON immediately.

◆ 1.5.4 OVERSPEED LAMP

An engine overspeed above a safe limit causes the engine to automatically shut down, which turns ON the indicator lamp. The overspeed lamp comes on when the unit is run at a 15% faster rpm than rated.



◆ 1.5.5 LOW OIL PRESSURE LAMP

This lamp lights up (latches) to indicate low oil pressure in the engine as follows:

- During cranking, after engine has reached 800 to 1000 rpm, the circuit allows four seconds for oil pressure to build.
- In auto mode, if the unit runs above 800-1000 rpm for more than four seconds, and oil pressure is below a safe level, the engine shuts down, but the lamp does NOT go ON. The system then actuates eight restart attempts; the engine shuts down, and the lamp goes ON.
- If the engine starts normally with good oil pressure, but oil pressure drops later, the system waits five seconds for oil pressure to be restored. If pressure is still low after a five-second delay, the engine shuts down, and the lamp goes ON immediately.

◆ 1.5.6 RPM SENSOR LOSS LAMP

Units with the "C" Option console are equipped with an rpm sensor, which is mounted directly over the engine flywheel gear teeth. This sensor is a magnetic pickup that emits an electrical pulse at the passage of each flywheel gear tooth. Sensor electrical signals are used by the DC control/latch-crank circuit board as engine speed (rpm) signals. The circuit board uses these rpm signals (a) to establish a starter lockout speed, and (b) to shut down the engine if the engine runs too fast (overspeed). If the rpm signals to the circuit board are lost, engine shutdown occurs, but the lamp will not light, (i.e., the condition will not latch), then, depending on whether the sensor signal loss occurred during a manual or an automatic start attempt, the following events occur:

► Manual Startup

If the engine starts within two seconds after cranking begins, shutdown occurs as soon as the Start/Stop switch is released, but without a lamp ON condition (latching does not occur). If engine does not start within two seconds after cranking begins, which disables starting, the rpm sensor loss light goes ON.

► Automatic Startup

The engine recranks within about one second after it has stopped. If sensor loss persists, engine shuts down, and lamp lights about two seconds after cranking has restarted.

If engine starts within two seconds after recrank has begun, the starter remains engaged until the two-second delay is over.

◆ 1.5.7 TEST/RESET SWITCH

To test all lamps, push this switch in. Following any fault shutdown with any monitor panel lamp illuminated, engine cranking is inhibited. To reset the system (unlatch a fault) and crank the engine again, push the switch in (lamp must go out). If the switch is actuated with the engine running, only the lamps will be tested. The engine will not shut down.

NOTE:


If engine shuts down due to some unmonitored problem (such as, out of fuel or failed ignition system), none of the lamps will come ON. If such an unmonitored shutdown occurs with the Auto/Off/Manual switch set to AUTO, engine recranks and attempts to start for any of the cycles remaining in the eight-crank limit. After all eight crank cycles have been used, the engine shuts down, and the OVERCRANK lamp goes ON.

1.6 OPTIONAL ANNUNCIATOR PANEL

Some units may come equipped with a factory-installed annunciator panel having up to nine annunciated fault conditions displayed (Figure 1.2). This optional panel is often called a "prealarm" panel, since it warns of impending problems before an actual fault shutdown occurs.

The panel is designed to monitor various engine condition-sensing devices having normally-open (N.O.) or normally-closed (N.C.) contacts.

Figure 1.2 — Optional Annunciator (Prealarm) Panel




1.7 OPTIONAL REMOTE ANNUNCIATOR

An optional 18-light REMOTE annunciator panel that can be mounted on a wall (Figure 1.3) is also available. For information on the remote annunciator panels, ask the local dealer/distributor or consult the factory. Ask for information on the Models 9555 and 9556 remote annunciator panels. The following apply to the remote annunciator panels:

- It is designed for use with installation having a Generac Power Systems GTS-type transfer switch and a "C" Option control panel.
- The panel is available in both flush-mounted (Model 9556) and surface-mounted (Model 9555) configurations.
- The panel has a built-in audible alarm horn, with a reset switch to turn off the horn without disturbing the lighted indication.
- Remote monitoring of the standby generator set provides enough information to avoid unnecessary maintenance trips to the generator site.

Figure 1.3 — Optional 18-Light Remote Annunciator




1.8 STANDARD ALARM RELAY

The generator's DC control/latch-crank circuit board is equipped with an alarm relay "driver". All units with "C" Option control panels are equipped with an alarm relay that is connected to the circuit board driver (Figure 1.4). If any one or more of the five annunciated shutdown faults occur, the circuit board driver energizes the optional alarm relay.

A remote-mounted alarm or annunciator device may be connected across the relay contacts so that a failure will turn on the remote alarm or device. The connected alarm device may range from an alarm horn to a warning light to a telephone dialer with a pre-recorded message. The alarm relay normally-open, normally-closed, and common contacts are shown in Figure 1.4.

Figure 1.4 — Standard Alarm Relay



1.9 PREPARATION BEFORE STARTUP

The instructions in this section assume that the standby generator has been properly installed, serviced, tested, adjusted, and otherwise prepared for use by a competent, qualified installation contractor. Be sure to read RULES FOR SAFE OPERATION on the inside of the front cover carefully, before attempting to operate this (and related) equipment.

◆ 1.9.1 PRIOR TO INITIAL STARTUP

Before starting the generator for the first time, the installer must complete the following:

- Properly locate and properly mount the generator, transfer switch, and other standby system components, in strict compliance with applicable codes, standards, and regulations.
- Make sure the fuel supply system to the generator (a) delivers the correct fuel at the correct pressure, and (b) is properly purged and leak-tested according to code. No fuel leakage is permitted.
- Have the engine crankcase properly filled to the correct level with the recommended oil.
- Have engine cooling system properly filled with recommended coolant mixture. Check the system for leaks and other problems.
- If engine is equipped with a mechanical governor, make sure the governor is properly filled with oil. Use crankcase oil to fill.
- Check engine v-belt tension and belt condition.
- Make sure the generator is properly connected to an approved earth ground.
- The generator battery must be fully charged, properly installed and interconnected, and ready for use.

◆ 1.9.2 STARTUP INSPECTION

A standard, three-part form entitled “Startup Inspection for Standby Power Systems” (Part No. 67377) must be completed by the installation technician or engineer in order to activate warranty. As stated on the form, inspections are to be performed only by factory-trained personnel. The installer must complete the form and distribute copies as follows:

- White copy: Mail to Generac Service Department, P.O. Box 310, Eagle, WI 53119.
- Pink copy: For service file of installing dealer.
- Yellow copy: For the customer’s records.

2.1 OPERATING UNIT WITH MANUALLY OPERATED TRANSFER SWITCH

If the generator was installed with a transfer switch capable of manual operation only, the following applies: A manually-operated transfer switch is one that will not provide automatic startup and does not include the intelligence circuit, which comprises of a utility voltage sensor PCB, an inphase monitor PCB, a seven day exerciser PCB, or other type of sensing circuits found in a Closed Transition Transfer Switch (CTTS) or a Bypass Isolation Switch (BIS).

2.2 OPERATING UNIT WITH AUTOMATIC TRANSFER SWITCH

If the generator has been installed with a Generac “GTS”-type automatic transfer switch, the engine may be started and stopped either automatically or manually.

IMPORTANT: BE SURE TO READ THE APPLICABLE AUTOMATIC TRANSFER SWITCH MANUAL CAREFULLY. DIFFERENCES EXIST BETWEEN TRANSFER SWITCHES.

◆ 2.2.1 MANUAL STARTUP AND TRANSFER

To crank and start the engine and to transfer electrical loads to the STANDBY power source, proceed as follows:

- See applicable transfer switch instructions. If so equipped, set the Safety Disconnect Switch to MANUAL.
- On the generator’s Meter and Control Panel, set the Auto/Off/Manual switch to MANUAL.



The safety disconnect switch and the Auto/Off/Manual switches must be set as instructed above, or the generator will crank and start as soon as the utility power to the transfer switch is turned OFF.

- Turn OFF both the NORMAL (utility) and EMERGENCY (standby) power supplies to the transfer switch, using whatever means is provided (such as the main-line circuit breaker(s)).



DO NOT attempt manual operation until all power voltage supplies to the transfer switch have been positively turned OFF; otherwise, extremely dangerous---possibly lethal---electrical shock will result.

- Refer to the instructions that correspond to the installed transfer switch. Manually actuate the switch main contacts to their STANDBY (emergency) position, as outlined in the corresponding manual. LOAD circuit must be connected to the STANDBY power supply before proceeding.
- On the generator console, hold the Start/Stop switch START to crank the engine. Hold it until it begins running, then release the switch to its centered (RUN) position.
- Let the engine warm up and stabilize at no-load.
- Turn ON the STANDBY power supply to the transfer switch, using whatever means provided (such as STANDBY source main-line circuit breaker).
- The generator will now power the load circuits.

◆ 2.2.2 MANUAL RETRANSFER AND ENGINE SHUTDOWN


To retransfer LOAD circuits back to the NORMAL (utility) power source and to stop the engine, proceed as follows:

- Turn OFF both the UTILITY and STANDBY power supplies to the transfer switch, using whatever means provided, such as the main-line circuit breaker(s).




DO NOT attempt manual operation until all power voltage supplies to the transfer switch have been positively turned OFF; otherwise, extremely dangerous---possibly lethal---electrical shock will result.

- Refer to the applicable transfer switch instructions. Manually actuate the transfer switch main contacts to their utility position (LOAD connected to UTILITY power supply).
- Turn ON the UTILITY power supply to the transfer switch, using whatever means are provided (such as the UTILITY main-line circuit breaker(s)).
- Check that the UTILITY voltage is available to the transfer switch (see appropriate transfer switch instructions).
- Let the generator engine run at no-load for a few minutes. Then, set the generator Start/Stop switch to STOP. Wait for the engine to come to a complete stop.
- Reset the system for fully automatic operation.



◆ 2.2.3 PREVENTING AUTOMATIC STARTUP





 When installed with an automatic transfer switch, Generac standby generators can crank and start suddenly, without warning, when UTILITY source voltage drops below a preset value. To prevent possible injuries caused by such sudden starts, disable the automatic transfer switch before working on, or around, the generator. Use any one, or more, of the following methods to disable the automatic start function:

- Set the generator's Auto/Off/Manual switch to OFF. Neither a manual nor an automatic start can be accomplished with this switch set to OFF.
- Remove the fuse from the generator control panel. To remove the fuse, push fuse holder cap in and turn cap counterclockwise. Remove cap and fuse element.
- Refer to the automatic transfer switch instructions. If the transfer switch is so equipped, set its Safety Disconnect switch to MANUAL position to prevent automatic startup and transfer.
- Disconnect battery cable from generator battery post, indicated by a negative, NEG, or (-).

Appendix 1 – Electrical Data

“C” Option Control Panel 24 Volt, 400 kW and Larger Interconnection Diagram – Drawing No. A7296-B





- AR - ALARM RELAY
- L1 - PRE-LD OIL PRESS. LAMP
- L2 - PRE-LD OIL TEMP. LAMP
- L3 - PRE-LD OIL VOLT. LAMP
- L4 - HI COOL. VOLT. LAMP
- L5 - LD BATT. VOLTS. LAMP
- L6 - RUPTURE BASIN LAMP
- L7 - RUPTURE FUEL LAMP
- LCT - LD COOLANT TEMP. SWITCH
- LFS - LDW FUEL LEVEL SWITCH
- PHT - HI COOLANT TEMP. SWITCH
- PLP - PRE-LD OIL PRESS. SWITCH
- RBS - RUPTURED BASIN SWITCH

Appendix 1 – Electrical Data

"C" Option Control Panel 24 Volt, 400 kW and Larger


Wiring Diagram – Drawing No. A4723-B



- J3 -CONNECTOR ALARM CIRCUIT BOARD
- L1 -LIGHT, OVERSPEED
- L2 -LIGHT, OVERCRANK
- L3 -LIGHT, OIL PRESSURE
- L4 -LIGHT, OIL LEVEL
- L5 -LIGHT, NOT IN AUTO START MODE
- L6 -LIGHT, PANEL
- L7 -LIGHT, PREHEAT
- L8 -LIGHT, TEST/RESET
- L9 -LIGHT, TEST/RESET
- L10 -LIGHT, TEST/RESET
- L11 -LIGHT, TEST/RESET
- L12 -LIGHT, TEST/RESET
- L13 -LIGHT, TEST/RESET
- L14 -LIGHT, TEST/RESET
- L15 -LIGHT, TEST/RESET
- L16 -LIGHT, TEST/RESET
- L17 -LIGHT, TEST/RESET
- L18 -LIGHT, TEST/RESET
- L19 -LIGHT, TEST/RESET
- L20 -LIGHT, TEST/RESET
- L21 -LIGHT, TEST/RESET
- L22 -LIGHT, TEST/RESET
- L23 -LIGHT, TEST/RESET
- L24 -LIGHT, TEST/RESET
- L25 -LIGHT, TEST/RESET
- L26 -LIGHT, TEST/RESET
- L27 -LIGHT, TEST/RESET
- L28 -LIGHT, TEST/RESET
- L29 -LIGHT, TEST/RESET
- L30 -LIGHT, TEST/RESET
- L31 -LIGHT, TEST/RESET
- L32 -LIGHT, TEST/RESET
- L33 -LIGHT, TEST/RESET
- L34 -LIGHT, TEST/RESET
- L35 -LIGHT, TEST/RESET
- L36 -LIGHT, TEST/RESET
- L37 -LIGHT, TEST/RESET
- L38 -LIGHT, TEST/RESET
- L39 -LIGHT, TEST/RESET
- L40 -LIGHT, TEST/RESET
- L41 -LIGHT, TEST/RESET
- L42 -LIGHT, TEST/RESET
- L43 -LIGHT, TEST/RESET
- L44 -LIGHT, TEST/RESET
- L45 -LIGHT, TEST/RESET
- L46 -LIGHT, TEST/RESET
- L47 -LIGHT, TEST/RESET
- L48 -LIGHT, TEST/RESET
- L49 -LIGHT, TEST/RESET
- L50 -LIGHT, TEST/RESET
- L51 -LIGHT, TEST/RESET
- L52 -LIGHT, TEST/RESET
- L53 -LIGHT, TEST/RESET
- L54 -LIGHT, TEST/RESET
- L55 -LIGHT, TEST/RESET
- L56 -LIGHT, TEST/RESET
- L57 -LIGHT, TEST/RESET
- L58 -LIGHT, TEST/RESET
- L59 -LIGHT, TEST/RESET
- L60 -LIGHT, TEST/RESET
- L61 -LIGHT, TEST/RESET
- L62 -LIGHT, TEST/RESET
- L63 -LIGHT, TEST/RESET
- L64 -LIGHT, TEST/RESET
- L65 -LIGHT, TEST/RESET
- L66 -LIGHT, TEST/RESET
- L67 -LIGHT, TEST/RESET
- L68 -LIGHT, TEST/RESET
- L69 -LIGHT, TEST/RESET
- L70 -LIGHT, TEST/RESET
- L71 -LIGHT, TEST/RESET
- L72 -LIGHT, TEST/RESET
- L73 -LIGHT, TEST/RESET
- L74 -LIGHT, TEST/RESET
- L75 -LIGHT, TEST/RESET
- L76 -LIGHT, TEST/RESET
- L77 -LIGHT, TEST/RESET
- L78 -LIGHT, TEST/RESET
- L79 -LIGHT, TEST/RESET
- L80 -LIGHT, TEST/RESET
- L81 -LIGHT, TEST/RESET
- L82 -LIGHT, TEST/RESET
- L83 -LIGHT, TEST/RESET
- L84 -LIGHT, TEST/RESET
- L85 -LIGHT, TEST/RESET
- L86 -LIGHT, TEST/RESET
- L87 -LIGHT, TEST/RESET
- L88 -LIGHT, TEST/RESET
- L89 -LIGHT, TEST/RESET
- L90 -LIGHT, TEST/RESET
- L91 -LIGHT, TEST/RESET
- L92 -LIGHT, TEST/RESET
- L93 -LIGHT, TEST/RESET
- L94 -LIGHT, TEST/RESET
- L95 -LIGHT, TEST/RESET
- L96 -LIGHT, TEST/RESET
- L97 -LIGHT, TEST/RESET
- L98 -LIGHT, TEST/RESET
- L99 -LIGHT, TEST/RESET
- L100 -LIGHT, TEST/RESET


- AM -AC AMMETER
- AR -ALARM RELAY
- BVM -BATTERY VOLTMETER
- CB1 -CIRCUIT BREAKER, EXCITATION
- F1 -FUSE-15 AMPERE, 12 AMP
- G1 -GAUGE-WATER TEMP
- G2 -GAUGE-OIL PRESSURE
- HZ -FREQUENCY METER
- J1 -CONNECTOR ALARM CIRCUIT BOARD
- J2 -CONNECTOR ENGINE CONTROL
- J3 -CONNECTOR ALARM CIRCUIT BOARD
- L1 -LIGHT, OVERSPEED
- L2 -LIGHT, OVERCRANK
- L3 -LIGHT, OIL PRESSURE
- L4 -LIGHT, OIL LEVEL
- L5 -LIGHT, NOT IN AUTO START MODE
- L6 -LIGHT, PANEL
- L7 -LIGHT, PREHEAT
- L8 -LIGHT, TEST/RESET
- L9 -LIGHT, TEST/RESET
- L10 -LIGHT, TEST/RESET
- L11 -LIGHT, TEST/RESET
- L12 -LIGHT, TEST/RESET
- L13 -LIGHT, TEST/RESET
- L14 -LIGHT, TEST/RESET
- L15 -LIGHT, TEST/RESET
- L16 -LIGHT, TEST/RESET
- L17 -LIGHT, TEST/RESET
- L18 -LIGHT, TEST/RESET
- L19 -LIGHT, TEST/RESET
- L20 -LIGHT, TEST/RESET
- L21 -LIGHT, TEST/RESET
- L22 -LIGHT, TEST/RESET
- L23 -LIGHT, TEST/RESET
- L24 -LIGHT, TEST/RESET
- L25 -LIGHT, TEST/RESET
- L26 -LIGHT, TEST/RESET
- L27 -LIGHT, TEST/RESET
- L28 -LIGHT, TEST/RESET
- L29 -LIGHT, TEST/RESET
- L30 -LIGHT, TEST/RESET
- L31 -LIGHT, TEST/RESET
- L32 -LIGHT, TEST/RESET
- L33 -LIGHT, TEST/RESET
- L34 -LIGHT, TEST/RESET
- L35 -LIGHT, TEST/RESET
- L36 -LIGHT, TEST/RESET
- L37 -LIGHT, TEST/RESET
- L38 -LIGHT, TEST/RESET
- L39 -LIGHT, TEST/RESET
- L40 -LIGHT, TEST/RESET
- L41 -LIGHT, TEST/RESET
- L42 -LIGHT, TEST/RESET
- L43 -LIGHT, TEST/RESET
- L44 -LIGHT, TEST/RESET
- L45 -LIGHT, TEST/RESET
- L46 -LIGHT, TEST/RESET
- L47 -LIGHT, TEST/RESET
- L48 -LIGHT, TEST/RESET
- L49 -LIGHT, TEST/RESET
- L50 -LIGHT, TEST/RESET
- L51 -LIGHT, TEST/RESET
- L52 -LIGHT, TEST/RESET
- L53 -LIGHT, TEST/RESET
- L54 -LIGHT, TEST/RESET
- L55 -LIGHT, TEST/RESET
- L56 -LIGHT, TEST/RESET
- L57 -LIGHT, TEST/RESET
- L58 -LIGHT, TEST/RESET
- L59 -LIGHT, TEST/RESET
- L60 -LIGHT, TEST/RESET
- L61 -LIGHT, TEST/RESET
- L62 -LIGHT, TEST/RESET
- L63 -LIGHT, TEST/RESET
- L64 -LIGHT, TEST/RESET
- L65 -LIGHT, TEST/RESET
- L66 -LIGHT, TEST/RESET
- L67 -LIGHT, TEST/RESET
- L68 -LIGHT, TEST/RESET
- L69 -LIGHT, TEST/RESET
- L70 -LIGHT, TEST/RESET
- L71 -LIGHT, TEST/RESET
- L72 -LIGHT, TEST/RESET
- L73 -LIGHT, TEST/RESET
- L74 -LIGHT, TEST/RESET
- L75 -LIGHT, TEST/RESET
- L76 -LIGHT, TEST/RESET
- L77 -LIGHT, TEST/RESET
- L78 -LIGHT, TEST/RESET
- L79 -LIGHT, TEST/RESET
- L80 -LIGHT, TEST/RESET
- L81 -LIGHT, TEST/RESET
- L82 -LIGHT, TEST/RESET
- L83 -LIGHT, TEST/RESET
- L84 -LIGHT, TEST/RESET
- L85 -LIGHT, TEST/RESET
- L86 -LIGHT, TEST/RESET
- L87 -LIGHT, TEST/RESET
- L88 -LIGHT, TEST/RESET
- L89 -LIGHT, TEST/RESET
- L90 -LIGHT, TEST/RESET
- L91 -LIGHT, TEST/RESET
- L92 -LIGHT, TEST/RESET
- L93 -LIGHT, TEST/RESET
- L94 -LIGHT, TEST/RESET
- L95 -LIGHT, TEST/RESET
- L96 -LIGHT, TEST/RESET
- L97 -LIGHT, TEST/RESET
- L98 -LIGHT, TEST/RESET
- L99 -LIGHT, TEST/RESET
- L100 -LIGHT, TEST/RESET


- R2 -RESISTOR-FIELD BOOST
- R3 -RESISTOR-OIL GAUGE
- R4 -RESISTOR-WATER TEMP
- RR1 -RELAY
- RR2 -RELAY
- RR3 -RELAY
- RR4 -RELAY
- RR5 -RELAY
- RR6 -RELAY
- RR7 -RELAY
- RR8 -RELAY
- RR9 -RELAY
- RR10 -RELAY
- RR11 -RELAY
- RR12 -RELAY
- RR13 -RELAY
- RR14 -RELAY
- RR15 -RELAY
- RR16 -RELAY
- RR17 -RELAY
- RR18 -RELAY
- RR19 -RELAY
- RR20 -RELAY
- RR21 -RELAY
- RR22 -RELAY
- RR23 -RELAY
- RR24 -RELAY
- RR25 -RELAY
- RR26 -RELAY
- RR27 -RELAY
- RR28 -RELAY
- RR29 -RELAY
- RR30 -RELAY
- RR31 -RELAY
- RR32 -RELAY
- RR33 -RELAY
- RR34 -RELAY
- RR35 -RELAY
- RR36 -RELAY
- RR37 -RELAY
- RR38 -RELAY
- RR39 -RELAY
- RR40 -RELAY
- RR41 -RELAY
- RR42 -RELAY
- RR43 -RELAY
- RR44 -RELAY
- RR45 -RELAY
- RR46 -RELAY
- RR47 -RELAY
- RR48 -RELAY
- RR49 -RELAY
- RR50 -RELAY
- RR51 -RELAY
- RR52 -RELAY
- RR53 -RELAY
- RR54 -RELAY
- RR55 -RELAY
- RR56 -RELAY
- RR57 -RELAY
- RR58 -RELAY
- RR59 -RELAY
- RR60 -RELAY
- RR61 -RELAY
- RR62 -RELAY
- RR63 -RELAY
- RR64 -RELAY
- RR65 -RELAY
- RR66 -RELAY
- RR67 -RELAY
- RR68 -RELAY
- RR69 -RELAY
- RR70 -RELAY
- RR71 -RELAY
- RR72 -RELAY
- RR73 -RELAY
- RR74 -RELAY
- RR75 -RELAY
- RR76 -RELAY
- RR77 -RELAY
- RR78 -RELAY
- RR79 -RELAY
- RR80 -RELAY
- RR81 -RELAY
- RR82 -RELAY
- RR83 -RELAY
- RR84 -RELAY
- RR85 -RELAY
- RR86 -RELAY
- RR87 -RELAY
- RR88 -RELAY
- RR89 -RELAY
- RR90 -RELAY
- RR91 -RELAY
- RR92 -RELAY
- RR93 -RELAY
- RR94 -RELAY
- RR95 -RELAY
- RR96 -RELAY
- RR97 -RELAY
- RR98 -RELAY
- RR99 -RELAY
- RR100 -RELAY



Appendix 1 – Electrical Data


"C" Option Control Panel 24 Volt Diesel, Less than 400 kW Control Panel Electrical Schematic - Drawing No. 84850-C





Appendix 1 – Electrical Data

"C" Option Control Panel 12 Volt Gas Control Panel Electrical Schematic – Drawing No. 85023-A



PHASE SELECTOR SWITCH

| CONTACTS | 1 | 2 | 3 | OFF |
|----------|---|---|---|-----|
| 1 | 0 | X | X | X |
| 2 | 0 | X | X | X |
| 3 | X | 0 | X | X |
| 4 | X | X | 0 | X |
| 5 | X | X | X | 0 |
| 6 | 0 | 0 | 0 | 0 |
| 7 | 0 | 0 | 0 | 0 |
| 8 | 0 | 0 | 0 | 0 |
| 9 | 0 | 0 | 0 | 0 |
| 10 | 0 | 0 | 0 | 0 |
| 11 | 0 | 0 | 0 | 0 |
| 12 | 0 | 0 | 0 | 0 |
| 13 | 0 | 0 | 0 | 0 |
| 14 | 0 | 0 | 0 | 0 |
| 15 | 0 | 0 | 0 | 0 |
| 16 | 0 | 0 | 0 | 0 |
| 17 | 0 | 0 | 0 | 0 |
| 18 | 0 | 0 | 0 | 0 |
| 19 | 0 | 0 | 0 | 0 |
| 20 | 0 | 0 | 0 | 0 |

X INDICATES CLOSED


LEGEND

- AM - AC AMMETER
- AR - ALARM RELAY
- BCA - BATTERY CHARGE AMMETER
- BCB - BATTERY CHARGE AMMETER
- D1 - DIODE - 60V, 1.2A
- D2 - DIODE - 800V, 1.2A
- F1 - FUSE - 15 AMPS
- C1 - GAUGE - WATER TEMP
- HM - HOURMETER - PRESSURE
- FREQUENCY METER
- PCB1 - CIRCUIT BOARD
- PCB2 - CIRCUIT BOARD
- CONNECTOR ENGINE CIRCUIT BOARD
- CONNECTOR ALARM CIRCUIT BOARD
- L1 - LIGHT - OVERCRANK
- L2 - LIGHT - OVERCRANK
- L3 - LIGHT - OVERCRANK
- L4 - LIGHT - HIGH TEMP
- L5 - LIGHT - LOW TEMP
- L6 - LIGHT - NOT IN AUTOMATIC START MODE
- L7 - LIGHT PANEL
- PCB1 - CIRCUIT BOARD ENGINE CONTROL
- PCB2 - CIRCUIT BOARD ENGINE CONTROL
- POTENTIOMETER VOLTAGE ADJUST
- R2 - RESISTOR FIELD BOOST
- R3 - RESISTOR ENGINE ALTERNATOR
- SW1 - SWITCH - AUTO/MANUAL/OFF
- SW2 - SWITCH - TEST/RESET
- SW3 - SWITCH - TEST/RESET
- SW4 - SWITCH - PHASE SELECTOR
- TS1,2 - TERMINAL STRIP
- VM - A-C VOLTMETER
- VR - VOLTAGE REGULATOR

Appendix 1 – Electrical Data


“C” Option Control Panel 12 Volt Gas


Control Panel Wiring Diagram – Drawing No. 85024-A



LEGEND


- | | | | |
|-----|----------------------------------|-------|---------------------------------|
| AM | — AC AMMETER | L4 | — LIGHT HIGH TEMP/LOW LEVEL |
| AR | — ALARM RELAY | L5 | — LIGHT LOW OIL PRESSURE |
| CB1 | — CIRCUIT BREAKER— FIELD BOOST | L7 | — LIGHT PANEL |
| D1 | — DIODE— 600V, 12A | PCB1 | — CIRCUIT BOARD ENGINE CONTROL |
| D2 | — DIODE— 800V, 2A | PCB2 | — CIRCUIT BOARD ALARM |
| F1 | — FUSE— 15 AMPS | R1 | — POTENTIOMETER— VOLTAGE ADJUST |
| G1 | — GAUGE— WATER TEMP | R2 | — RESISTOR FIELD BOOST |
| G2 | — GAUGE— OIL PRESSURE | SW1 | — SWITCH AUTO/MANUAL/OFF |
| J1 | — CONNECTOR ALARM CIRCUIT BOARD | SW2 | — SWITCH— TEST/RESET |
| J2 | — CONNECTOR ENGINE CIRCUIT BOARD | SW3 | — SWITCH— START/STOP |
| L1 | — LIGHT RPM SENSOR LOSS | SW4 | — SWITCH— PHASE SELECTOR |
| L2 | — LIGHT OVERSPEED | TS1,2 | — TERMINAL STRIP |
| L3 | — LIGHT OVERCRANK | VM | — A-C VOLTMETER |
| | | VR | — VOLTAGE REGULATOR |






Appendix 2 – Exploded Views and Parts Lists

"C" Option Control Panel 24 Volt Diesel Control Panel – Drawing No. 84851-J



Appendix 2 – Exploded Views and Parts Lists


"C" Option Control Panel 24 Volt Diesel Control Panel – Drawing No. 84851-J



| ITEM | PART NO. | QTY. | DESCRIPTION | ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|--------------------------------|------|----------|------|--|
| 1 | 070023 | 1 | CONTROL PANEL BOTTOM | 37 | 070081 | 1 | HOURMETER |
| 2 | 070026 | 1 | SLKSCRND PANEL FRONT | 38 | 062304 | 1 | AMMETER 40-0-40 DC |
| 3 | 070028 | 1 | COVER CON PNL SIDE | 39 | 055405 | 1 | GAUGE OIL PRESSURE |
| 4 | 067680 | 1 | ASSY VOLTAGE REGULATOR 60HZ | 40 | 055406 | 1 | GAUGE COOLANT TEMPERATURE |
| | 092952 | 1 | ASSY VOLTAGE REGULATOR 50HZ | 41 | 070083 | 1 | ASSY PCB ENGINE MONITOR |
| 5 | 039271 | 1 | FITTING 90 DEGREE 3/4 | 42 | 055089 | 1 | CONN PLUG PNL 15P AMP M-N-L |
| 6 | 034616 | 1 | FITTING STRAIGHT 3/4 | 43 | 070082 | 1 | BLOCKER LIGHT |
| 7 | | 1 | CIRCUIT BREAKER | 44 | 053247 | 1 | LUG RNGTNG INS 22-18 X10 X.322 |
| 8 | 082985 | 1 | RES 100R 5% 5W ASSY=55405 | 45 | 029187 | 2 | SPACER .19 X .31 X .50 PL |
| 9 | 082984 | 1 | RES 120R 10% 2W ASSY 55406 | 46 | 077043B | 1 | FLEX CONDUIT .50 ID |
| 10 | 086266 | 1 | RES WW LUG 75R 5% 25W | 50 | 036904 | 4 | SCREW PPHM #6-32 X 3/4 (NOT SHOWN) |
| 11 | 055444 | 1 | HEATSINK | 51 | 036908 | 2 | SCREW PPHM #6-32 X 1-1/4 |
| 12 | 030468 | 1 | WASHER STEP NYLON .20 | 52 | 022155 | 2 | WASHER LOCK #6 |
| 13 | 049939 | 1 | RECTIFIER MSC 12A 600V 1N1206R | 53 | 022985 | 6 | WASHER FLAT #6 ZINC |
| 14 | 083089 | 1 | ASSY PCB "C" CONTROL 12/24V | 54 | 022188 | 2 | NUT HEX #6-32 STEEL |
| 15 | 033147 | 1 | SCREW HHM #10-32 X 1 | 55 | 036918 | 4 | SCREW PPHM #8-32 X 1/2 |
| 16 | 024469 | 2 | SCREW HHTT #10-32 X 3/8 CZ | 56 | 022264 | 4 | WASHER LOCK #8-M4 |
| 17 | 084853A | 1 | HARNESS F/<100KW 24V C DIESEL | 57 | 033121 | 16 | SCREW HHC #10-32 X 1/2 |
| | 084853B | 1 | HARNESS F/>101KW 24V C DIESEL | 58 | 022152 | 26 | WASHER LOCK #10 |
| | 084853C | 1 | HARNESS F/12LMITS 24V C DIESEL | 59 | 023897 | 14 | WASHER FLAT #10 ZINC |
| 18 | 029333 | 6 | TIE WRAP 7.4"X.19" NATL UL | 60 | 022158 | 20 | NUT HEX #10-32 STEEL |
| 19 | 084875 | 1 | DECAL TERMINAL STRIP | 61 | 038150 | 4 | WASHER FLAT #8 ZINC |
| 20 | 055920 | 1 | SWITCH SPST SPADE PNL MNT | 62 | 022471 | 4 | NUT HEX #8-32 STEEL |
| 21 | 055867 | 1 | SWITCH TOG SPDT 15A SPD MOM | 63 | 084787 | 1 | CABLE RIBBON 16" |
| 22 | 067625 | 1 | SWITCH TOGGLE 3P3T 15/10A | 64 | 070370 | 2 | WASHER MICA .203 |
| 23 | 032300 | 1 | HOLDER FUSE | 65 | 083288 | 1 | LIGHT 28VDC .17A MIN BAYNT MNT |
| 24 | 022676 | 1 | FUSE 15A X AGC15 | 66 | 023762 | 4 | WASHER SHAKEPROOF EXT #10 STL |
| 25 | 040213 | 4 | PCB SUPPORT SNAP-IN 1/4" | 68 | 081767 | 2 | RELAY PNL 24VDC DPDT 10A |
| 26 | 0C2428 | 14 | SCREW PHTT #6-32 X 1/2 ZYC | 70 | 064000 | 1 | CONTROL PNL SIDE |
| 27 | 061945 | 1 | SWITCH SELECTOR 6A AMP/V | 71 | 064008 | 1 | COVER CON PNL TOP |
| 28 | 071361 | 1 | POT 5K 10% 2.25W PNL | 72 | 098940 | 1 | HARNESS C-OPT CTRL PNL |
| 29 | 050123 | 1 | KNOB PLASTIC .25 SHAFT | 73 | 066040 | 1 | DECAL - TERM STRIP |
| 30 | 055349 | 1 | INSULATOR | 77 | 0C2323 | 4 | SCREW PHTT #6-32 X 5/8 ZYC |
| 31 | 070030 | 1 | COVER GENERAC SILKSCREENED | 78 | 0C1229 | 1 | DECAL CUST CONN BOX |
| 33 | 070042 | 1 | FREQUENCY METER 240V 55-65HZ | 79 | 022507 | 4 | SCREW HHC 1/4-20 X 1/2 G5 (NOT SHOWN) |
| | 070042-A | 1 | FREQUENCY METER 240V 45-55HZ | | | | |
| 34 | | 1 | AC AMMETER | 80 | 022097 | 8 | WASHER LOCK M6-1/4 (NOT SHOWN) |
| 35 | | 1 | AC VOLTMETER | 81 | 040479 | 4 | VIB MNT 1.0 X 1.0 X 1/4-20 (NOT SHOWN) |
| 36 | 083287 | 1 | LIGHT HLDR CLR LNS W/O BULB | | | | |


Appendix 2 – Exploded Views and Parts Lists

**"C" Option Control Panel 24 Volt Gas
Control Panel – Drawing No. 84711-N**



Appendix 2 – Exploded Views and Parts Lists

"C" Option Control Panel 24 Volt Gas Control Panel – Drawing No. 84711-N




| ITEM | PART NO. | QTY. | DESCRIPTION | ITEM | PART NO. | QTY. | DESCRIPTION |
|------|-----------|------|-------------------------------------|------|------------|------|---|
| 1 | 070023 | 1 | CONTROL PANEL BOTTOM | 32 | * 084717 | 1 | ASSEMBLY TIME RELAY |
| 2 | 070026 | 1 | CONTROL PANEL FRONT | 33 | 084733 | 1 | HARNESS CONTROL PANEL C |
| 3 | 070028 | 1 | CONTROL PANEL SIDE | 34 | 083287 | 1 | LIGHT HLDR CLR LNS W/O BULB |
| 4 | 067680 | 1 | REGULATOR ASSEMBLY VOLTAGE B&D | 35 | 083288 | 1 | LIGHT 28V DC .17A MIN BAYNT MNT |
| 5 | 039271 | 1 | FITTING 90 DEGREE 3/4 | 37 | 070081 | 1 | METER HOURS |
| 6 | 034616 | 1 | FITTING STRAIGHT 3/4 | 38 | 062304 | 1 | AMMETER 40-0-40 DC |
| 7 | 057159 | 1 | CIRCT BRK 2 X 1 ETA 46-500-P | 39 | 055405 | 1 | GAUGE OIL PRESSURE |
| | 053623 | 1 | CIRCT BRK 2.5 X 1 ETA 46-500-P | 40 | 055406 | 1 | GAUGE COOLANT TEMPERATURE |
| | 054502 | 1 | CIRCT BRK 3 X 1 ETA 46-500-P | 41 | 066040 | 1 | DECAL TERMINAL STRIP |
| | 056247 | 1 | CIRCT BRK 3.5 X 1 ETA 46-500-P | 42 | 055089 | 1 | CONN ELEC AMP M-N-L 15 PLUG PNL |
| | 049350 | 1 | CIRCT BRK 4 X 1 ETA 46-500-P | 43 | 070082 | 1 | BLOCKER LIGHT |
| | 048476 | 1 | CIRCT BRK 4.5 X 1 AUT30KW CNT45K | 44 | 053247 | 1 | LUG RNGTNG INS 22-18 X 10 X .322 |
| | 048512 | 1 | CIRCT BRK 5 X 1 ETA 46-500-P | 45 | 029187 | 2 | SPACER .19 X .31 X .50 ST/ZNC |
| | 054450 | 1 | CIRCT BRK 5.5 X 1 ETA 46-500-P | 46 | 077043B | 16" | FLEX CONDUIT .50 ID |
| | 048505 | 1 | CIRCT BRK 6 X 1 ETA 46-500-P | 47 | 029333 | 6 | TIE WRAP 7" WHITE |
| | 048467 | 1 | CIRCT BRK 7 X 1 ETA 46-500-P | 49 | 0C2323 | 10 | SCREW PHM SWAGE 6-32 X 5/8 Z/YC |
| | 048468 | 1 | CIRCT BRK 8 X 1 ETA 46-500-P | 50 | 036904 | 2 | SCREW PPHM #6-32 X 3/4 (NOT SHOWN) |
| | 048470 | 1 | CIRCT BRK 9 X 1 ETA 46-500-P | 51 | 036908 | 2 | SCREW PPHM #6-32 X 1-1/4 |
| 8 | 057335 | 1 | BLOCK TERM 20A 20 X 6 X 1100V | 52 | 022155 | 2 | WASHER LOCK #6 |
| 9 | 046669 | 7 | BLOCK TERM JUMPER FOR S141 | 53 | 022985 | 6 | WASHER FLAT #6-M4 |
| 10 | ** 081767 | 1 | RELAY PNL 24VDC DPDT 10A | 54 | 022188 | 2 | NUT HEX #6-32 STEEL |
| 11 | 070042 | 1 | METER FREQUENCY 55-65HZ | 55 | 036918 | 4 | SCREW PPHM #8-32 X 1/2 |
| | 070042A | 1 | METER FREQUENCY 240V 45-55HZ | 56 | 022264 | 11 | WASHER LOCK M4 |
| 12 | 070054 | 1 | AMMETER AC 0 TO 50 | 57 | 033121 | 14 | SCREW HHM 10-32 X 1/2 |
| | 070055 | 1 | AMMETER AC 0 TO 100 | 58 | 022152 | 22 | WASHER LOCK #10 |
| | 070056 | 1 | AMMETER AC 0 TO 150 | 59 | 023897 | 15 | WASHER FLAT #10 ZINC |
| | 070045 | 1 | AMMETER AC 0 TO 200 | 60 | 022158 | 11 | NUT HEX #10-32 STEEL |
| | 070057 | 1 | AMMETER AC 0 TO 300 | 61 | 038150 | 8 | WASHER FLAT #8 ZINC |
| | 070058 | 1 | AMMETER AC 0 TO 400 | 62 | 022471 | 4 | NUT HEX #8-32 STEEL |
| | 070059 | 1 | AMMETER AC 0 TO 600 | 63 | 084787 | 1 | CABLE RIBBON 16" |
| | 070060 | 1 | AMMETER AC 0 TO 800 | 64 | 070083 | 1 | ASSEMBLY ENGINE MONITOR |
| 13 | 070043 | 1 | METER VOLT AC 0-300 | 65 | 082985 | 1 | ASSEMBLY RESISTER 68 OHM 5W |
| | 070044 | 1 | METER VOLT AC 0-600 | 66 | 082984 | 1 | ASSEMBLY RESISTER 120 OHM 2W |
| 14 | 083089 | 1 | ASSY BOARD "C" CONTROL 12/24V | 67 | 098940 | 1 | HARNESS C-OPT CTRL PNL |
| 15 | 0C2428 | 8 | SCREW TAPTITE PH #6-32 X 1/2 ZYC | 69 | 023762 | 3 | WASHER SHAKEPROOF EXT #10 STL |
| 17 | 064000 | 1 | CONTROL PANEL SIDE | 70 | 055444 | 1 | SINK HEAT |
| 18 | 064008 | 1 | COVER CONTROL PANEL TOP (NOT SHOWN) | 71 | 030468 | 1 | WASHER STEP NYLON .20 |
| 19 | 084736 | 1 | DECAL TERMINAL STRIP | 72 | 049939 | 1 | RECTIFIER MSC 12A 600V 1N1206R |
| 20 | 026536 | 1 | PLUG STEEL 0.5 | 73 | 070370 | 2 | WASHER MICA .203 |
| 21 | 055867 | 1 | SWITCH SPDT 15A SPD TGGL MOM | 75 | 086266 | 1 | RESISTOR WW LUG 75R 5% 25W |
| 22 | 067625 | 1 | SWITCH 3P TRIP THR 15/10A TGGL | 76 | 022507 | 4 | SCREW HHC 1/4-20 X 1/2 G5 (NOT SHOWN) |
| 23 | 032300 | 1 | HOLDER FUSE | 77 | 022097 | 8 | WASHER LOCK M6-1/4 (NOT SHOWN) |
| 24 | 022676 | 1 | FUSE 15A X AGC15 | 78 | 040479 | 4 | MOUNT VIBR 1.0 X 1.0 X 1/4-20 (NOT SHOWN) |
| 25 | 040213 | 4 | PCB SUPPORT SNAP-IN 1/4 | 79 | 0441140156 | 1 | WIRE ASSY 18AWG #0 (NOT SHOWN) |
| 26 | 024469 | 2 | SCREW TAPTITE #10-32 X 3/8 BP | 80 | 033147 | 1 | SCREW HHM #10-32 X 1 (NOT SHOWN) |
| 27 | 061945 | 1 | SWITCH 6A AMP/V SELECTOR | 81 | 0C1299 | 1 | DECAL WARNING |
| 28 | 071361 | 1 | POTENTIOMETER 5K +/-10% 2.25W PNL | | | | |
| 29 | 050123 | 1 | KNOB PLASTIC .25 SHAFT | | | | |
| 30 | 055349 | 1 | INSULATOR | | | | |
| 31 | 070030 | 1 | COVER GENERAC SILKSCREEN | | | | |

* USED ON 13.3L SPARK IGNITED ONLY

** USED ON 13.3L TURBO SPARK ONLY


Appendix 2 – Exploded Views and Parts Lists

**"C" Option Control Panel 12 Volt Diesel
Control Panel – Drawing No. 85027-H**



Appendix 2 – Exploded Views and Parts Lists


"C" Option Control Panel 12 Volt Diesel Control Panel – Drawing No. 85027-H



| ITEM | PART NO. | QTY. | DESCRIPTION | ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|-----------------------------------|------|------------|------|--|
| 1 | 070023 | 1 | CONTROL PANEL BOTTOM | | 070057 | 1 | AMMETER AC 0 TO 300 |
| 2 | 070026 | 1 | CONTROL PANEL FRONT | | 070058 | 1 | AMMETER AC 0 TO 400 |
| 3 | 070028 | 1 | CONTROL PANEL SIDE | | 070059 | 1 | AMMETER AC 0 TO 600 |
| 4 | 067680 | 1 | REGULATOR VOLT 60HZ | | 070060 | 1 | AMMETER AC 0 TO 800 |
| | 092952 | 1 | REGULATOR VOLT 50HZ | 35 | 070043 | 1 | METER VOLT AC 0 TO 300 |
| 5 | 039271 | 1 | FITTING 90 DEGREE 3/4 | | 070044 | 1 | METER VOLT AC 0 TO 600 |
| 6 | 034616 | 1 | FITTING STRAIGHT 3/4 | 36 | 070202 | 1 | LIGHT PANEL |
| 7 | 057159 | 1 | CIRCT BRK 2 X 1 ETA 46-500-P | 37 | 070081 | 1 | METER HOURS |
| | 053623 | 1 | CIRCT BRK 2.5 X 1 ETA 46-500-P | 38 | 062304 | 1 | AMMETER 40-0-40 DC |
| | 054502 | 1 | CIRCT BRK 3 X 1 ETA 46-500-P | 39 | 055405 | 1 | GAUGE OIL PRESSURE |
| | 056247 | 1 | CIRCT BRK 3.5 X 1 ETA 46-500-P | 40 | 055406 | 1 | GAUGE COOLANT TEMPERATURE |
| | 049350 | 1 | CIRCT BRK 4 X 1 ETA 46-500-P | 41 | 070083 | 1 | ASSY ENGINE MONITOR |
| | 048476 | 1 | CIRCT BRK 4.5 X 1 AUT 30KW CNT45K | 42 | 055089 | 1 | CONN ELEC AMP M-N-L 15PLUG PNL |
| | 048512 | 1 | CIRCT BRK 5 X 1 ETA 46-500-P | 43 | 070082 | 1 | BLOCKER LIGHT |
| | 054450 | 1 | CIRCT BRK 5.5 X 1 ETA 46-500-P | 44 | 053247 | 1 | LUG RNGTNG INS 22-18 X 10 X .322 |
| | 048505 | 1 | CIRCT BRK 6 X 1 ETA 46-500-P | 45 | 029187 | 2 | SPACER .19 X .31 X .50 ST/ZNC |
| | 048467 | 1 | CIRCT BRK 7 X 1 ETA 46-500-P | 46 | 077043B | 16" | FLEX CONDUIT .50 ID |
| | 048468 | 1 | CIRCT BRK 8 X 1 ETA 46-500-P | 49 | 0C2323 | 12 | SCREW PHM SWAGE 6-32X5/8 Z/YC |
| | 048470 | 1 | CIRCT BRK 9 X 1 ETA 46-500-P | 51 | 036908 | 2 | SCREW PPHM #6-32 X 1-1/4 |
| 8 | 044213 | 1 | RESIST MISC 10R X 12W | 52 | 022155 | 2 | WASHER LOCK #6 |
| 9 | 025192 | 1 | RECTIFIER MSC 2A 600V 1N5062 | 53 | 022985 | 2 | WASHER FLAT #6 |
| 10 | 048352 | 1 | RESIST MISC 5R X 25W | 54 | 022188 | 2 | NUT HEX #6-32 STEEL |
| | 057907 | 1 | RESISTOR WW LUG 10R 10% 25W | 55 | 036918 | 4 | SCREW HHM #8-32 X 1/2 |
| | 057405 | 1 | RESIST MISC 25R X 25W | 56 | 022264 | 6 | WASHER LOCK M4 |
| 11 | 055444 | 1 | HEAT SINK 13.3L | 57 | 033121 | 14 | SCREW HHM 10-32 X 1/2 |
| 12 | 030468 | 1 | WASHER STEP NYLON .20 | 58 | 022152 | 20 | WASHER LOCK #10 |
| 13 | 049939 | 1 | RECTIFIER MSC 12A 600V 1N1206R | 59 | 023897 | 12 | WASHER FLAT #10 |
| 14 | 083089 | 1 | BOARD "C" CONTROL 12/24V | 60 | 022158 | 9 | NUT HEX #10-32 STEEL |
| 15 | 024469 | 2 | SCREW TAPTITE #10-32X3/8 BP | 61 | 038150 | 4 | WASHER FLAT #8 ZINC |
| 17 | 085058 | 1 | HARNESS 12 VOLT DIESEL | 62 | 022471 | 4 | NUT HEX #8-32 STEEL |
| 18 | 029333 | 6 | TIE WRAP 7" WHITE | 63 | 084787 | 1 | CABLE RIBBON 16" |
| 19 | 070097 | 1 | DECAL TERMINAL STRIP | 64 | 070370 | 2 | WASHER MICA .203 |
| 20 | 055920 | 1 | SWITCH 1PST PSADE PNL MNT | 65 | 063617 | 1 | RELAY PNL 12VDC DPDT 10A @ 240VA |
| 21 | 055867 | 1 | SWITCH SPDT 15A SPD TGGL MOM | 66 | 023762 | 1 | WASHER SHAKEPROOF EXT #10 STL |
| 22 | 067625 | 1 | SWITCH 3P TRIP THR 15/10A TGGL | 67 | 057335 | 1 | BLOCK TERM 20A 20 X 6 X 1100V |
| 23 | 032300 | 1 | HOLDER FUSE | 68 | 046669 | 5 | JUMPER TERMINAL BLOCK |
| 24 | 022676 | 1 | FUSE 15A X AGC15 | 69 | 098940 | 1 | HARNESS C-OPTION CONTROL PANEL |
| 25 | 040213 | 4 | CONN PCB SUP SNAP-IN | 70 | 064000 | 1 | SIDE CONTROL PANEL |
| 26 | 0C2428 | 8 | SCREW TAPTITE PH #6-32 X 1/2 ZYC | 71 | 064008 | 1 | COVER CONTROL PANEL TOP (NOT SHOWN) |
| 27 | 061945 | 1 | SWITCH 6A AMP/V SELECTOR | | | | |
| 28 | 071361 | 1 | POTENTIO PNL 5K +/-10% 2.25W | 72 | 066040 | 1 | DECAL TERMINAL STRIP |
| 29 | 050123 | 1 | KNOB PLASTIC .25 SHAFT | 73 | 022507 | 4 | SCREW HHC 1/4-20 X 1/2 G5 (NOT SHOWN) |
| 30 | 055349 | 1 | INSULATOR | | | | |
| 31 | 070030 | 1 | COVER SILKSCREEN | 74 | 022097 | 8 | WASHER LOCK M6-1/4 (NOT SHOWN) |
| 32 | 070080 | 2 | INSULATOR | 75 | 040479 | 4 | MOUNT VIBR 1.00X1.00X1/4-20 (NOT SHOWN) |
| 33 | 070042 | 1 | METER FREQUENCY 55-65HZ | | | | |
| | 070042A | 1 | METER FREQUENCY 240V 45-55HZ | 76 | 036904 | 2 | SCREW PPHM #6-32 X 3/4 (NOT SHOWN) |
| 34 | 070054 | 1 | AMMETER AC 0 TO 50 | | | | |
| | 070055 | 1 | AMMETER AC 0 TO 100 | 77 | 0441140156 | 1 | ASSY WIRE 18AWG #15 (NOT SHOWN) |
| | 070056 | 1 | AMMETER AC 0 TO 150 | 78 | 033147 | 1 | SCREW HHM #10-32 X 1 (NOT SHOWN) |
| | 070045 | 1 | AMMETER AC 0 TO 200 | | | | |

Appendix 2 – Exploded Views and Parts Lists


**"C" Option Control Panel 12 Volt Gas
Control Panel – Drawing No. 085026-J**




SEE WIRING DIAGRAM #85024 FOR
INSTALLATION OF WIRE HARNESS ASM.

Appendix 2 – Exploded Views and Parts Lists

"C" Option Control Panel 12 Volt Gas Control Panel – Drawing No. 085026-J




| ITEM | PART NO. | QTY. | DESCRIPTION | ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|----------------------------------|--------|------------|---------------------|------------------------------------|
| 1 | 070023 | 1 | PANEL BOTTOM CONTROL | 070045 | 1 | AC AMMETER-0 TO 200 | |
| 2 | 070026 | 1 | PANEL FRONT CONTROL | 070057 | 1 | AC AMMETER-0 TO 300 | |
| 3 | 070028 | 1 | PANEL SIDE CONTROL | 070058 | 1 | AC AMMETER-0 TO 400 | |
| 4 | 067680 | 1 | REGULATOR ASSY VOLTAGE 60HZ | 070059 | 1 | AC AMMETER-0 TO 600 | |
| | 092952 | 1 | REGULATOR ASSY VOLTAGE 50HZ | 070060 | 1 | AC AMMETER-0 TO 800 | |
| 5 | 039271 | 1 | FITTING 90DEGREE ¾ | 35 | 070043 | 1 | AC VOLTMETER-0 TO 300 |
| 6 | 034616 | 1 | FITTING STRAIGHT ¾ | | 070044 | 1 | AC VOLTMETER-0 TO 600 |
| 7 | 057159 | 1 | CIRCT BRK 2 X 1 ETA 46-500-P | 36 | 070202 | 1 | LIGHT PANEL #26306C |
| | 053623 | 1 | CIRCT BRK 2.5 X 1 ETA 46-500-P | 37 | 070081 | 1 | METER HOURS |
| | 054502 | 1 | CIRCT BRK 3 X 1 ETA 46-500-P | 38 | 062304 | 1 | AMMETER 40-0-40 DC |
| | 056247 | 1 | CIRCT BRK 3.5 X 1 ETA 46-500-P | 39 | 055405 | 1 | GAUGE OIL PRESSURE |
| | 049350 | 1 | CIRCT BRK 4 X 1 ETA 46-500-P | 40 | 055406 | 1 | GAUGE COOLANT TEMPERATURE |
| | 048476 | 1 | CIRCT BRK 4.5 X 1 AUT30KW CNT45K | 41 | 070083 | 1 | ASSY ENGINE MONITOR |
| | 048512 | 1 | CIRCT BRK 5 X 1 ETA 46-500-P | 42 | 055089 | 1 | CONN ELEC AMP M-N-L 15PLUG PNL |
| | 054450 | 1 | CIRCT BRK 5.5 X 1 ETA 46-500-P | 43 | 070082 | 1 | LIGHT BLOCKER |
| | 048505 | 1 | CIRCT BRK 6 X 1 ETA 46-500-P | 44 | 053247 | 1 | LUG RNGTNG INS 22-18X10X.322 |
| | 048467 | 1 | CIRCT BRK 7 X 1 ETA 46-500-P | 45 | 029187 | 2 | SPACER .19X.31X.50 ST/ZNC |
| | 048468 | 1 | CIRCT BRK 8 X 1 ETA 46-500-P | 46 | 077043B | 16" | FLEX CONDUIT .50 ID |
| | 048470 | 1 | CIRCT BRK 9 X 1 ETA 46-500-P | 49 | 0C2323 | 12 | SCREW PHM SWAGE 6-32X5/8 Z/YC |
| 8 | 044213 | 1 | RESIST MISC 10RX12W | 51 | 036908 | 1 | SCREW PPHM #6-32 X 1-1/4 |
| 9 | 025192 | 1 | RECTIFIER MSC 2A 600V 1N5062 | 52 | 022155 | 2 | WASHER LOCK #6 |
| 10 | 044213 | 1 | RESIST MISC 10RX12W | 53 | 022985 | 2 | WASHER FLAT #6 |
| 11 | 055444 | 1 | HEAT SINK 13.3L | 54 | 022188 | 2 | NUT HEX #6-32 STEEL |
| 12 | 030468 | 1 | WASHER STEP NYLON .20 | 55 | 036918 | 4 | SCREW PPHM #8-32 X ½ |
| 13 | 049939 | 1 | RECTIFIER MSC 12A 600V 1N1206R | 56 | 022264 | 6 | WASHER LOCK M4 |
| 14 | 083089 | 1 | ASSY PCB "C" CONTROL 12/24V | 57 | 033121 | 14 | SCREW HHM 10-32 X ½ |
| 15 | 024469 | 2 | SCREW TAPTITE #10-32X3/8 BP | 58 | 022152 | 22 | WASHER LOCK #10 |
| 17 | 085025 | 1 | HARNESS 12-V. GAS | 59 | 023897 | 14 | WASHER FLAT #10 ZINC |
| 18 | 029333 | 6 | TIE WRAP 7" WHITE | 60 | 022158 | 9 | NUT HEX #10-32 STEEL |
| 19 | 070097 | 1 | DECAL TERMINAL STRIP | 61 | 038150 | 4 | WASHER FLAT #8 ZINC |
| 20 | 026536 | 1 | PLUG STEEL 0.5 | 62 | 022471 | 4 | NUT HEX #8-32 STEEL |
| 21 | 055867 | 1 | SWITCH SPDT 15A SPD TGGL MOM | 63 | 084787 | 1 | CABLE RIBBON 16" |
| 22 | 067625 | 1 | SWITCH 3P TRIP THR 15/10A TGGL | 64 | 070370 | 2 | WASHER MICA .203 |
| 23 | 032300 | 1 | FUSE HOLDER | 65 | 063617 | 1 | RELAY PNL 12VDC DPDT 10A@240VA |
| 24 | 022676 | 1 | FUSE 15A X AGC15 | 66 | 023762 | 1 | WASHER SHAKEPROOF EXT #10 STL |
| 25 | 040213 | 4 | PCB SUPPORT SNAP-IN 1/4 | 67 | 057335 | 1 | BLOCK TERM 20A 20 X 6 X 1100V |
| 26 | 0C2428 | 8 | SCREW TAPTITE PH #6-32X1/2 ZYC | 68 | 046669 | 5 | BLOCK TERM JUMPER |
| 27 | 061945 | 1 | SWITCH 6A AMP/V SELECTOR | 69 | 098940 | 1 | HARNESS "C" OPTION |
| 28 | 071361 | 1 | POTENTIO PNL 5K +/-10% 2.25W | 70 | 064000 | 1 | PANEL SIDE CONTROL |
| 29 | 050123 | 1 | KNOB PLASTIC .25 SHAFT | 71 | 064008 | 1 | PANEL TOP CONTROL (NOT SHOWN) |
| 30 | 055349 | 1 | INSULATOR | 72 | 066040 | 1 | DECAL TERMINAL STRIP |
| 31 | 070030 | 1 | COVER GENERAC SILKSCREEN | 73 | 036904 | 2 | SCREW PPHM #6-32 X 3/4 (NOT SHOWN) |
| 32 | 070080 | 2 | INSULATOR | 74 | 022507 | 4 | SCREW HHC 1/4-20 X 1/2 G5 |
| 33 | 070042 | 1 | METER FREQUENCY 60HZ | 75 | 040479 | 4 | MOUNT VIBR 1.00X1.00X1/4-20 |
| | 070042A | 1 | METER FREQUENCY 50HZ | 76 | 022097 | 8 | WASHER LOCK M6-1/4 |
| 34 | 070054 | 1 | AC AMMETER-0 TO 50 | 77 | 0441140156 | 1 | ASSY WIRE 18AWG #0 (NOT SHOWN) |
| | 070055 | 1 | AC AMMETER-0 TO 100 | 78 | 033147 | 1 | SCREW HHM #10-32 X 1 (NOT SHOWN) |
| | 070056 | 1 | AC AMMETER-0 TO 150 | 79 | 0C1299 | 1 | DECAL WARNING |









Appendix 3 – Interconnection Diagram

"C" Option Control Panel 12 Volt Gas Interconnection Diagram – Drawing No. 87625



Appendix 3 – Interconnection Diagram

“C” Option Control Panel 12 Volt Gas Interconnection Diagram – Drawing No. 87625






Appendix 3 – Interconnection Diagram

"C" Option Control Panel 24 Volt Diesel

Interconnection Diagram – Drawing No. 87624









NOTES:

- 3-POLE, 1-PHASE & 4-POLE, 3-PHASE TRANSFER SWITCHES GENERALLY NOT EQUIPPED WITH NEUTRAL BLOCK
- 4.0L & 6.4L UNITS REQUIRE 120 VAC FOR ENGINE COOLANT PUMP HEATER, 13.3L UNITS REQUIRE 240 VAC - SEE INSERTS
- SEE INSERTS 'D' & 'E'
- TB3/PIN 61&200 INCLUDED WITH OPTIONAL PRE-ALARM LIGHTS ON GENERATOR CONTROL PANEL ON UNITS WITHOUT TB3 CONNECT WIRES 500 THRU 506 DIRECTLY TO REMOTE ANNUNCIATOR
- MODEL 8235 ALARM HORN SHOWN FOR 'C'-OPTION UNITS TB2 TERMINALS 209-210-211 CONNECT TO ALARM RELAY CONTACTS. FOR 'A' & 'B' OPTION UNITS, SEE INSET 'G'.
- 209 (NC) CONTACTS OPEN ON ANNUNCIATED SHUTDOWN
- 211 (NO) CONTACTS CLOSE ON ANNUNCIATED SHUTDOWN
- 210 (C) CONNECT TO FUSE +24V DC CIRCUIT AS SHOWN

Appendix 3 – Interconnection Diagram

"C" Option Control Panel 24 Volt Diesel Interconnection Diagram – Drawing No. 87624



Part II

Remote Annunciator Panels


1.1 THREE LIGHT REMOTE ANNUNCIATOR

The Generac Three Light Remote Annunciator (Figure 1.1) provides a valuable reference when used with the Generac automatic transfer switch and standby generator with a C option control panel.

This equipment is designed to be mounted remotely from the standby generator set. The panel, when properly interconnected with a Generac standby generator system and transfer switch, annunciates up to three (3) standby electric system operating parameters.

- **Utility Power Supply:** This light comes ON when customer electric loads are being powered by the NORMAL (utility) power source.
- **Emergency Power Supply:** This light comes ON when customer electric loads are being powered by the EMERGENCY (standby) power source.
- **Generator Fault Light:** This light comes ON when the generator engine has shut down automatically due to a fault condition (such as low oil pressure, high coolant temperature, overcrank, overspeed, or RPM sensor loss). Fault conditions that will result in an automatic engine shutdown are discussed in the INSTRUCTIONS AND PARTS MANUAL for the applicable generator set.

Figure 1.1 — Model 8848 Annunciator Panel Lights



◆ 1.1.1 INSTALLATION

Mount the annunciator at any convenient location near or remote from the standby generator. Mounting dimensions are shown in Appendix ????. Holes are provided for fastening the panel to a desk, wall or other convenient object. Four 7/8" (22mm) holes are also provided for routing of required wiring into the panel. Installation must comply with all applicable codes and regulations.

Required wiring between the Model 8848 annunciator, the Generac generator meter and control (upper) panel, and transfer switch auxiliary contacts are shown in Appendix ???, Interconnection Diagram.

NOTE:


Two different types of auxiliary contacts may be encountered on Generac transfer switches.

1.2 FIVE LIGHT REMOTE ANNUNCIATOR

The Model 8617 Remote Annunciator Panel (Figure 1.2), when properly interconnected with a Generac standby generator equipped with an Option C control panel, will provide remote annunciation of the same five engine operating parameters as the generator panel. The remote panel mounts five advisory lamps. On occurrence of one or more of the panel monitored faults, the applicable lamp will illuminate and the horn will sound. Both the lamp(s) and the Alarm Horn can be turned OFF by depressing the Reset switch. All five lamps may be tested by actuating the Test switch. The following engine fault conditions will be indicated on the annunciator panel:

- Low Engine Oil Pressure
- High Engine Coolant Temperature/Low Coolant Level
- Overcrank Condition
- Overspeed Condition
- RPM Sensor Loss Condition

Figure 1.2 — Model 8617 Remote Annunciator



◆ 1.2.1 OPERATION

Both the remote and generator panel advisory lamps are controlled by a single DC CONTROL-LATCH-CRANK circuit board housed in the generator control console. Engine mounted, normally open (N.O.) switches and sensors provide the necessary signal to the circuit board on occurrence of a monitored engine fault. should any one (or more) of the monitored faults occur, an automatic engine shutdown, illumination of the applicable lamp(s), and sounding of the Alarm Horn will occur. circuit board action will then “latch” the fault. That is, the applicable lamp(s) will remain ON after engine shutdown. While any lamp remains lighted (latched), further attempts at generator cranking and startup are inhibited. A 12 volt DC input is required to operate the panel.

NOTE:

See applicable standby generator owner’s manual for more detailed operational description of remote and generator panel lamps.

◆ 1.2.2 CUSTOMER CONNECTIONS

Suitable, approved wiring must be purchased for interconnection of the Remote Annunciator Panel with Terminal block TB2. Connect each wire to a numbered terminal block screw and to an identically numbered terminal in the remote annunciator panel. A total of nine wires are required. Numbered terminals may be identified as follows:

- #94 — Low Oil Pressure Shutdown
- #95 — High Coolant Temperature/Low Coolant Level Shutdown
- #96 — Overcrank Shutdown
- #97 — Overspeed Shutdown
- #98 — RPM Sensor Loss Shutdown
- #137 — Test Switch Connections
- #138 — Reset Switch Connections
- #209 — Alarm Relay Normally Closed Contacts*
- #210 — Alarm Relay Common Contacts*
- #211 — Alarm Relay Normally Open Contacts*

* DO NOT EXCEED ONE (1) AMPERE OF CURRENT ACROSS ALARM RELAY CONTACTS.

◆ 1.2.3 PARTS INCLUDED WITH REMOTE PANEL

Factory shipment of any standby generator set which includes the optional Remote Annunciator Panel will include a WIRING HARNESS (Part No. 70287). The WIRING HARNESS includes the following parts:

1. Terminal Block TB2 (Part No. 55911)
2. Terminal Block Decal (Part No. 66040)
3. Alarm Relay (Part No. 63617)
4. The Wiring Harness proper

1.3 18 LIGHT REMOTE ANNUNCIATOR


The Model 9555 Remote Annunciator Panel is a self contained system, utilizing solid state circuits to annunciate up to sixteen (16) engine-driven generator operating parameters (Figure 1.3). The system meets NFPA (National Fire Protection Association) specifications for standby electric power systems.


The system will monitor any sensing device having normally-open (N.O.) contacts which provide a +DC signal to the applicable panel lamp on contacts closure. On contacts closure, both an alarm lamp and an alarm horn are activated and latched in to manual reset. The alarm horn may be silenced without disturbing the visual indication and with any subsequent alarm re-activating the horn. The system includes a test circuit.

NOTE:

The one exception to the normally-open (N.O.) contacts rule is the **LOW BATTERY VOLTAGE lamp. This lamp must be connected to normally-closed (N.C.) contacts on the battery monitor circuit board, located in the generator control panel.**

Figure 1.3 — Model 9555 Remote Annunciator Panel





◆ 1.3.1 GENERATOR STOP SIGNALS

All signals occur when generator shutdown occurs as a result of the failure indicated by the illuminated lamp(s).

1. **High Water Temperature/Low Water Level:** This lamp comes ON and the horn sounds when the generator's high temperature alarm is active.
2. **Low Oil Pressure:** This lamp illuminates and the alarm horn sounds when the generator's low oil pressure alarm is active.
3. **Overspeed:** This lamp turns ON and the alarm horn sounds when the generator's overspeed alarm is active.
4. **Overcrank:** This lamp turns on and the alarm horn sounds when the generator's overcrank alarm is active.
5. **Sensor Loss:** This lamp illuminates and the alarm horn sounds when the generator's rpm sensor loss alarm is active.

◆ 1.3.2 LATCHABLE SIGNALS

The following signals can be individually selected by means of miniature rocker switch on the Remote Panel's monitor circuit board. The available switch positions are "Latch On" and "Latch Off". "Latch Off" indicates the lamp will turn ON only when the signal is present. "Latch On" indicates the lamp will be ON until the monitor "Reset" switch is pressed. The alarm horn sounds when "Latch" is selected. The horn will stay ON until either the "Rearm Horn" or the "Reset" switch is pressed.

1. **Low Battery Voltage:** This lamp illuminates when the generator's battery voltage drops low, indicating a discharge condition.
2. **High Battery Voltage:** This lamp will turn ON when generator battery voltage is high, indicating an overcharge condition.
3. **Battery Charger Failure:** This lamp will illuminate on failure of the generator's battery charge system.
4. **Low Fuel:** This lamp illuminates when an occurrence of a low fuel level in the generator's fuel tank.
5. **Pre-alarm/High Temp.:** This lamp will illuminate to warn of an approaching or imminent high coolant temperature shutdown.
6. **Pre-alarm/Low Temp.:** This lamp will illuminate when the coolant temperature has decreased, indicating an engine coolant heater failure.
7. **Pre-alarm/Low Oil Pressure:** This lamp will illuminate in advance of a low oil pressure shutdown. It indicates engine oil pressure has decreased to near the point of automatic shutdown.

8. **Generator Run:** This lamp illuminates to advise that the generator has started and/or is running. Lamp ON indicates the generator "run" circuit is active (Wire #14 on units with 12 volts DC engine control system, Wire #219 on units with 24 volts DC engine control system).

◆ 1.3.3 OTHER LAMPS

1. **System Ready:** This lamp will be ON to indicate the generator set is able to run. If the lamp is OUT, a "stop" signal is present.
2. **Not In Auto:** This lamp will illuminate to indicate the generator's Auto-Off-Manual switch is NOT set to "Auto" (that is, the switch is set to either "Manual" or "Off" and automatic operation is not possible).
3. **Horn Switch Off:** This lamp will turn ON to indicate the horn switch on the annunciator panel is turned OFF. With the horn switch set to OFF, lamps will not be affected. However, the alarm horn will not sound.
4. **Line Power:** This lamp will be ON when the automatic transfer switch main contacts are in their "Utility" position (and connected to the "Utility" power supply).
5. **Generator Power:** This lamp will turn ON when the transfer switch main contacts are in their "Standby" position, i.e., load is connected to the generator power supply.


◆ 1.3.4 PANEL WIRING INTERCONNECTIONS

All INPUT signal connections are made at a 24 screw terminal block, located on the Remote Panel's MONITOR CIRCUIT BOARD. Use purchased No. 14 AWG wiring for all interconnections. Maximum recommended distance between the Remote Panel and the standby generator should not exceed 1000 feet (305 meters). See page 36 for installer's wiring interconnections.

1.4 TROUBLESHOOTING

Troubleshooting the 18 lamp annunciator is limited to checking wire connections at the generator panel, transfer switch and annunciator, and checking for proper DC inputs to annunciator terminal strip. If all connections and input DC voltage signals are good but a problem still exists with the annunciator operation, replace annunciator circuit board.

1. **Automatic Generator Stop Signals:** The horn and lamp are always latched if one of these signals occurs. Generator stop lamps and horn can be reset by either the test/reset switch at the annunciator or reset of fault lamps at the generator.
2. **Test/Reset:** Pressing the test/reset switch energizes all lamps except the "horn switch off" lamp and the horn. Release of the switch resets the lamps and horn. The test/reset switch has no effect on fault indicators at the genset.



Section 1 – General Information

Remote Annunciator Panels

3. **Latch Select:** The lamps and horn can be selected to be latched by on-board switch. Unlatched signals activate the lamp only; the lamp is de-energized if the fault signal is cleared. Latching provides an audible signal plus keeps the lamp energized as an indicator even if the pre-alarm fault has been cleared.
4. **Rearm:** The rearm clears the horn but not the lamps. The lamps are held active by either latch or fault signal. After rearm, horn is enabled to sound if another fault occurs.
5. **System Ready Lamp:** This lamp indicates the genset is operational. The lamp is energized whenever power is applied to the annunciator circuit and no generator stop signals are present.
6. **Line-Power/Gen Power Lamps:** This indicates the position of the transfer switch. When load is transferred to the genset, the “Generator Power” lamp is lit and the horn sounds.
7. **Horn Switch Off Lamp:** This lamp indicates that power to the horn has been disconnected by a horn disable switch.
8. **Annunciator Delays:** Signals will be annunciated if they exist for the following minimum times:
 - Not in Auto, Horn Off, 100 seconds.
 - Pre-alarm Low Oil Pressure, 10 seconds.
 - All others, 1 second.



1.5 ANNUNCIATED SIGNALS

| Signal | Source | Lamp | Response | Latched | Rearm |
|-----------------|-----------------|--------|-------------|---------|-------|
| High Temp. | Control Board* | Red | Lamp & Horn | Yes | Yes |
| Low Oil | Control Board* | Red | Lamp & Horn | Yes | Yes |
| Overspeed | Control board* | Red | Lamp & Horn | Yes | Yes |
| Overcrank | Control Board* | Red | Lamp & Horn | Yes | Yes |
| Sensor Loss | Control Board* | Red | Lamp & Horn | Yes | Yes |
| System Ready | Annunciator | Green | Lamp | No | N/A |
| Line Power | Transfer Switch | Green | Lamp | No | N/A |
| Generator Power | Transfer Switch | Yellow | Lamp & Horn | No | Yes |
| High Battery | Battery Monitor | Yellow | Lamp & Horn | Select | Yes |
| Low Battery | Battery Monitor | Yellow | Lamp & HOIn | Select | Yes |
| Not In Auto | Control Board | Red | Lamp & Horn | No | No |
| Horn Switch Off | Annunciator | Red | Lamp | No | N/A |


1.6 PRE-ALARMS

| Signal | Source | Lamp | Response | Latched | Rearm |
|---------------------|--------------------|--------|-------------|---------|-------|
| Low Fuel | Float Switch | Yellow | Lamp & Horn | Select | Yes |
| High Temperature | Temperature Switch | Yellow | Lamp & Horn | Select | Yes |
| Low Temperature | Temperature Switch | Yellow | Lamp & Horn | Select | Yes |
| Low Oil | Pressure Switch | Yellow | Lamp & Horn | Select | Yes |
| Generator Run | Control Board | Yellow | Lamp & Horn | Select | Yes |
| Battery Charge Fail | Battery Monitor | Yellow | Lamp & Horn | Select | Yes |


Appendix 4 – Electrical Data
 Three Light Remote Annunciator
 Mounting Dimensions



ALL DIMENSIONS IN INCHES AND CENTIMETERS






Appendix 4 – Electrical Data
Five Light Remote Annunciator
Mounting Dimensions



Appendix 4 – Electrical Data


18 Light Remote Annunciator
Mounting Dimensions








Appendix 4 – Electrical Data

Three Light Remote Annunciator Interconnection Diagram



Appendix 4 – Electrical Data
 Five Light Remote Annunciator
 Interconnection Diagram








Appendix 4 – Electrical Data


**Five Light Remote Annunciator
Electrical Schematic – Drawing No. 066561**

- Legend**
- L1 = Low Oil Pressure Lamp
 - L2 = High Coolant Temperature Lamp
 - L3 = Overcrank Lamp
 - L4 = Overspeed Lamp
 - L5 = RPM Sensor Loss Lamp
 - SW1 = Reset Switch
 - SW2 = Test Switch
 - H1 = Alarm Horn




Appendix 4 – Electrical Data
Three Light Remote Annunciator
Electrical Schematic – Drawing No. 067787







Appendix 4 – Electrical Data
18 Light Remote Annunciator
Wiring Diagram – Drawing No. 086833-C




Appendix 5 – Exploded Views and Parts Lists

Three Light Remote Annunciator
Drawing No. 067786




| ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|--|
| 1 | 022442 | 4 | NO. 6-32 X 3/8" ROUND HEAD MACHINE SCREW |
| 2 | 064009-A | 1 | LAMP - YELLOW |
| 3 | 064009-B | 1 | LAMP - GREEN |
| 4 | 067783 | 1 | PANEL (SILKSCREENED) |
| 5 | 056892 | 4 | NO. 10-24 X 3/8" CRIMPTITE SCREW |
| 6 | 059143 | 1 | FRONT PANEL |
| 7 | 059144 | 1 | PANEL SUPPORT BRACKET |
| 8 | 022471 | 2 | NO. 8-32 HEX NUT |
| 9 | 022264 | 2 | NO. 8 LOCK WASHER |
| 10 | 059149 | 1 | GENERAC DECAL |
| 11 | 046357 | 1 | TERMINAL BLOCK |
| 12 | 036919 | 2 | NO. 8-32 X 5/8" PAN HEAD MACHINE SCREW |
| 13 | 067784 | 1 | TERMINAL BLOCK DECAL |
| 14 | 059142 | 1 | ENCLOSURE |
| 15 | 064009 | 1 | LAMP - RED |



Appendix 5 – Exploded Views and Parts Lists



Five Light Remote Annunciator Mounting Locations in Generator Control Console for Optional Terminal Boards and Alarm Relay



| ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|--|
| 1 | 066040 | 1 | DECAL, TERMINAL BOARD |
| 2 | 055911 | 1 | BOARD, TERMINAL |
| 3 | 063617 | 1 | RELAY, ALARM |
| 4 | | 1 | BOARD, TERMINAL & DECAL (OPTIONAL PRE-ALARM) |

Appendix 5 – Exploded Views and Parts Lists

Five Light Remote Annunciator Panel Assembly - Drawing No. 066559-B




| ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|-------|------------------------------|
| 1 | 066556 | 1 | FRONT PANEL |
| 2 | 066558 | 1 | SUPPORT - TERMINAL STRIP |
| 3 | 064012 | 1 | MONITER PANEL - SILKSCREENED |
| 4 | 059149 | 1 | DECAL - GENERAC |
| 5 | 064009 | 5 | INDICATOR LIGHT (RED) |
| 6 | 055920 | 2 | PUSH BUTTON SWITCH |
| 7 | 049441 | 4 | #6-32 X 3/8" TAPTITE |
| 8 | 061286 | 1 | SOUND - ALERT |
| 9 | 055911 | 1 | TERMINAL STRIP |
| 10 | 059150-A | 1 | DECAL |
| 11 | 036919 | 2 | #8-32 X 5/8" PPHMS |
| 12 | 022264 | 2 | #8 LOCK WASHER |
| 13 | 022471 | 2 | #8-32 HEX NUT |
| 14 | 030957 | 2 | RECEPTACLE LUG 1/4" |
| 15 | 028799 | 5 | RECEPTACLE LUG 1/4" |
| 16 | 032012 | 14.5" | #20 BARE COPPER WIRE |



Appendix 5 – Exploded Views and Parts Lists


Five Light Remote Annunciator
 Harness (098940) - Drawing No. 070287-C




| ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|-------------|
| 1 | 098940 | 1 | HARNESS |
| 2 | 063617 | 1 | RELAY |

Appendix 5 – Exploded Views and Parts Lists


Five Light Remote Annunciator Harness (C Option Control Panel) - Drawing No. 098940-C



| WIRE # | LGTH. | WIRE DESC. | LUG #1 | LUG #2 | FROM | TO |
|--------|-------|-------------------|---------------------|--|------|----|
| 94 | 26.5 | UL 1007/1569 TEW | ETC# AA-2190-06X-T | AMP# 35 0980-3 | A1 | C4 |
| 95 | 26.06 | #18 AWG 300V | INSULATED SNAPSPADE | OR EQUIVALENT | A2 | C5 |
| 96 | 25.62 | 16 STRANDS/30 AWG | #6 SCREW 18-22 AWG | | A3 | C2 |
| 97 | 25.19 | DK BLUE COLOR | OR EQUIVALENT | | A4 | C6 |
| 98 | 24.75 | | | | A5 | C1 |
| 137 | 24.31 | | | | A6 | C3 |
| 209 | 7.00 | | | ETC# BB-8138-T | A8 | B |
| 210 | 6.56 | | | INSULATED FASTON | A9 | B |
| 211 | 6.12 | | | .187 X .020" #18-22 AWG | A10 | B |
| 228 | 19.5 | | | 0.25" PIGGYBACK FASTON GENERAC P/N - 028800 | A12 | D |






| ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|---------------------------------|
| 1 | 055911 | 1 | TERMINAL BLOCK VERNITRON #09012 |
| 2 | 071271 | 1 | CONNECTOR 6-CKT AMP P/N 640250 |
| 3 | 028739 | 12 | TIE WRAP 4" |



Appendix 5 – Exploded Views and Parts Lists

18 Light Remote Annunciator Drawing No. 086585-C



| ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|--------------------------|
| 1 | 086582 | 1 | PANEL, ANNUNCIATOR REAR |
| 2 | 084968 | 1 | PC BOARD - MONITOR |
| 3 | 086579 | 1 | SUPPORT, PC BOARD |
| 4 | 040213 | 6 | PCB STAND OFF |
| 5 | 086580 | 2 | SUPPORT, PC BOARD |
| 6 | 036901 | 6 | #6-32 X 3/8" PHCS |
| 7 | 086581 | 1 | PANEL, ANNUNCIATOR FRONT |
| 8 | 061282-A | 1 | DECAL, CLEAR LEXAN |
| 9 | 061283 | 1 | SWITCH, ON/OFF |
| 10 | 061284 | 2 | SWITCH, TEST/RESET |
| 11 | 032300 | 1 | HOLDER, FUSE |
| 12 | 044299 | 1 | FUSE, 1 AMP |
| 13 | 061286 | 1 | SOUNALERT |
| 14 | 077704 | 1 | PLUG |
| 15 | 086584 | 1 | DECAL, ATTENTION |

| ITEM | PART NO. | QTY. | DESCRIPTION |
|-------------------------|----------|------|-----------------------|
| 16 | 056892 | 4 | CRIMPTITE |
| 17 | 025034 | 2 | PLUG BUTTON |
| 18 | 086583 | 2 | DECAL, ANNUNCIATOR |
| 29* | 028739 | 2 | TIE WRAP |
| 30†¥ | 048766 | 1 | TERM BLOCK |
| 31†¥ | 055869 | 1 | SWITCH - TOGGLE, SPST |
| 32 | 022985 | 6 | #6 FLAT WASHER |
| 33 | 022155 | 6 | #6 LOCK WASHER |
| 34 | 022188 | 6 | #6-32 HEX NUT |
| * NOT SHOWN | | | |
| SERIES | | | |
| † 86585B — 86583 DECAL | | | |
| ¥ 86585M — 86583M DECAL | | | |

GENERAC® POWER SYSTEMS, INC.

P.O. BOX 8
WAUKESHA, WI 53187

Part No. OC4205

Revision B (09/27/02)

Printed in U.S.A.