


# Operation and Installation

## Automatic Transfer Switches



Models:

**TES**  
**TLS**

Contactors:

Electrically Held  
Mechanically Held

25-400 Amperes

**KOHLER**<sup>®</sup>  
POWER SYSTEMS

**ISO 9001**  
**KOHLER**  
GENERATORS  
INTERNATIONALLY REGISTERED  
U.S.A. Plant ISO Registered

TP-5659 11/93a

# Service Assistance

For service or information, check the yellow pages of the telephone directory under the heading GENERATORS-ELECTRIC for the authorized Kohler service distributor/dealer.

KOHLER CO., Kohler, Wisconsin 53044  
Phone 920-565-3381  
Fax 920-459-1646 (North American Sales)  
920-459-1614 (International Sales)  
For Sales and Service in U.S.A. and Canada  
Phone 1-800-544-2444

In any communications regarding the automatic transfer switch, please include the MODEL and SERIAL numbers as found on the nameplate attached to the transfer switch. Enter the numbers in the spaces provided below. This information will enable the authorized Kohler service distributor/dealer to supply the correct part or data for this particular model.

Model No. \_\_\_\_\_

Serial No. \_\_\_\_\_

# Table of Contents

SUBJECT	PAGE	SUBJECT	PAGE
<b>Safety Precautions</b> .....	i	Mechanical Installation .....	3-1
<b>Glossary of Abbreviations</b> .....	ii	Lifting .....	3-1
<b>Section 1. Introduction</b> .....	<b>1-1</b>	Mounting .....	3-1
Scope and Purpose of Manual .....	1-1	Electrical Wiring .....	3-2
Purpose of Manual .....	1-1	Power Connections .....	3-2
List of Related Manuals .....	1-1	Start Generator Connections .....	3-3
Arrangement of Manual .....	1-1	Other Accessory Connections .....	3-3
Automatic Transfer Switch Description .....	1-1	<b>Section 4. Operation</b> .....	<b>4-1</b>
Purpose of Switch .....	1-1	Switches and Indicators .....	4-1
Components of Switch .....	1-1	Automatic Operation .....	4-1
Sequence of Operation .....	1-4	Manual Operation .....	4-1
<b>Section 2. Specifications</b> .....	<b>2-1</b>	<b>Section 5. Accessories</b> .....	<b>5-1</b>
Ratings .....	2-1	Program Transition .....	5-1
Specifications .....	2-3	Description .....	5-1
<b>Section 3. Installation</b> .....	<b>3-1</b>	Adjustment .....	5-1
Upon Receipt of Unit .....	3-1	Other Accessories .....	5-1
Inspection .....	3-1	<b>Section 6. Diagrams &amp; Drawings</b> .....	<b>6-1</b>
Storage .....	3-1	Enclosure Drawings .....	6-1

# Safety Precautions

A transfer switch, like any other electrical device, can pose potential dangers to life and limb if improperly maintained or imprudently operated. The best way to prevent accidents is to be aware of the potential dangers and to always use good common sense. In the interest of safety, some general precautions relating to operating of a transfer switch follow. Keep these in mind.

This manual contains several types of safety precautions which are explained below.

## DANGER

Danger is used to indicate the presence of a hazard that *will* cause severe personal injury, death, or substantial property damage if the warning is ignored.

## WARNING

Warning is used to indicate the presence of a hazard that *can* cause severe personal injury, death, or substantial property damage if the warning is ignored.

## CAUTION

Caution is used to indicate the presence of a hazard that *will* or *can* cause *minor* personal injury or property damage if the warning is ignored.

### NOTE

Note is used to notify people of installation, operation, or maintenance information that is important but not hazard-related.

## HAZARDOUS VOLTAGE/ ELECTRICAL SHOCK

### DANGER



**Hazardous voltage.**  
**Will cause severe injury or death.**

Disconnect power sources before servicing.  
Barrier must be installed after adjustments, maintenance, or servicing.

### NOTE

**HARDWARE DAMAGE!** Transfer switch may make use of both American standard and metric hardware. Be sure to use the correct size tools to prevent rounding of bolt heads and nuts.

### NOTE

**When replacing hardware, do not substitute with inferior grade hardware.** Screws and nuts are available in different hardness ratings. American Standard hardware uses a series of markings and metric hardware uses a numeric system to indicate hardness. Check markings on bolt head and nuts for proper identification.

## HEAVY EQUIPMENT

### WARNING



**Unbalanced weight.**  
**Improper lift can cause severe injury, death, or equipment damage.**

Use adequate lifting capacity.  
Never leave automatic transfer switch standing upright unless it is securely bolted in place or properly stabilized.

# Glossary of Abbreviations

Abbreviations are used throughout this manual. Normally in the text they will appear in complete form with the abbreviation following in parenthesis the first time they are used. After that they will appear in the abbreviated form. The commonly used abbreviations are shown below.

<b>Abbreviation</b>	<b>Description</b>	<b>Abbreviation</b>	<b>Description</b>
AC	alternating current	e.g.	example given
AHWT	anticipatory high water temp.	EMI	electromagnetic interference
ALOP	anticipatory low oil pressure	etc.	etcetera, (and so forth)
AM	amplitude modulation	ext.	external
Amp.	ampere	°F	Fahrenheit degree
Amps.	amperes	fl. oz.	fluid ounce, fluid ounces
ANSI	American National Standard Institute	FM	frequency modulation
API	American Petroleum Institute	fs	full scale
approx.	approximate, approximately	ft.	foot, feet
A/R	as required, as requested	ft. lbs.	foot pound, foot pounds
A/S	as supplied, as stated, as suggested	ga.	gauge
ASA	American Standards Association	gal., gals.	gallon, gallons
assy.	assembly	gal./hr.	gallons per hour
ASTM	American Society for Testing Materials	gph	gallons per hour
ATDC	after top dead center	gpm	gallons per minute
ATS	automatic transfer switch	gr.	grade
aux.	auxiliary	grd.	ground
AWG	American Wire Gauge	HCHT	high cylinder head temperature
AWM	appliance wiring material	HET	high exhaust temperature
bhp	brake horsepower	Hg	mercury (element)
bmep	brake mean effective power	H <sub>2</sub> O	water
Btu	British thermal unit	hp	horsepower
°C	Celsius degree	hr, hrs	hour
cc	cubic centimeter	HWT	high water temperature
CCA	cold cranking Amps.	Hz	hertz (cycles per second)
CEC	Canadian Electrical Code	ID	inside diameter
cfh	cubic feet per hour	in.	inch(es)
cfm	cubic feet per minute	inc.	incorporated
CID	cubic inch displacement	in. lbs.	inch pounds
cm	centimeter, centimeters	int.	internal
cmm	cubic meters per minute	int.-ext.	internal-external
co.	company	ISO	International Standards Organization
cont'd.	continued	J	joule, joules
C.S.A.	Canadian Standards Association	JIS	Japanese Industry Standard
cu. in.	cubic inch, cubic inches	kg	kilogram, kilograms
cyl.	cylinder	kg/cm <sup>2</sup>	kilograms per square centimeter
dBA	decibels	kgm	kilogram meter(s)
DC	direct current	km	kilometer, kilometers
DCR	direct current resistance	kPa	kiloPascal, kiloPascals
deg.	degree	kph	kilometers per hour
dept.	department	kV	kilovolt
dia.	diameter	kVA	kilovolt amperes

<b>Abbreviation</b>	<b>Description</b>
kW	kilowatt, kilowatts
kWH	kilowatt hour
L	liter, liters
LxWxH	length x width x height
LED, LEDs	light emitting diode
lb., lbs.	pound, pounds
L/hr.	liter per hour, liters per hour
L/min.	liter(s) per minutes
LOP	low oil pressure
LP	liquefied petroleum
LWT	low water temperature
m	meter, meters
m <sup>3</sup>	cubic meter, cubic meters
max.	maximum
MCM	one thousand circular mils.
mi.	mile, miles
mil	one one-thousandth of an inch
min.	minimum
mJ	millijoule, millijoules
MJ	mega joule, mega joules
mm	millimeter, millimeters
m <sup>3</sup> /min	cubic meters per minute
MPa	megaPascal
mph	miles per hour
MS	military standard
mW	milliwatt, milliwatts
MW	megawatt, megawatts
N/A	not available
NEC	National Electrical Code
NEMA	National Electrical Manufacturers Association
NFPA	National Fire Protection Association
Nm	Newton meter, Newton meters
no., nos.	number, numbers
NPT	National Standard taper pipe thread per general use

<b>Abbreviation</b>	<b>Description</b>
N/R	not required
OC	overcrank
OD	outside diameter
OEM	original equipment manufacturer
OS	overspeed, oversize
OV	overvoltage
oz.	ounce, ounces
PF	power factor
pot.	potentiometer
ppm	parts per million
psi	pounds per square inch
pt., pts.	pint, pints
qt., qts.	quart, quarts
qty.	quantity
ref.	reference
RFI	radio frequency interference
rms	root mean square
rpm	revolutions per inch
SAE	Society of Automotive Engineers
sec.	second, seconds
SCR	silicon controlled rectifier
spec, specs	specification
sq.	square
sq. cm	square centimeters
sq. in.	square inch, square inches
tach	tachometer
TDC	top dead center
temp.	temperature
TIF	telephone influence factor
turbo	turbocharger
UNC	Unified coarse thread (was NC)
UNF	Unified fine thread (was NF)
UL	Underwriter's Laboratories, Inc.
US	undersize
V	volt, volts
VAC	Volts alternating current
VDC	volts direct current
W	watt, watts

# Notes

# Section 1. Introduction

## Scope and Purpose of Manual

### Purpose of Manual

This manual provides operation and initial installation instructions for Kohler automatic transfer switches that use 25-400 ampere contactors as the power switching device. Read through this manual and carefully follow all procedures and safety precautions to ensure safe, reliable operation of the automatic transfer switch. Be sure to keep a copy of this manual with the automatic transfer switch for future reference.

### List of Related Manuals

The group of power switching devices covered by this manual are part of a family of related units. Separate operation and installation manuals are available for each group within the overall family. Be sure this manual is the correct manual for this automatic transfer switch.

A controller is included in each automatic transfer switch. There are three types of controllers and each type of controller is covered in a separate operation and installation manual. To be complete, this power switching device manual must be accompanied by a copy of the operation and installation manual for the controller used in the automatic transfer switch. Available controllers and the related manual numbers are as follows:

Controller, E33+	TP-5662
Controller, S340+ (Solid State)	TP-5663
Controller, M340+ (Microprocessor)	TP-5664

### Arrangement of Manual

Information in this manual is arranged in six sections as follows:

**D Section 1. Introduction**, defines the scope and purpose of this manual and lists related manuals as well as manuals for related automatic transfer switches. In addition, the introduction includes a description of an automatic transfer switch to

familiarize the reader with the components that make up the switch.

**D Section 2. Specifications**, lists the important characteristics including electrical ratings of the automatic transfer switches covered by this manual.

**D Section 3. Installation**, provides installation information, including mechanical mounting considerations and electrical wiring data.

**D Section 4. Operation**, provides information about controls and indicators and describes operation, both automatic and manual, of the automatic transfer switch.

**D Section 5. Accessories**, provides information about accessories available for the automatic transfer switches.

**D Section 6. Drawings and Diagrams**, includes wiring diagrams and drawings for the automatic transfer switches covered by this manual.

## Automatic Transfer Switch Description

### Purpose of Switch



An automatic transfer switch is a switching device that automatically transfers critical electrical loads from a normal (preferred) power source to an emergency (standby) power source. The automatic transfer occurs when normal power fails or is substantially reduced. An automatic transfer switch also transfers the load back from emergency power to the normal power source when normal power is restored.

### Components of Switch

A typical automatic transfer switch (Figure 1) includes the actual power switching device and the logic controller to perform power monitoring and transfer sequencing tasks. An interface is also included to match the standard controller inputs/outputs to the levels required by a specific switching device.

The power switching device used in the models covered by this manual is made of two multi-pole line contactors. These contactors are mechanically and electrically interlocked together to avoid conditions where both contactors are closed at the same time. With this feature, it is possible to select one power source to feed the load without crosscoupling that power source to the other power source.

The three functional units that make up the automatic transfer switch are mounted in an enclosure with a hinged front door. The controller mounts on the back of the front door so its controls and indicators are available to an operator. A signal cable, with in-line connectors to facilitate component replacement and door removal, connects the controller to the interface board and the switching devices.



- 1. Normal Power Contactor
- 2. Mounting Flange
- 3. Standby Power Contactor

- 4. Interface Panel
- 5. Logic Controller

**Figure 1. Transfer Switch Components**

## Sequence of Operation

Operation of the typical automatic transfer switch (Figure 2) is divided into two separate sequences: (1) failure of normal power and the resulting transfer to emergency power and (2) restoration of normal power and the resulting transfer back to normal power. A brief description of both sequences is provided below. Note that these sequences may be affected by accessories described in Section 5 of this manual or in the applicable logic controller operation and installation manual. In addition, for more specific details on circuit operation including time delays, refer to the applicable controller operation and installation manual. (See **List of Related Manuals** earlier in this Section.)

**D Failure of Normal Power**, either loss or deterioration of one or more phases, is detected by monitors within the controller. The monitor that detects the failure starts a time delay, typically called Time Delay Engine Start. If power is restored before the time delay expires, the timer is reset. But, if the failure persists and the time delay expires, the controller issues a signal to start the standby (emergency) power generator. This time delay scheme is used to prevent unnecessary starting of the generator during short power interruptions.

A second set of monitors within the controller check the status of the emergency power. When the voltage and frequency of the emergency (generator) power is good, these monitors start a

timing cycle, typically called Time Delay Normal to Emergency. At the end of the timing cycle, which is provided to allow the generator outputs to stabilize, the controller issues a signal to the transfer switch to remove normal power to the load and then connect emergency power to the load.

Once it is switched, the transfer switch remains in the emergency position, supplying power to the load from the emergency source until normal power is restored.

**D Restoration of Normal Power** automatically begins a sequence that transfers the load back to the normal power source. The monitors within the controller continue to check the status of the normal power, even when the load is operating from emergency power. When these monitors detect a stable condition of the normal power, a time delay typically called Time Delay Emergency to Normal is started. If the normal power fails again before the time delay expires, the time delay is reset. This timing period is included to ensure that the normal power is stabilized before it is reconnected to the load.

If the normal power remains good and the time delay expires, the controller issues a signal to the transfer switch to remove emergency power and reconnect normal power to the load. Normally, at the same time as the power transfer, the logic starts a timer, typically called Time Delay Engine Cooldown. After this time delay expires, the generator engine is stopped.




Figure 2. Transfer Switch Block Diagram

# Notes

# Section 2. Specifications

## Ratings

A nameplate (Figure 3) is attached to the automatic transfer switch enclosure. The nameplate label includes a Kohler part number coded to provide characteristic and rating information that affects installation and operation. Copy the part number into the blank boxes provided in Figure 4 and then use the tables in Figure 4 to interpret the correct part number.

### NOTE

Also copy the part number and serial number from the nameplate into the spaces provided on the inside front cover of this manual for use when requesting service or parts.





Figure 3. Transfer Switch Nameplate

Record the transfer switch part number in the boxes below. The transfer switch part number defines characteristics and ratings as explained in the accompanying chart.



**Kohler Part Number Key**

This chart explains the Kohler Transfer Switch part numbering code system. The sample part number shown is for a standard mechanically held contactor power switch with S340+ Logic rated at 600 Volts, 60 Hertz, 3-phase, 3-pole, and 4 wires in a NEMA 1 enclosure with an amperage rating of 80 amperes.

**SAMPLE PART NUMBER**

**TLS-160341-0080**

**Classification of Power Switch**

T: Electrically & Mechanically Held

**Type of Power Switch**

E: Electrically Held Contactor  
L: Mechanically Held Contactor

**Type of Switch**

S: Standard

**Type of Logic**

- 1: S340+
- 2: E33+
- 3: S340+ with Program Transition
- 4: E33 with Program Transition
- 5: M340+
- 6: M340+ with Program Transition

**Voltage Code**

- 60: 600 Volt, 60 Hz
- 62: 120 Volt, 60 Hz
- 63: 220 Volt, 50 Hz
- 64: 240 Volt, 60 Hz
- 66: 480 Volt, 60 Hz
- 68: 208 Volt, 60 Hz
- 71: 380 Volt, 50/60 Hz

**Number of Poles**

- 3: 3 Pole, 3 Phase
- 6: 4 Pole-Fully Rated Poles (No Overlapping Neutral)

**Number of Wires**

- 3: 3 Wire
- 4: 4 Wire

**Enclosure**

NEMA Type 1

**Amperes**

Numbers Indicate Ampere Rating of Switch

**Figure 4. Transfer Switch Model Designations**

# Specifications

Specifications for automatic transfer switches covered by this manual are listed below:

- D Provided as a complete automatic transfer switch with E33+, S340+ (solid state logic) or M340+ (microprocessor logic) controller in a NEMA Type 1 enclosure
- D Meets IEC standards
- D Can be turned off manually

- D Three pole and four pole models
- D Four pole fully rated (no overlapping neutral)
- D Program Transition function available
- D Switch amperage ratings from 25-400 amperes
- D Rated operational voltage of contactors of 1000 VAC
- D Contactor characteristics summarized in Figure 5 and Figure 6

Transfer Switch Rating (Amperes) AC-1 + AC-3 D		Rated Insulation Voltage UL/CSA	Making Capacity amps*	Breaking Capacity amps*				Short Term Current Rating* From cold (no current flow for 15mn at temp of 40° C/104° F)						
				220-380 -415 -440V	500V	660V	1000V	For 1s	For 5s	For 10s	For 30s	For 1mn	For 3mn	For 10mn
40	25	600	450	450	400	180	¾	380	290	240	155	120	80	50
50	32	600	550	550	450	180	¾	430	340	260	175	138	92	60
80	65	600	1000	1000	1000	630	¾	900	660	520	340	260	175	110
110	80	600	1100	1100	1000	640	¾	990	800	640	420	320	210	135
200	145	1000	1300	1300	1100	900	400	1100	1100	1100	640	520	400	320
270	180	1000	2100	1800	1600	1200	600	1500	1500	1500	920	740	500	400
350	245	1000	2450	2450	2200	1750	800	2200	2200	2200	1230	950	620	480
500	400	1000	4500	4000	3500	3000	1200	3600	3600	3600	2400	1700	1200	1000

\*Per IEC 158-1 for transfer switches with rating of 25–80 amperes; per IEC 947-2 for transfer switches with rating of 145–400 amperes.

All transfer switches listed in this table have a dry air operating temperature range of –5 to +55° C (+23 to +131° F).

+ IEC AC-1 Ratings apply to all types of AC loads with a power factor of .095 or greater.

D IEC AC-3 Ratings apply to squirrel cage motor loads or other loads generating inrush currents of 5 to 7 times full load.

**Figure 5. Characteristic Summary of Electrically- and Mechanically-Held Contactors**

Transfer Switch Rating (Amperes) AC-1 + AC-3 D		Rated Insulation Voltage UL/CSA	Making Capacity amps*	Breaking Capacity amps*				Short Term Current Rating* From cold (no current flow for 15mn at temp of 40° C/104° F)						
				220-380 -415 -440V	500V	660V	1000V	For 1s	For 5s	For 10s	For 30s	For 1mn	For 3mn	For 10mn
200	145	1000	1500	1500	1200	1000	450	1200	1200	1200	700	600	450	350
270	180	1000	1800	1800	1600	1150	600	1500	1500	1500	920	740	500	400
350	245	1000	2450	2450	2200	1750	800	2200	2200	2200	1230	950	620	480
500	400	1000	4000	4000	3500	3000	1200	3600	3600	3600	2400	1700	1200	1000
*Per IEC 158-1														
All transfer switches included in this table have a dry air operating temperature range of -15 to +70° C (+5 to +158° F).														
+ IEC AC-1 Ratings apply to all types of AC loads with a power factor of .095 or greater.														
D IEC AC-3 Ratings apply to squirrel cage motor loads or other loads generating inrush currents of 5 to 7 times full load.														

**Figure 6. Characteristic Summary of Magnetically-Held Contactors**

# Section 3. Installation

Kohler automatic transfer switches are shipped factory wired and tested, ready for installation. The actual installation process consists of mechanically mounting and electrically wiring the unit to the normal and emergency power sources, the load circuits, and the generator.

## Upon Receipt of Unit

### Inspection

Carefully unpack or uncrate the automatic transfer switch and check for shipping damage. If damage is discovered, file damage claims with the shipping company immediately and also notify the distributor/dealer.

### Storage

Do not remove the protective packing until ready for final installation. Protect the automatic transfer switch at all times from excessive moisture, construction grit, and metal chips. Avoid storage in low-temperature, high-humidity areas where moisture could condense on the unit.


## Mechanical Installation

To plan the installation, use the dimensions given on the enclosure drawings in Section 6. Select the mounting site to match local electrical code restrictions for the enclosure type. Mount the automatic transfer switch as near the load and power sources as possible. Also be sure to allow adequate space for switch servicing and full opening of the enclosure door.

### Lifting

The approximate weight of each automatic transfer switch covered by this manual is given in Figure 7. For

lifting, use a spreader bar. Attach the bar only to the enclosure's mounting holes or lifting eyes; do not lift the unit at any other points. Ensure the front door is in place and latched closed when moving or mounting the unit.

<b>⚠ WARNING</b>

<p><b>Unbalanced weight.</b> <b>Improper lift can cause severe injury, death, or equipment damage.</b></p> <p>Use adequate lifting capacity. Never leave automatic transfer switch standing upright unless it is securely bolted in place or properly stabilized.</p>



### Mounting

The automatic transfer switches covered by this manual must be mounted vertically to a rigid supporting structure such as a wall. Key hole slots for mounting purposes are provided in the mounting brackets on the top and bottom of each unit. When mounting the unit, plumb the enclosure to ensure that the door hinges are vertical to avoid any distortion of the enclosure or door. Place washers behind the mounting bracket key holes to shim the enclosure to a plumb condition.

Transfer Switch Rating Value Amperes	Approximate Weight lb (kg)
25-180	233 (106)
245 or 400	305 (139)

**Figure 7. Automatic Transfer Switch Weight**

# Electrical Wiring



<p><b>Hazardous voltage.</b>  <b>Will cause severe injury or death.</b></p> <p>Disconnect power sources before servicing.          Barrier must be installed after adjustments, maintenance, or servicing.</p>

**NOTE**

For easy access during installation wiring, the front door of the enclosure can be removed. Simply disconnect the cable plug that connects the front door components to the internal components and then lift the door off its hinge pins.

## Power Connections

All conductors should enter the enclosure at recommended locations as shown on the enclosure

dimension drawing in Section 6. When drilling entry holes for any conductors, cover the transfer switch components for protection from metal chips and construction grit. Remove any debris from the enclosure with a vacuum cleaner (*using compressed air for this purpose can lodge contaminants in components and cause damage*).

Connection points for the normal power, emergency power, and load are clearly marked on contactor assembly and are also shown on the enclosure dimension drawing in Section 6. Be sure to heed the phase markings (A, B, C, and N).

**NOTE**

Connect source and load phases as indicated by the markings and drawings. Improper connections may cause short circuits and can cause phase-sensitive load devices to run in reverse or prevent load devices from functioning.

Remove surface oxides from conductors by cleaning with a wire brush. When aluminum conductors are used, apply oxidation inhibitor to the conductors. Tighten lugs and carefully wipe away excess oxidation inhibitor. Lugs must be tightened to torque listed in Figure 8.

Transfer Switch Rating (Amperes)	Number of Cables	Lug Size (AWG)	Torque Value (in lb)	Lug Size (mm <sup>2</sup> )	Torque Value (Nm)
25	1	18-8	15	1.5-8.4	1.7
	2	18-6		1.5-10	
32	1	14-6	20	2.5-10	2.3
	2	14-6		2.5-10	
65	1	10-3	35	4-25	4
	2	10-3		4-25	
80	1	10-2	75	4-35	8.5
	2	10-2		4-35	
145/150	1	6-3/0	200	10-95	22.6
180/185	1	6-3/0	200	10-95	22.6
245/265	1	6-300 MCM	275	10-150	31
400	1	4-600 MCM	500	16-304	56

**Figure 8. Lug Sizes and Tightening Torque Values for Power Connections**

## Start Generator Connections

The generator start signal connections are located on a terminal block on the transfer switch contactor. The location of terminal block is marked by a red decal within the enclosure. Connect the generator conductors for the start signal to terminals 3 and 4 as shown in the interconnection diagrams provided in Section 6 of this manual.

## Other Accessory Connections

Any external connections necessary for accessories are described in the applicable controller manual. (See **List of Related Manuals** in Section 1 of this manual.)

# Notes

# Section 4. Operation

## Switches and Indicators



The switches and indicators on the automatic transfer switch are determined by the controller used in that switch. For details on this subject, refer to the appropriate controller operation and installation manual. (See **List of Related Manuals** in Section 1.)

## Automatic Operation

Automatic operation is a function of the controller installed in the unit. For all details and procedures for both initialization and automatic operation, refer to the appropriate controller operation and installation manual. (See **List of Related Manuals** in Section 1.)

## Manual Operation


Manual operation of the transfer switch, which is limited to opening of the contactors, is of use when the controller fails or when testing/troubleshooting the unit. However, those transfer switches that are electrically held are not capable of manual operation. To open contactors of a mechanically or magnetically held switch, proceed as follows:

 <b>DANGER</b>

<b>Hazardous voltage.</b> <b>Will cause severe injury or death.</b>  Disconnect power sources before servicing. Barrier must be installed after adjustments, maintenance, or servicing.

1. Turn off both power sources.
2. Open enclosure door of automatic transfer switch.
3. For a mechanically held switch, press orange button on switch cover to open contactors. (See Figure 9). For a magnetically held switch, operate lever on side of switch to open contactors. (See Figure 10.)
4. Close enclosure door.

### NOTE

The logic controller may cause the switch to operate and close the contactors again when the power source(s) is (are) restored.




1. Normal Contactor

2. Standby (Emergency) Contactor

3. Orange Button

**Figure 9. Mechanically-Held Automatic Transfer Switch Operation**



- 1. Normal Contactor
- 2. Standby (Emergency) Contactor

3. Lever

**Figure 10. Magnetically-Held Automatic Transfer Switch Operation**

# Notes

# Section 5. Accessories

## Program Transition

### NOTE

For ATS utilizing the M340+ logic control, the program transition function is accomplished within the microprocessor and therefore no timing relays are required. See TP-5664 for operational details. DO NOT use this section.



### Description

The Program Transition accessory consists of two timing relays that plug into the interface board. (See Figure 11.) If these relays are present, power transfers from normal to emergency or emergency to normal power sources occur in three steps: (1) the switch for the previously connected power source opens, (2) there is a delay period, adjustable from 2 to 40 seconds, to allow residual voltage in the load circuit to decay, and (3) the switch for the new power source is closed.

### Adjustment


Two separate timing relays are used. One relay, K4 (TDOE), produces the time delay for the normal to emergency power transfer. The other relay, K3 (TDON), produces the time delay for the emergency to normal power transfer. Each relay has a separate adjustment. To make the adjustment, proceed as follows:

1. Disconnect or turn off both the normal and emergency power sources.

 <b>DANGER</b>

<b>Hazardous voltage.</b> <b>Will cause severe injury or death.</b>
Disconnect power sources before servicing. Barrier must be installed after adjustments, maintenance, or servicing.

2. Open enclosure door of automatic transfer switch.
3. Locate the appropriate relay on the interface board. (See Figure 11.)

4. Insert a screwdriver into the adjustment slot of the adjustment screw, visible through the cover of the relay, and turn the adjustment screw to the desired time delay period.
5. Close the enclosure door.
6. Reconnect or turn on the applicable (normal or emergency) power source.
7. Operate the automatic transfer switch automatically and check the time delay period to ensure that it is properly adjusted.



1. K3 (TDON)

2. K4 (TDOE)

**Figure 11. Interface Board with Timing Relays**

## Other Accessories


All other accessories for this automatic transfer switch are controller accessories. For controller accessory information and procedures, refer to the appropriate controller operation and installation manual. (See **List of Related Manuals** in Section 1.)

# Notes

# Section 6. Diagrams & Drawings

Diagram or Drawing	Drawing Number	Page
<b>Enclosure Dimensions</b>		
Enclosure Dimensions, 25-180-Amp.	ADV-5909	6-3
Enclosure Dimensions, 245-400 Amp.	ADV-5911	6-4
<b>Schematic Diagrams</b>		
E33+ Logic Without Program Transition		
25-80 Amp. mechanically held contactor	321150	6-5
145-400 Amp. mechanically held contactor	321152	6-6
25-400 Amp. electricially held contactor	321153	6-7
E33+ Logic With Program Transition		
25-80 Amp. mechanically held contactor	321151	6-8
145-400 Amp. mechanically held contactor	321234	6-9
25-400 Amp. electricially held contactor	321235	6-10
S340+ Logic Without Program Transition		
25-80 Amp. mechanically held contactor	321094	6-11
145-400 Amp. mechanically held contactor	321238	6-12
25-400 Amp. electricially held contactor	321237	6-13
S340+ Logic With Program Transition		
25-80 Amp. mechanically held contactor	321093	6-14
145-400 Amp. mechanically held contactor	321034	6-15
25-400 Amp. electricially held contactor	321035	6-16




# Notes



AMPERE	CABLE LUG SIZES PER PHASE A,B,C,N WHEN PRESENT	
	SIZE (USA)	SIZE (METRIC) NOTE (1)
25	1 CABLE 18-8 AWG 2 CABLE 18-6 AWG	1 CABLE 1.5-10 MM <sup>2</sup> 2 CABLE 1.5-6 MM <sup>2</sup>
32	1 CABLE 14-6 AWG 2 CABLE 14-6 AWG	1 CABLE 2.5-10 MM <sup>2</sup> 2 CABLE 2.5-10 MM <sup>2</sup>
65	1 CABLE 10-3 AWG 2 CABLE 10-3 AWG	1 CABLE 2.5-25 MM <sup>2</sup> 2 CABLE 2.5-16 MM <sup>2</sup>
80	1 CABLE 10-2 AWG 2 CABLE 10-2 AWG	1 CABLE 4-50 MM <sup>2</sup> 2 CABLE 4-35 MM <sup>2</sup>
145/150	1 CABLE 6-3/0	1 CABLE 10-70 MM <sup>2</sup>
180/185	1 CABLE 6-3/0	1 CABLE 10-70 MM <sup>2</sup>

NOTES:  
 1. FLEXIBLE WITHOUT CABLE ENDS.  
 2. DIMENSIONS IN [ ] ARE MILLIMETERS.

Figure 12. NEMA Type 1 Enclosure, 25-180 Amp.



NOTES:  
1. FLEXIBLE WITHOUT CABLE ENDS.  
2. DIMENSIONS IN [ ] ARE MILLIMETERS.

AMPERE	CABLE LUG SIZE PER PHASE A,B,C,N WHEN PRESENT	
	SIZE (USA)	SIZE (METRIC) NOTE (1)
245/265	1 CABLE 6-300 MCM	1 CABLE 10-150 MM <sup>2</sup>
400	1 CABLE 4-600 MCM	1 CABLE 16-300 MM <sup>2</sup>

NEMA 1 ENCLOSURE  
TL() & TE() 245A-400A (IEC RATING)

ADV-5911

Figure 13. NEMA Type 1 Enclosure, 245-400 Amp.






Figure 14. E33+ Logic, 25-80 Amps., Mechanically Held Contactor Without Program Transition



321152-

Figure 15. E33+ Logic, 145-800 Amp., Mechanically Held Contactor Without Program Transition



321153-

Figure 16. E33+ Logic, Electrically Held Contactor Without Program Transition




Figure 17. E33+ Logic, Electrically Held Contactor With Program Transition






Figure 18. E33+ Logic, 25-80 Amp. Mechanically Held Contactor With Program Transition



321235-

Figure 19. E33+ Logic, 145-400 Amp. Mechanically Held Contactor With Program Transition



321094-

Figure 20. S340+ Logic, Electrically Held Contactor Without Program Transition




Figure 21. S340+ Logic, 25-80 Amp. Mechanically Held Contactor Without Program Transition






Figure 22. S340+ Logic, 145-400 Amp Mechanically Held Contactor Without Program Transition




321093-

Figure 23. S340+ Logic, Electrically Held Contactor With Program Transition



321034-

Figure 24. S340+ Logic, 25-80 Amp. Mechanically Held Contactor With Program Transition



321035-

Figure 25. S340+ Logic, 145-400 Amp. Mechanically Held Contactor With Program Transition

**TP-5659 11/93a**

E Kohler Co., 1993. All rights reserved.

# **KOHLER**<sup>®</sup> POWER SYSTEMS

KOHLER CO. Kohler, Wisconsin 53044  
Phone 920-565-3381, Web site [www.kohlergenerators.com](http://www.kohlergenerators.com)  
Fax 920-459-1646 (U.S.A. Sales), Fax 920-459-1614 (International)  
For the nearest sales and service outlet in U.S.A. and Canada  
Phone 1-800-544-2444

Kohler Power Systems  
Asia Pacific Headquarters  
7 Jurong Pier Road  
Singapore 619159  
Phone (65)264-6422, Fax (65)264-6455