


LOAD BANK TECHNICAL MANUAL

MODEL: NEPTUNE 120
120KW, 480V, 3P, 60HZ
PARTS # : 72086



SIMPLX[®]

LOAD BANKS & FUEL SUPPLY SYSTEMS

Simplex Inc., 1139 N. MacArthur Blvd., Springfield, IL 62702
217-525-6995 (24 hr.) • Fax: 217-525-7984
E-Mail: Simplex@fgi.net



LOAD BANK TECHNICAL MANUAL

Customer: Katolight Corp.

Work Order: 35973-99-43

Model: Neptune 120

November 1999

The information herein is the property of Simplex, Inc. and/or its subsidiaries.
Without written permission, any copying, transmitting to others, and other use
except that for which it is loaned, is prohibited.
(File: Lbsman6p .p65: Disk: SDCX149)

LOAD BANK SPECIFICATIONS SHEET

November 1999

Customer: Katolight Corp.

Work Order: 35973-99-43

Model: Neptune 120

Capacity:	120KW @ 1 PF		
Voltage:	480VAC		
Connection:	3 Phase, 3 Wire		
Frequency:	60Hz		
Cooling:	Forced Air		
Fan/Control Power:	Internal 480VAC / Internal 480:120V Transformer		
Max. Intake Air Temp.:	120°F	Max. Exhaust Air Temp.:	

Applicable Drawing Numbers and Special Notes:

Control Section	47B100384A
Load Section	47B100385
Load Strapping	47B100386
Element/Reactor Layout	47BD100480
Anti-Condensation	47B100481
Parts Legend	47B100482
Subpanel Layout	47BD100483
Remote Control Box	47BD100484
Nameplates	47BD100485
Pictorial	7BD86832

Contents

DESCRIPTION	2
Control System	4
Cooling System	5
Load System	6
PRIMARY INSPECTION	7
INSTALLATION	8
Location	8
Procedure	9
OPERATION	9
Manual	10
Automatic	10
Load Dump	12
Shutdown	12
FAILURE DETECTION	12
Thermocouple Temperature Switch	13
REMOTE/AUXILIARY OPERATION	13
MAINTENANCE	14
Each Operation	14
Every 50 Hours or 6 Months	15
Motor Lubrication	15
TROUBLESHOOTING	16
Cooling Fan Motor Will Not Operate	16
Cooling Failure Indicated	16
Test Meters Do Not Operate Properly	16
Some Load Steps Cannot Be Energized	16
DRAWINGS AND PARTS LIST	17
APPENDIX A - ABBREVIATIONS USED IN THIS MANUAL	18
APPENDIX B - CALCULATIONS & FORMULAS	19

DESCRIPTION

Simplex Planet Series Load Banks are precision test instruments specifically designed to apply discrete, selectable electrical load to a power source while measuring the response of the generator to the applied load. They also provides a means for routine maintenance exercise to assure long term reliability and readiness of the standby generator. Exercise Load Banks eliminate the detrimental effects of unloaded operation of diesel engine generators.


Planet Series Load Banks are available in various cabinet designs and capacities. Standard cabinets are rated as NEMA Type 3R outdoor weatherproof but are also available as NEMA Type 1 indoor. If desired, the Load Bank can be mounted on a trailer.

Power source testing is accomplished by applying resistive load steps at unity (1.0) power factor. *See the Load Bank Specifications Sheet in the front of this manual for the rating of your Load Bank.*



The photographs in this manual are examples only and may differ from your Load Bank.

Load application is by magnetic contactor. All load branch circuits are protected by 200,000AIC class-T fuses.

Operating controls are located on Local and Remote Control Panels. The Control Panels contain printed circuit boards with 24VDC components. DC control power is supplied to the printed circuit boards by a 24VDC power supply located in the Load Bank. Common serviceable components include Control Fuses (CF1-CF2) and Power Supply Fuse (FU1). Lamps on the control panels indicate the Load Bank operating status. Control priority is determined by the "Load Bank Mode" selector switch: Off, Local-Manual, Local-Auto, Remote.




LOAD BANK	CAPACITY
Ceres (LBS-A)	5-60KW
Comet (LBS-B)	70-200KW
Mercury	5-400KW
Triton	150-400KW
Trident	450-750KW
Neptune	250-650KW
Mars	700-1400KW
Saturn	1500-3000KW



The Local Control Panel contains the following controls and indicator lamps:

1. Load Step switches and lamps,
2. Master Load switch and lamp,
3. Push to Run pushbutton,
4. Push to Stop pushbutton,
5. Power Available lamp,
6. Mode Selector switch,
 - a. Local/Manual Run lamp,
 - b. Local/Auto Run lamp,
 - c. Remote Mode lamp,
 - d. Remote Load Dump lamp,
7. Press to Test pushbutton,
8. Load Dump Bypass switch and lamp,
9. Normal Operation lamp, and
10. Cooling Failure lamp.




References to Remote Control in this manual should be ignored if the Load Bank you are using is equipped with a Local Control Panel only.

References to Automatic Operation in this manual should be ignored if the Load Bank you are using is equipped with Manual Load Step Application only.

The "Power Available" lamp illuminates when the Load Bus is energized and Control Power is supplied to the system. The "Normal Operation" lamp illuminates when Control Power is available and the Cooling System is operating properly.

This Load Bank is protected against cooling failures (loss of cooling air flow, high intake or exhaust air temperature which could damage the Load Bank or present a safety hazard to the operator). When a cooling failure occurs the automatic safety features in the Control System immediately remove the load from the load source. The malfunction

must be corrected and the Load Bank must be reset by pressing the "Push to Stop" pushbutton and then pressing the "Push to Run" pushbutton before the load can be re-applied.



The Load Bank consists of three principal systems:


1. Control System
2. Cooling System
3. Load System

CONTROL SYSTEM


The Control System allows the operator to apply a desired load to the test source and measure the response of the test source to the load. This system also contains the circuitry utilized to disconnect the Load Bank from the test source in the event of cooling failures and/or improperly positioned operating controls. The Load Bank Control System components are located on the Local Main Logic Control Panel (CP1) printed circuit board.

Control power (120V) is supplied to the input of the 24VDC power supply (DCS) by one of the following methods:

1. control power transformer
2. line to neutral from the test source
3. external source



Control Section Interior

**Resistive Load Bank**


The 24VDC output of DCS is applied to the Local and Remote Main Logic Control panel circuit boards. 120V control power is applied to the coil of the Fan Motor Contactor (FMC) through terminal TB'A' 17 of the Main Logic Control Panel printed circuit board. Fan power is applied to the Fan Motor (MOT) through the Fan Circuit Breaker (FCB) and the Fan Motor Contactor (FMC) contacts.


In Auto Mode only, the FMC and the MOT remain de-energized until the "Push to Run" pushbutton is depressed or the run contacts close.

COOLING SYSTEM

Resistive Load Elements are cooled by a forced air system consisting of an aluminum fan blade directly driven or belt driven by a TEFC motor, turning at approximately 1750 RPM at 60Hz (1488RPM at 50Hz). The fan motor is energized by a 600V, 3 pole contactor and protected by a three pole, 100A frame circuit breaker.

Reactive Load Elements (inductive or capacitive) are convection cooled or cooled by a forced air system. The forced air system consists of 12" fan shutter assemblies. The fans turn approximately 1550 RPM at 60Hz.

**Reactive Load Bank**



Resistive Load Elements



Fuses

LOAD SYSTEM

The Load System consists of independently controlled resistive and/or reactive load elements specifically designed for Load Bank systems. They are protected by 200,000AIC, 600VAC fuses.

Simplex Resistive Load Elements conservatively operate at approximately half the maximum temperature rating of the alloy (1080°F vs. 1920°F). For example:


Alloy: FeCrAl

Ratings: 3333W@120V
4170W@139V

Connections: 120V wye (208V),
139V wye (240V, 3 ϕ),
277V wye (480V, 3 ϕ),
240 delta (240V, 3 ϕ), or
480 delta (480V, 3 ϕ).

See Parts Legend Drawing for specific elements used.

These elements are rigidly supported by high-temperature, ceramic-clad, stainless-steel supports. Element-to-element short circuits are virtually eliminated. The elements are assembled in discrete trays which are assembled in a vertical "stack". Each tray is independently serviceable without disturbing adjacent trays.




Reactive Load Elements

Reactive Load Elements are iron-core, non-saturable, air gap calibrated and air cooled. Standard elements have a temperature sensor embedded in the windings to detect element overheating and are varnish coated. Epoxy coatings are available for severe environments.


PRIMARY INSPECTION

Preventative visual inspections of the shipping crate and Load Bank is advised. Physical or electrical problems due to handling and vibration may occur. Never apply power to a Load Bank before performing this procedure. The following Nine Point/30 Minute Inspection is recommended before installation, as part of the 50 hour / 6 month maintenance schedule and whenever the Load Bank is relocated:

1. If crate shows any signs of damage examine the Load Bank in the corresponding areas for signs of initial problems.
2. Check the entire outside of the cabinet for any visual damage which could cause internal electrical or mechanical problems due to reduced clearance.
3. Inspect all hinged panels and doors for smooth and safe operation, try all latches and knobs.
4. Rotate and push all switches through all positions to ensure smooth operation.
5. Check cooling system by inspecting fan motor and blade. Slowly rotate blade by hand and note clearance of blade tip through its rotation near the housing. Observe free rotation of motor shaft.
6. Inspect all relays, timers, and control modules by opening all accessible panels. Make sure all components are secure in their bases and safety bails are in place. Spot check electrical connections for tightness. If any loose connections are found inspect and tighten all remaining connections.
7. Examine all accessible internal electrical components such as fuses, contactors and transformers. Check lugged wires at these components.



Cooling Fan



Control Section Components

8. Inspect bottom of crate/enclosure for any components that may have jarred loose during shipment such as indicator light lenses, switch knobs, etc.
9. Visually inspect element chamber for foreign objects, broken ceramic insulators, mechanical damage.


If any problems are observed during Primary Inspection call the Simplex Service Manager at 217-525-6995 (24hrs.)

INSTALLATION

LOCATION

Nema-3R Load Banks are intended for outdoor installation. Nema-1 Load Banks must be installed indoors. The load elements in this Load Bank are cooled by a forced air system which discharges through the top, sides or the back of the cabinet. This Load Bank will produce a large quantity of exhaust air. Location of the Load Bank is of prime importance and should be done by trained personnel. It is one of the most critical factors involved in safe operation. The Load Bank must be positioned and installed according to large airflow requirements.

- There must be a minimum clearance of 25 feet on the discharge side and 6 feet on all other sides for horizontal Load Banks. All other Load Banks require a minimum clearance of 6 feet on all sides.
- Load Banks installed indoors must be equipped with an exhaust air duct of minimum back pressure (supplied by others) which routes all Load Bank hot exhaust air outdoors.
- With the exception of the Ceres (LBS-A), the Comet (LBS-B), and Load Banks installed indoors with the proper exhaust duct, never install any structure or object at any height above the Load Bank.
- Always locate the Load Bank in a secure area accessible by trained personnel only.
- Use the eyehooks and forklift channels provided to position the Load Bank.
- Never point the exhaust at a nearby surface or object which may be adversely affected by high temperature.



- Never operate the Load Bank in a confined space without regard for adequate intake of air and provision for exit of high temperature exhaust.
- Consider that the Load Bank and a nearby generator set may have to compete for cooling air.
- Never bounce hot exhaust air off nearby objects and allow it to recirculate through the cooling system.
- Never operate the Load Bank in proximity to a sprinkler system.

WARNING

Damage to the Load Bank due to improper installation is not covered by the Simplex Warranty.


WARNING

Do not store or operate in rain or spray unless unit is designed for this service or adequate protection is provided.

Failure to properly install this Load Bank may result in substantial damage to or the destruction of the Load Bank, adjacent equipment and the building in which the Load Bank is installed.

PROCEDURE

1. Confirm the test source is properly grounded and ground the Load Bank to its own independent ground.
2. Confirm all load command switches are in the "Off" position.
3. Confirm the Fan Circuit Breaker (FCB) is in the "Off" position.
4. Per load connection drawings cable the load source to the Load Bank.
5. Connect customer supplied Load Dump contacts to TB'LD' 1-2 or place the "Load Dump Mode" switch in the "Bypass" position.
6. Place the Fan Circuit Breaker (FCB) in the "On" position.




OPERATION

1. Place the "Load Bank Mode" switch in the "Local Manual", "Local Auto" or "Remote" position.
2. Start-up generator or bring other test source on line.

If External Fan/Control Power is being used, depress the "Push to Run" pushbutton to energize the cooling fan before starting the generator to assure proper fan operation.


3. Adjust power source voltage and frequency.
4. Confirm the illumination of the "Power Available" lamp.
5. Press the "Push to Run" pushbutton to energize the cooling fan.

A false "Cooling Failure" lamp indication will be present until the cooling fan creates sufficient airflow to close the Fan Pressure Switch (PS). The "Normal Operation" lamp illuminates and control voltage is supplied to the "Master Load" switch. With voltage



⚠ WARNING ⚠
Do Not allow the Load Bank to operate unattended for extended periods.

6. Verify the illumination of the "Normal Operation" lamp before proceeding.
7. Visually observe correct fan operation and investigate any unusual fan related noises.
8. Check air intake for obstructions and confirm positive air flow.



MANUAL

9. Select the desired load steps by placing them in the "On" position.
10. Place the "Master Load" switch in the "On" position.

This simultaneously applies all of the load steps which are in the "On" position.

Trim is achieved by flipping the load steps "On" and "Off" while the "Master Load" is in the "On" position.

11. Adjust source voltage and load. Monitor as needed.

WARNING

If a failure occurs the corresponding lamp will illuminate and the load will be de-energized. Before reapplying a load, the failure must be corrected and the system must be reset by turning the Load Bank "Off" then "On".

AUTOMATIC

When the operator places the Load Bank in automatic mode the Current Sensing Relays and Time Delay Relays (CSR and TDR) automatically apply load as needed. These relays are factory set to maintain a minimum net load on the generator equalling the Load Bank rating. Time delay is set at 3 seconds. If necessary, these relays can be field adjusted. The following example illustrates how they function:


Example:

30KW Load Bank with three 10KW load steps

With normal load applied to the generator, equal to the Load Bank rating (30KW), no Load Bank load steps are energized.

Load Step #1 energizes when the normal load drops below 30KW after the time delay interval determined by TDR1.

Load Step #2 energizes when the normal load drops to 20KW after the time delay interval determined by TDR2.




Load Step #3 energizes when the normal load drops to 10KW after the time delay interval determined by TDR3.


On the top of each Current Sensing Relay (CSR) dust cover there is an adjustment knob (3/4 turn potentiometer) with an arbitrary 0.05-1.0 scale. Turn the knob clockwise for a higher current pick-up point and counterclockwise for a lower current pick-up point.

Planet Series Load Banks utilize 60 second and/or 30 second Time Delay Relays (TDR). On the top of each TDR there is an adjustment knob (one turn potentiometer). The 60 second relay is adjustable from 0-60 seconds. The 30 second relay is adjustable from .1 to 30 seconds. Follow the directions on the white stickers for each potentiometer to adjust the set points.

⚠ WARNING ⚠
 If an automatic test is interrupted by a Load Bank failure, do not reset the Load Bank until the source of the failure has been determined.



60 Second TDR



LOAD DUMP

This Load Bank contains a Load Dump feature which de-energizes all applied load when customer supplied contacts open. Normally closed to run, they are rated at 2A @ 24VDC and should be wired to TB'LD' 1-2. When these contacts open all applied load will be de-energized and the load section will be disabled. If desired, the customer may install automatic transfer switch contacts, a manual pushbutton or circuit breaker for this use.

The operator also has the option of bypassing these contacts and enabling the load section by flipping the "Auto Load Dump" switch to the "Bypass" position. This disables the load dump feature and illuminates the "Load Dump Bypass" lamp.

SHUTDOWN

1. De-energize the load.
2. Run the cooling fan for 5 minutes to assure a thorough cool down of all load elements (optional).
3. Place the "Fan/Control Power" switch in the "Off" position or press the "Push to Stop" pushbutton.

! WARNING !


Always remove all power from the load bus and all fan/control power before servicing the Load Bank. Never operate or service a Load Bank that is not properly connected to an earthground.

FAILURE DETECTION

If a "Failure" occurs the corresponding lamp will illuminate and the load will be de-energized. Before reapplying a load, the failure must be corrected and the system must be reset by turning the Load Bank "Off" then "On".

This is a permissive/energize-to-run circuit in which all safety sensors must energize their control relays on normal operation before load can be applied. This system includes the following switches and relays:

1. Exhaust Temperature Switch (EXTS),
2. Pressure Switch (PS),
3. Intake Temperature Switch (INTS),
4. Cooling Failure Relay (CFR) and
5. Time Delay Relay (TDR).




Thermocouple Temperature Switch

The exhaust temperature network consists of a type J thermocouple (TC) and a solid state thermocouple sensor (EXTS). The temperature switch has been factory adjusted for precise Load Bank over temperature protection un-

der normal operating conditions. Unusual operating conditions may require field adjustment. The setpoint of the Exhaust Temperature Switch (EXTS) may be changed by rotating the adjustment knob on the variable resistor. Consult the Simplex Service Department (217-525-6995 24hrs) before changing the temperature switch setpoint.

REMOTE/AUXILIARY OPERATION

This Load Bank can be operated from a Remote Control Panel, supplied by Simplex or others, or any number of other devices including programmable controllers, personal, mini or mainframe computers, programmable timers, etc.



WARNING

Before attaching any remote auxiliary control device to the Load Bank consult the Simplex Service Department.

By supplying positive 24VDC signals (from the Load Bank DC supply only) to the Local Main Logic Control Panel the Load Bank operator is able to energize the cooling fan, apply load steps and monitor load bank failure systems from a remote control panel. The correct configuration of Load Bank Local and Remote Printed Circuit Board interconnections for remote control operation is shown in the illustration on the previous page.

Guidelines For A User Supplied Auxiliary Remote Load Bank Control Device

The device must have some means of switching 24VDC signals from the load bank power supply to the main printed circuit board (CP1) to control the load bank. The device should also have a means of monitoring 24VDC output signals from CP1 which annunciate Load Bank status and operation. 24VDC is supplied at terminals 1 (-) and 12 (+) of TB'RC' for this use.

To operate the Load Bank from any remote device the "Load Bank Mode" selector switch on the Local Control Panel must be placed in the "Remote" position. To energize the Load Bank cooling fan and control system the remote device must input a positive signal at Terminal 10 of TB'B'. To energize the load steps the device must input a positive signal on terminals 7, 19, 27, etc. Output signals from CP1 for Load Bank

annunciation of remote control, load dump, cooling failure and normal operation will appear at TB'B' Terminals 14, 5, 19, and 24 respectively. Do not use the Load Bank 24VDC power supply to power any other auxiliary devices. It must be used only as a source for supplying control signals to the Load Bank printed circuit board.

Before attaching any remote auxiliary control device to the Load Bank consult the Simplex Service Department.

MAINTENANCE

The Load Bank has been designed to require minimum maintenance. All components have been chosen for a long, reliable life. Two basic intervals of maintenance are required: each operation and every 50 hours or 6 months (whichever comes first).

EACH OPERATION

The air intake screens and louvers, fan and cooling chamber, and exhaust openings must be checked for any obstructions or foreign objects. Due to the high volume of air circulated, paper and other items can be drawn into the air intakes. During Load Bank operation insure that air is exiting from the top exhaust vent.

The load branches should be checked for blown fuses or opened load resistors. To check the fuses or load resistors, operate the Load Bank from a balanced 3-phase source and check the three line currents. The three current readings should be essentially the same. If a sizeable difference is noted one or more load fuses or load resistors may have malfunctioned.

WARNING

For continued safety and for maximum equipment protection, always replace fuses with one of equal rating only.

EVERY 50 HOURS OR 6 MONTHS

Check the tightness of the electrical connections. The expansion and contraction caused by Load Bank operation may result in loose connections. The vibrations caused by the cooling fan may also loosen electrical connections. If the Load Bank is transported "over the road", the electrical connections should be checked for tightness at a shorter-than-normal time interval. See "Primary Inspection".

MOTOR LUBRICATION

Most Load Bank direct drive cooling fan motors are permanently lubricated and sealed and do not require lubrication.


Inspect the fan motor supplied with your Load Bank for grease fittings. If the motor contains grease fittings you must lubricate the motor. Belt driven cooling fans have bearings which should be lubricated. Bearings should be lubricated every 50 hours of operation or 6 months whichever comes first.

The motor manufacturer recommends a two-year lubrication interval for motors used for normal, steady-running, light-duty, indoor loads, in relatively clean atmospheres.

Type of Grease

Use Westinghouse 5370IRY grease, un-less a special grease is specified on the nameplate. Some equivalent greases are:

- Chevron SR1-2 - Standard Oil of California
- Premium RB ----- Texaco, Inc.
- Unirex N2 ----- Exxon
- Dolium R ----- Shell Oil Company
- Rykon Premium - American Oil



Shaft and Grease Fitting

GREASING REFERENCE TABLE

Shaft Diameter At Face of Bracket	Amount of Grease to Add
3/4" to 1 1/4"	1/8 cu.in. or 0.1 oz.
1 1/4" to 1 7/8"	1/4 cu.in. or 0.2 oz.
1 7/8" to 2 3/8"	3/4 cu.in. or 0.6 oz.
2 3/8" to 3 3/8"	2.0 cu.in. or 1.6 oz.

Procedure for Regreasing

When regreasing, stop the motor, remove the outlet plug and add the amount of grease suggested in the reference table. Use hand-lever gun only. Discontinue at once if grease appears at the outlet plug. This may occur before the specified amount of grease is used. Run the motor for about ten minutes before replacing the outlet plug.

WARNING

Overgreasing is a major cause of bearing and motor failure. Also make sure dirt and contaminants are not introduced when adding grease.

TROUBLESHOOTING

This section is designed to aid the electrical technician in basic Load Bank system troubleshooting. All of the problems listed can be verified with a basic test meter and/or continuity tester. For safety reasons, when troubleshooting Load Bank systems always remove all test source power, fan/control power, anti-condensation heater power, etc.

COOLING FAN MOTOR WILL NOT OPERATE

1. Inoperative Fan Circuit Breaker (CB)
2. Fan/Control Power not available/incorrect
3. Inoperative Fan Motor (MOT)
4. Fan Motor Contactor (FMC) de-energized
5. Restriction of air (intake or exhaust)
6. Fan pressure switch inoperative


COOLING FAILURE INDICATED

Exhaust temp above EXTS setpoint:

1. Over temperature sensor failure
2. Fan failure
3. Air restriction (intake or exhaust)
4. Overvoltage condition present

Exhaust temp below EXTS setpoint:

1. Restriction of air (intake or exhaust)
2. Fan pressure switch inoperative
3. Overtemperature sensor failure



RIGHT SIDE VIEW
EXTERNAL PANELS REMOVED

TEST METERS DO NOT OPERATE PROPERLY

1. Meter voltage switch failure
2. Meter multiplier resistor inoperative
3. Improper positioning of meter voltage selector switch
4. Current transformer or current transformer-wiring failure
5. Test meter failure
6. Meter fuses open

SOME LOAD STEPS CANNOT BE ENERGIZED

1. Inoperative load step switches
2. Open load step resistor(s)
3. Inoperative load step relays
4. Inoperative load step contactors
5. Open load step fuses

! WARNING !

When troubleshooting Load Bank systems always remove all test source power, fan/control power, anti-condensation heater power, etc.

DRAWINGS AND PARTS LIST

The drawings included in this manual are the most accurate source of part numbers for your Load Bank. When ordering replacement parts for Simplex Load Banks, always consult the Parts Drawing. When contacting the Simplex Service Department always have your work order and drawing number ready for reference. The Load Bank Specifications Sheet in the front of this manual lists all of the drawings included in this manual. The Work Order Number and the Drawing Numbers are also located on each drawing legend. *A typical drawing legend and parts list is illustrated below.*

SIMPLX®		SPRINGFIELD, ILLINOIS
SCALE :	APPROVED BY :	DRAWN BY : GB
DATE : 7/28/98		REVISED : 0.
RESISTIVE LOAD BANK 2000KW, 480V, 3Ø, 60HZ		SATURN 2000 UL CONTROL SECTION
W.O. # 32711-98-43		DRAWING NUMBER 47B95558C

ITEM	QTY.	PART #	DESIG.	DESCRIPTION
1	120	47B95561	LR1-LR120	LOAD ELEMENTS POWR-WEB, 16,667W @ 480V
2	41	13012160	C1-C40 FMC	CONTACTOR 62A, 600V, 3POLE 120VAC COIL
3	4	14035500	CF1-CF4	FUSE 5A, 600V, 200KA1C
4	120	14086000	F1-F120	FUSE 70A, 600V, 200KA1C
5	2	15011500	(CF1-CF4)	FUSEBLOCK 30A, 600V, 2 POLE
6	1	24646020	MOT	MOTDR. 20HP, 3 PHASE 208-230/460VAC, TEFC 1800 RPM
7	1	13828000	(MOT)	FAN BLADE, 60" 50000CFM
8	1	12046340	FCB	FAN CIRCUIT BREAKER 100A FRAME, 50A TRIP, 3 POLE, 600V
9	1	25673000	TB'E'	TERMINAL BLOCK 30A, 600V, 24 LINE
10	1	25672000	TB'CP1' TB'LD' TB'CF' TB'CT' TB'PC'	TERMINAL BLOCK 30A, 600V, 15 LINE
11	2	25457000	T1, T2	TRANSFORMER, 1000VA 480/240-240/120V
12	3	24771000	K1-K3	GENERAL PURPOSE RELAY 10A, 3PDT, 120VAC COIL
13	3	24891000	(K1-K3)	RELAY BASE 11 PIN SCREW TRM
14	1	25256500	PS	PRESSURE SWITCH, SPDT DIFFERENTIAL SENSING
15	1	25309650	INTS	INTAKE TEMP SWITCH SPST, OPENS @ 120 DEG F
16	4	25309560	EXTS1-4	EXHAUST TEMP SWITCH OPENS @ 75 DEG F ABOVE NORMAL OPERATING TEMP
17	4	25512400	TC1-4	THERMOCOUPLE, TYPE J (FOR EXTS)

APPENDIX A - ABBREVIATIONS USED IN THIS MANUAL

Listed below are abbreviations of terms found on Simplex Load Bank Systems. When following a load bank drawing utilize this guide to define abbreviated system and component names. As this is a master list, drawings and text pertaining to your equipment may not contain all these terms.

AC -Alternating current	GFB -Ground fault breaker	OVR -Overvoltage relay-relay used in overvoltage failure system, located on relay sub-panel
AIC -Ampere interrupting current-maximum short circuit fault current a component can safely interrupt	GBTR -Ground breaker tripped relay	OLR -Overload relay-used for motor protection
AM -Ammeter	HVR -High voltage relay	OTR -Overtemperature relay-used in failure system
AMSW - Ammeter selector switch-selects any phase for current reading	Hz -Hertz-cycles per second, measurement of frequency	PF -Power factor-in resistive only loads expressed as unity (1.0), in inductive loads expressed as lagging, in capacitive loads expressed as leading
CF -Control fuse	IFCV -Incorrect fan/control voltage	PAR -Control power available relay-relay energized when control power is available
CFM -Cubic feet per minute-used to rate fan air flow capacity and load bank cooling requirement	INTS -Intake air temperature switch	PFM -Power factor meter
CFR -Cooling failure relay-normally energized relay in cooling failure subsystem	K -Relay coil/contact designation	PS -Pressure switch-switch used to detect fan failure
CPC -Control power contactor	KVA -Kilovolt amperes	RR -Reset relay
CPF -Control power fuse	KVAR -Kilovolt amperes-reactive	RTM -Running time meter-keeps time log of equipment use.
CT -Current transformer- used in metering circuits	KW -Kilowatts	TB -Terminal block
DC -Direct current	KWM -Kilowatt meter	TDR -Time delay relay-relay which times out before contacts change state
EXTS -Exhaust air temperature switch	KWT -Kilowatt meter transducer	TEFC -Totally enclosed, fan cooled-refers to motor enclosure
FCB -Fan circuit breaker-circuit breaker in series with fan control power	LM -Louver motor	TEAO -Totally enclosed, air-over-refers to motor enclosure
FCVR -Fan control voltage relay-normally energized relay on relay sub-panel	LMC -Louver motor contactor	UPS -Uninterruptable power source
FM -Frequency meter-monitors frequency of test source	LR -Load resistive element	V -Voltage
FMC -Fan motor contactor-controls power to fan motor	LX -Load reactive element	VSR -Voltage sensing relay
FMSW -Frequency meter switch	L1 -Line 1	XCB -Reactive load controlling circuit breaker
FPS -Fan power switch-used to energize cooling system	L2 -Line 2	
	L3 -Line 3	
	MCB -Main circuit breaker	
	MDS -Main Disconnect Switch	
	MF -Meter fuse	
	MLB -Main Load Bus	
	MOT -Motor	
	NEMA -National electrical manufacturer's association	
	ODP -Open, drip-proof-refers to motor enclosure	

APPENDIX B - CALCULATIONS & FORMULAS

The following calculations are used to determine the actual kilowatt load being applied by the Load Bank, when line voltages and currents are known (at 1.0 power factor).

3 Phase

1. Read all three line currents and find the average reading.
2. Read all three line-to-line voltages and find the average reading.
3. Multiply the average current times the average voltage.
4. Multiply the answer of step #3 times the square root of 3 (1.732).
5. Divide the answer of step #4 by 1000. The answer is the actual kilowatts of load being applied by the Load Bank.

Single Phase

1. Determine the line current.
2. Determine the line-to-line voltage.
3. Multiply the line current times the line-to-line voltage.
4. Divide the answer of step #3 by 1000.
5. The answer of step #4 is the actual kilowatts being applied by the load bank.

EXAMPLES

Using line voltages and currents:

3 Phase

Current Readings	Voltage Readings
A ₁ = 249A	V ₁₋₂ = 481V
A ₂ = 250A	V ₂₋₃ = 479V
A ₃ = 254A	V ₃₋₁ = 483V

$$\begin{aligned} \text{Average Current} &= \frac{A_1 + A_2 + A_3}{3} \\ &= \frac{249+250+254}{3} \\ &= 251A \end{aligned}$$

$$\begin{aligned} \text{Average Voltage} &= \frac{V_{1-2} + V_{2-3} + V_{3-1}}{3} \\ &= \frac{481 + 479 + 483}{3} \\ &= 481V \end{aligned}$$

$$\begin{aligned} \text{Kilowatts} &= \frac{\text{Volts} \times \text{Amps} \times 1.732}{1000} \\ &= \frac{481 \times 251 \times 1.732}{1000} \\ &= 209.1KW \end{aligned}$$

Single Phase

Current Reading: 150A Voltage Reading: 240V

$$\begin{aligned} \text{Kilowatts} &= \frac{\text{Volts} \times \text{Amps}}{1000} \\ &= \frac{150 \times 240}{1000} \\ &= 36.1KW \end{aligned}$$

The following calculations are used to determine the amount of current when the desired amount of kilowatts is applied at 1.0 power factor.

3 Phase

1. Multiply the desired amount of kilowatts to be applied by 1000.
2. Multiply the operating voltage times the square root of 3 (1.732)
3. Divide the answer of step #1 by the answer of step #2.
4. The answer of step #3 is the average line current with the desired kilowatts applied at 1.0 power factor.

Single phase

1. Multiply the desired amount of kilowatts to be applied by 1000.
2. Divide the answer of step #1 by the operating voltage.
3. The answer of step #2 is the average line current with the desired amount of kilowatts applied at 1.0 power factor.

The following calculations are used to determine a step kilowatt rating at other than a rated voltage. This is accomplished by referencing the load step to a KW value at a known voltage.

1. Determine the new unrated operating voltage.
2. Divide the new operating voltage by the reference voltage.
3. Square the answer of step #2.
4. Multiply the answer of step #3 times the reference kilowatt value of the load step which the new kilowatt rating is desired.
5. The answer of step #4 is the kilowatt rating of the load step at the new voltage.

EXAMPLES

When desired amount of kilowatts is applied at 1.0 PF:

3 Phase

Applied: 50KW Operating Voltage: 480V

$$\begin{aligned} \text{Amperage} &= \frac{\text{KW} \times 1000}{\text{Volts} \times 1.732} \\ &= \frac{50 \times 1000}{480 \times 1.732} \\ &= \frac{50,000}{831.36} \\ &= 60.1 \end{aligned}$$

Single Phase

Applied: 25KW Operating Voltage: 240V

$$\begin{aligned} \text{Amperage} &= \frac{\text{KW} \times 1000}{\text{Volts}} \\ &= \frac{25 \times 1000}{240} \\ &= \frac{25,000}{240} \\ &= 104.2 \end{aligned}$$


Determining step KW at other than rated voltage:

Applied: 80KW Operating Voltage: 450V
Rated Voltage: 480V

$$\begin{aligned} \text{Step KW} &= (\text{Oper. Volt.} \div \text{Rated Volt.})^2 \times \text{Applied KW} \\ &= (450 \div 480)^2 \times 80 \\ &= .9375^2 \times 80 \\ &= 70.3 \end{aligned}$$

FORMULAS


		<u>Alternating Current</u>	<u>Direct Current</u>
Kilowatts	1 phase	$\frac{\text{Volts} \times \text{Amps} \times \text{PF}^*}{1000}$	$\frac{\text{Volts} \times \text{Amps}}{1000}$
	3 phase	$\frac{1.732 \times \text{Volts} \times \text{Amps} \times \text{PF}^*}{1000}$	
*Power Factor, expressed as decimal. (Resistive Load Bank PF is 1.0)			
Amperes <i>(KW known)</i>	1 phase	$\frac{\text{KW} \times 1000}{\text{Volts} \times \text{PF}}$	$\frac{\text{KW} \times 1000}{\text{Volts}}$
	3 phase	$\frac{\text{KW} \times 1000}{1.732 \times \text{Volts} \times \text{PF}}$	
KVA	1 phase	$\frac{\text{Volts} \times \text{Amps}}{1000}$	
	3 phase	$\frac{1.732 \times \text{Volts} \times \text{Amps}}{1000}$	
Amperes <i>(KVA known)</i>	1 phase	$\frac{\text{KVA} \times 1000}{\text{Volts}}$	
	3 phase	$\frac{\text{KVA} \times 1000}{1.732 \times \text{Volts}}$	
KVAR	1 phase	$\frac{\text{Volts} \times \text{Amps} \times \sqrt{1-\text{PF}^2}}{1000}$	
	3 phase	$\frac{1.732 \times \text{Volts} \times \text{Amps} \times \sqrt{1-\text{PF}^2}}{1000}$	



- NOTES:
1. UNIT MUST BE GROUNDED FOR OPERATORS SAFETY.
 2. DASHED LINES INDICATES WIRING NOT SUPPLIED BY SIMPLEX.
 3. CONTROL WIRE - 36 AWG, 35°C.
 4. CONTACTITY FROM TPCP: 1-3 INDICATES COOLING FAILURE, CONTACTITY FROM TPCP: 7-C INDICATES NORMAL OPERATION.
 5. LOAD IS DISENGAGED WHEN CONTACT IS OPEN UNLESS LOAD BANK BYPASS SWITCH IS ENGAGED.
 6. RATING MINIMUM TORQUE TO 30NM.HS.


- LOAD BANK WIRING COLOR CODED AS FOLLOWS:
- ALL AC CONTROL WIRE:
 LINE - BLACK
 COMMON/NEUTRAL - WHITE
 COIL JUMPER -
 LINE - RED
 COMMON/NEUTRAL - BLUE
- ALL AC POWER WIRING:
 A PHASE, LINE 1 - BLACK
 B PHASE, LINE 2 - RED
 C PHASE, LINE 3 - BLUE
- ALL DC CONTROL WIRING:
 POSITIVE - RED WITH A WHITE STRIPE
 NEGATIVE - BLACK WITH A WHITE STRIPE
- ALL AC POWER WIRING:
 POSITIVE - RED WITH YELLOW TAPE END
 NEGATIVE - BLACK WITH YELLOW TAPE END
- ALL WIRES ATTACHED TO LOAD BANK GROUND - GREEN
 ALL LOAD STRAPPING - WHITE

THE INFORMATION HEREON IS THE PROPERTY OF SIMPLEX, INC. AND/OR ITS SUBSIDIARIES. WITHOUT WRITTEN PERMISSION ANY COPYING, TRANSMITTAL TO OTHERS AND USE EXCEPT THAT FOR WHICH IT IS LOANED IS PROHIBITED.
 © 1988 SIMPLEX, INC. ALL RIGHTS RESERVED




DISK S/N: 4314

A RTB'A' 17 VAS 13		CJG
		7-28-99
SIMPLX		
SPRINGFIELD, ILLINOIS		
DATE - 5/14/99	APPROVED BY -	DRAWN BY - CJG
RESISTIVE INDUCTIVE LOAD BANK TUNING 420 UL		
120KW/30KVAR, 480V, 60HZ CONTROL SECTION		
W.O. 35973-99		4781 00384A



NOTES:

1. UNIT MUST BE GROUNDED FOR OPERATOR'S SAFETY.
2. DASHED LINES INDICATE WIRES NOT SUPPLIED BY SIMPLEX.
3. INTERNAL LOAD BANK LOAD WIRE #8 AWG, 150°C, EXCEPT WHERE NOTED.






LOAD BANK WIRING COLOR CODED AS FOLLOWS:
 ALL AC CONTROL WIRE JUMPERS:
 LINE SIDE, "A" SIDE OF COIL - RED ("R")
 COMMON (GROUND OR NEUTRAL), "B" SIDE OF COIL - BLUE ("B")
 ALL AC POWER WIRING:
 A PHASE, LINE 1 - BLACK ("BK")
 B PHASE, LINE 2 - RED ("R")
 C PHASE, LINE 3 - BLUE ("B")
 ALL WIRES ATTACHED TO LOAD BANK GROUND - GREEN ("G")
 ALL LOAD JUMPERS AND STRAPPING - WHITE ("W")

DISK S/N: 4314




SIMPLX		SPRINGFIELD, ILLINOIS	
SCALE:	APPROVED BY:	DATE:	REVISION:
		5/18/99	1
RESISTIVE/INDUCTIVE LOAD BANK 120KW/90KVAR, 480V, 3ø, 60Hz		NEPTUNE-120 UL LOAD SECTION	
W.O. # 35973-99-43			DRAWING NUMBER 478100385

FRONT OF TRAY



THE INFORMATION HEREON IS THE PROPERTY OF SIMPLEX, INC., AND/OR ITS SUBSIDIARIES. WITHOUT WRITTEN PERMISSION ANY COPYING, TRANSMITTAL TO OTHERS AND USE EXCEPT THAT FOR WHICH IT IS LOANED IS PROHIBITED.
 © 1999 SIMPLEX, INC. ALL RIGHTS RESERVED

REAR OF TRAY




DISK S/N: 4314

SIMPLX		SPRINGFIELD, ILLINOIS	
SCALE :	APPROVED BY :	DRAWN BY :	CJC
DATE : 5/30/99		REVISED :	1
RESISTIVE/INDUCTIVE LOAD BANK 120KW/208VAC/480V/3PH/3W/3Z		NEPTUNE PRO UL LOAD STRAPPING	
W-0-35973-99-A37		DRAWING NUMBER 478100386	


LR12-LR1

LR24-LR13

LR36-LR25



LEFT SIDE



LR1-LR12

LR13-LR24

LR25-LR36

INTS PS

FAN
MOTOR

LX1
3.75
KVAR

LX2
7.50
KVAR


LX3
7.50
KVAR

LX4
15.00
KVAR

RIGHT SIDE

DISK S/N: 4314

SIMPLX		SPRINGFIELD, ILLINOIS	
SCALE: 1/2"	APPROVED BY: [Signature]	DRAWN BY: C.J.G.	REVISION:
DATE: 5/10/93			
RESISTIVE/INDUCTIVE LOAD BANK NEPTUNE-120VLL		ELEMENT/REACTOR LAYOUT	
120KW/400KVAR/480V/50/60HZ			
W.O. # 35973-99-43		DRAWING NUMBER 47BD100480	



THE INFORMATION HEREON IS THE PROPERTY OF SIMPLEX, INC., AND/OR ITS SUBSIDIARIES. WITHOUT WRITTEN PERMISSION ANY COPYING, TRANSMITTAL TO OTHERS AND USE EXCEPT THAT FOR WHICH IT IS LOANED IS PROHIBITED.
 © 1999 SIMPLEX, INC. ALL RIGHTS RESERVED

NOTES:

1. UNIT MUST BE GROUNDED FOR OPERATORS SAFETY.
2. DASHED LINES INDICATE WIRE NOT SUPPLIED BY SIMPLX.
3. ALL CONTROL WIRE #16 AWG, 105°C (EXCEPT WHERE NOTED)

LOAD BANK WIRING COLOR CODED AS FOLLOWS:

ALL AC CONTROL WIRE:

LINE - BLACK

COMMON/NEUTRAL - WHITE

COIL JUMPERS:

LINE - RED

COMMON/NEUTRAL - BLUE

ALL AC POWER WIRING:

A PHASE, LINE 1 - BLACK

B PHASE, LINE 2 - RED

C PHASE, LINE 3 - BLUE

ALL DC CONTROL WIRING:

POSITIVE - RED WITH A WHITE STRIPE

NEGATIVE - BLACK WITH A WHITE STRIPE


ALL DC POWER WIRING:

POSITIVE - RED WITH YELLOW TAPED END


NEGATIVE - BLACK WITH YELLOW TAPED END

ALL WIRES ATTACHED TO LOAD BANK GROUND - GREEN

ALL LOAD STRAPPING - WHITE



2.1 Amps



DISK S/N: 4314

SIMPLX		SPRINGFIELD, ILLINOIS	
SCALE -	APPROVED BY -	DRAWN BY - C.J.G.	REVISION - 1
DATE 5/1/99			
RESISTIVE/INDUCTIVE LOAD BANK 120KW/90KVAR, 480V, 3P, 60HZ		NEPTUNE-120 UL AND CONDENSATION	
DRAWING NUMBER 478100481		478100481	


ITEM	QTY.	PART #	DESIG.	DESCRIPTION	ITEM	QTY.	PART #	DESIG.
1	6	24299610	LR1-LR6	LOAD ELEMENTS POWR-WEB, 833W @ 240V	16	12	14057500	F4-F9 XF4-X
2	12	24299615	LR7-LR18	LOAD ELEMENTS POWR-WEB, 1667W @ 240V	17	6	14069000	F10-F11 XF10-X
3	6	24299620	LR19-LR24	LOAD ELEMENTS POWR-WEB, 3333W @ 240V	18	6	14073000	F13-F14 XF13-X
4	6	24299625	LR25-LR30	LOAD ELEMENTS POWR-WEB, 4167W @ 240V	19	3	14080000	XF16-X
5	6	24299630	LR31-LR36	LOAD ELEMENTS POWR-WEB, 8333W @ 240V	20	3	14086000	F16-F
6	1	-----	LX1	LOAD REACTOR, 3.75KVAR 480V, 3PH., 60HZ 3-WIRE, DELTA CONNECTION (QLSUN)	21	1	15010000	[CF3]
7	2	-----	LX2,LX3	LOAD REACTOR, 7.50KVAR 480V, 3PH., 60HZ 3-WIRE, DELTA CONNECTION (QLSUN)	22	1	15011500	[CF1,CF
8	1	-----	LX4	LOAD REACTOR, 15.00KVAR 480V, 3PH., 60HZ 3-WIRE, DELTA CONNECTION (QLSUN)	23	8	15013000	[F1-F12] [XF1-XF
9	1	-----	LX5	LOAD REACTOR, 18.75KVAR 480V, 3PH., 60HZ 3-WIRE, DELTA CONNECTION (QLSUN)	24	3	15015500	[F13-F15] [XF13-XF
10	1	-----	LX6	LOAD REACTOR, 37.50KVAR 480V, 3PH., 60HZ 3-WIRE, DELTA CONNECTION (QLSUN)	25	1	24642000	MOT
11	10	13013100	C1-C5 XC1-XC4 FMC	CONTACTOR 35A, 600V, 3POLE 120VAC COIL	26	1	13825100	[MOT]
12	3	13021500	XC5, XC6 C6	CONTACTOR 65A, 600V, 3POLE 120VAC COIL	27	1	12046300	FCB
13	2	14027000	CF1, CF2	FUSE 4A, 600V, 200KAIC	28	3	25670000	TB'E' TB'CF' TB'LD' TB'SH'
14	1	14035000	CF3	FUSE 5A, 600V, 100KAIC	29	1	25454000	T1
15	6	14043000	F1-F3 XF1-XF3	FUSE 10A, 600V, 200KAIC	30	1	25256500	PS
					31	1	25309650	INTS
					32	1	25309560	EXTS
					33	AR	25512400	TC
					34	1	50016500	DCS

THE INFORMATION HEREON IS THE PROPERTY OF SIMPLEX, INC.,
AND/OR ITS SUBSIDIARIES. WITHOUT WRITTEN PERMISSION ANY
COPYING, TRANSMITTAL TO OTHERS AND USE EXCEPT THAT FOR
WHICH IT IS LOANED IS PROHIBITED.
© 1999 SIMPLEX, INC. ALL RIGHTS RESERVED

QTY.	DESCRIPTION	ITEM	QTY.	PART #	DESIG.	DESCRIPTION
1	FUSE 20A, 600V, 200KAIC	35	1	50000300	CP1	CONTROL PANEL, LOCAL PRINTED CIRCUIT BOARD
3	FUSE 30A, 600V, 200KAIC	36	3	14010000	FU1-FU3	FUSE; 2A, 250V (COMPONENTS OF CP1 & DCS)
1	FUSE 35A, 600V, 200KAIC	37	1	50010300	TD	TIME DELAY RELAY 7 SEC DELAY ON OPERATE (COMPONENT OF CP1)
1	FUSE 50A, 600V, 200KAIC	38	1	50000400	CP5	CONTROL PANEL, REMOTE PRINTED CIRCUIT BOARD
3	FUSE 70A, 600V, 200KAIC	39	3	50000310	CP2-CP4	CONTROL PANEL, LOCAL AUX. PRINTED CIRCUIT BOARD
3	FUSEBLOCK 30A, 600V, 1 POLE	40	3	50000410	CP6-CP8	CONTROL PANEL, REMOTE AUX. PRINTED CIRCUIT BOARD
1	FUSEBLOCK 30A, 600V, 2 POLE	41	1	24827790	OLR	OVERLOAD RELAY 3 POLE 600V, 6-18A ADJUSTABLE
3	FUSEBLOCK 30A, 600V, 3 POLE	42	2	25317000	DSW DSW1	DISCONNECT SWITCH 3P, 40A, 480V, 20 HP
1	FUSEBLOCK 60A, 600V, 3 POLE	43	1	24829000	DLRX	DLR AUXILIARY CONTACT
1	MOTOR, 2HP, 3 PHASE 208-230/460VAC, TEFC 1800 RPM	44	1	25309201	THERM	THERMSTAT 35-95 DEG. F SPDT, 125VA
1	FAN BLADE, 24" 1000CFM	45	1	15142000	[THERM]	CONDUIT BOX
2	FAN CIRCUIT BREAKER 100A FRAME, 15A TRIP, 3 POLE, 600V	46	2	24300002	SH1, SH2	LOAD ELEMENT 125W @ 120V 14"
1	TERMINAL BLOCK 30A, 300V, 12 LINE	47	1	7BD90557	[SH1, SH2]	HEATER MOUNTING BRACKET
1	TRANSFORMER, 750VA 480/240:240/120V	48	1	7BD44465C	MLB PHASE-A	MAIN LOAD BUS 0.250" X 3.000" X 30.500"
1	PRESSURE SWITCH, SPDT DIFFERENTIAL SENSING	49	1	7BD44466C	MLB PHASE-B	MAIN LOAD BUS 0.250" X 3.000" X 34.750"
1	INTAKE TEMP SWITCH SPST, OPENS @ 120 DEG F	50	1	7BD44467E	MLB PHASE-C	MAIN LOAD BUS 0.250" X 3.000" X 39.000"
3	EXHAUST TEMP SWITCH OPENS @ 75 DEG F ABOVE NORMAL OPERATING TEMP	51	3	7BD63693	[MLB]	NEMA BUS CONNECTOR 0.250" X 4.000" X 10.500"
1	THERMOCOUPLE, TYPE J (FOR EXTS)	52	1	47BD63191	GND	GROUND BUS 0.250" X 3.000" X 12.250"
6	DC SUPPLY, 120VAC INPUT 24VDC OUTPUT	53	6	15400000	[MLB]	ISOLATOR 2.750"


DISK S/N: 4314

SIMPLX		SPRINGFIELD, ILLINOIS	
SCALE: 1	APPROVED BY: <i>[Signature]</i>	DATE: 5/12/99	DRAWN BY: C.J.G.
RESISTIVE LOAD BANK 120KW/90KVAR, 480V, 3Ø, 60HZ	REVISION: 1	NEPTUNE-120 UL LEGEND	
W.O. #25075-09-13	DRAWING NUMBER 47B100482		





L.H. SIDEPANEL

LX1-LX6
WIRE-WAY




GROUND BUS
47BD63191
250 X 3.000 X 12.250




MAIN SUBPANEL

(3) NEMA HOLE
(12) .562 HOLE
7BD63693


LR1-LR36
WIRE-WAY



RH SIDE PANEL



TOP VIEW
BUS BARS



FUSE DETAIL



PATTERNS
PER PHASE

DISK S/N: 4314

SIMPLX		SPRINGFIELD, ILLINOIS	
SCALE: 1/8"	APPROVED BY: <i>KEN</i>	DRAWN BY: C.J.G.	REVISION: 1
DATE: 5/31/99	RESISTIVE LOAD BANK		NEPTUNE-120 UL
120KW/90KVAR, 480V, 3Ø, 60HZ		SUBPANEL LAYOUT	
W.O. # 35973-99-43			DRAWING NUMBER 47BD100483



LOCKABLE LATCH





DISK S/N: 4314

SIMPLX		SPRINGFIELD, ILLINOIS	
SCALE - 1	APPROVED BY - <i>[Signature]</i>	DRAWN BY - CJC	
DATE - 5/11/99	REVISED - 2/2/01		
RESISTIVE LOAD BANK		NEPTUNE-120 UL	
120KW/90KVAR, 480V, 3, 60HZ		REMOTE CONTROL BOX	
W.O. # 35973-98-43		DRAWING NUMBER 4788100484	

SIMPLX FORCED AIR-COOLED REACTIVE LOAD BANK-LBS SERIES

CAPACITY: 120KW/90KVAR AT 0.8PF
 VOLTAGE: 480VAC
 CONNECTION: 3-PHASE, 3-WIRE
 FREQUENCY: 60HZ
 FAN POWER: INTERNAL 480VAC
 CONTROL POWER: INTERNAL 480/120V TRANSFORMER

COOLING: FORCED AIR
 AIRFLOW: 8000 CFM
 MAXIMUM AIR INTAKE TEMP.: 120°F
 NOMINAL AIR TEMP. RISE: 45°F-150°F MAX
 TEMPERATURE RISE: $\frac{100}{1000}$
 DUTY CYCLE: Continuous
 SERIAL NO. 35073-99-43



LAMP TEST

PRESS TO TEST

AUTO LOAD DUMP

AUTO

BYPASS


LOCAL MANUAL CONTROL

PUSH TO RUN

PUSH TO STOP

LOAD BANK MODE

LOCAL LOCAL
MANUAL AUTO
OFF REMOTE



SIMPLX FORCED AIR-COOLED REACTIVE LOAD BANK-LBS SERIES

CAPACITY: 120KW/90KVAR AT 0.8PF
 VOLTAGE: 480VAC
 CONNECTION: 3-PHASE, 3-WIRE
 FREQUENCY: 60HZ
 FAN POWER: INTERNAL 480VAC
 CONTROL POWER: INTERNAL 480/120V TRANSFORMER




LAMP TEST

PRESS TO TEST

AUTO LOAD

AUTO

BYPASS



AIR-COOLED REACTIVE LOAD BANK-LBS SERIES

FORCED AIR
 8000 CFM
 AIR INTAKE TEMP: 120°F
 AIR TEMP RISE: 45°F - 150°F MAX
 FUSE RISE: _____
 CYCLE: Continuous
 NO. 35973-99-43



AIRFLOW
DIRECTION

LOAD BANK MODE

REMOTE DISCONNECT	LOAD DUMP BYPASS	NORMAL OPERATION	COOLING FAILURE
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

LOAD BANK MODE	REMOTE AUTO
	<input type="radio"/>
REMOTE MANUAL	<input type="radio"/>
REMOTE MANUAL CONTROL	<input type="radio"/>
PUSH TO RUN	<input type="radio"/>
PUSH TO STOP	<input type="radio"/>

LOAD CONTROL

ON	<input type="radio"/>	10KW	<input type="radio"/>	10KW
OFF	<input type="radio"/>		<input type="radio"/>	
ON	<input type="radio"/>	50KW	<input type="radio"/>	3.75KVAR
OFF	<input type="radio"/>		<input type="radio"/>	
ON	<input type="radio"/>	15.00KVAR	<input type="radio"/>	18.75KVAR
OFF	<input type="radio"/>		<input type="radio"/>	
ON	<input type="radio"/>	STEP 14	<input type="radio"/>	STEP 15
OFF	<input type="radio"/>		<input type="radio"/>	

FUSE REPLACEMENT CHART

CF1-CF3 4A,800V,200KAC
 FHO-FA

CF4-CF6 6A,800V,100KAC
 KTR-5

NEPTUNE-20 UL
 NEMA-3R W.O. #35973-99-43

SIMPLX

FUSE REPLACEMENT CHART

F1-F3 10A,800V,200KAC
 J28-70

F4-F6 20A,800V,200KAC
 J28-20

F7-F9 30A,800V,200KAC
 J28-20

NEPTUNE-20 UL
 NEMA-3R W.O. #35973-99-43

SIMPLX

FUSE REPLACEMENT CHART

F10-F12 60A,800V,200KAC
 J28-20

F13-F15 60A,800V,200KAC
 J28-20

F16-F18 75A,800V,200KAC
 J28-70



NEPTUNE-20 UL
 NEMA-3R W.O. #35973-99-43

SIMPLX


DISK S/N: 4314

SIMPLX SPRINGFIELD, ILLINOIS

SCALE: 1/2"	APPROVED BY:	DRAWN BY: CJG
DATE: 5/11/91	REVISION: 1	
RESISTIVE LOAD BANK 120KW/90KVAR/80V, 3PH, 50HZ	NEPTUNE-20 UL NAMEPLATES	
W.O. # 35973-99-43	DRAWING NUMBER 47BD100485	



LEFT SIDE VIEW




FOOTPRINT

NOTES:

1. B
2. C
3. P
4. A

THE INFORMATION HEREON IS THE PROPERTY OF SIMPLEX, INC., AND/OR ITS SUBSIDIARIES. WITHOUT WRITTEN PERMISSION ANY COPYING, TRANSMITTAL TO OTHERS AND USE EXCEPT THAT FOR WHICH IT IS LOANED IS PROHIBITED.



TOP OF CONTROL COMPARTMENT AVAILABLE FOR CONDUIT ENTRY.

CONSTRUCTION: ALL WELDED FORMED STEEL FRAME, DOORS, PANELS AND SKID.
 FORK LIFT TUBES 7GA HRS, OUTER SHELL 14GA HRS; BASE SKID,
 CONTROL BOX AND DOORS 14GA HRS, FAN/ELEMENT DOORS 16GA HRS
 ALL HINGES, EXTERIOR FASTENERS, AND EXTERIOR
 HARDWARE ARE STAINLESS STEEL

PRIMER: SHERWIN WILLIAMS - RECOATABLE EPOXY PRIMER
 G - B67H5 (24702600) - PART H B67V5 (24702700)

PAINT: SHERWIN WILLIAMS - POLANE HS PLUS POLYURETHANE
 COLOR: ASA 49 GRAY - F63HSA2036-3134 (24702800)
 CATALYST - V66V55 (24702801) / ACCELERATOR - V66B11 (24702802)

APPROXIMATE SHIPPING WEIGHT: 1,300 LBS LOAD BANK

DISK 5/N: 10438

SIMPLX		SPRINGFIELD, ILLINOIS
SCALE: 1" = 1'-0"	DATE: 7-10-97	DRAWN BY: TFM
REVISION PICTORIAL		REVISION
SINGLE 18" BOTTOM CONNECTED		
STD	DRAWING NUMBER 78086832	