

**Transfer Switch TS850/890
TSC800 Controller
Training Manual**

1) GENERAL

*Corporate Overview
Sales & Marketing Contacts
Agent & Distributor Contacts*

2) MISCELLANEOUS

Work Safe Report

3) TRANSFER SWITCHES

*TSC800 - Controller - Manual & data sheets.
TS850 Switch - Manual & drawings.
TSB850 - Bypass Switch - Manual & drawings.
TS890 - Switch - Manual & drawings.*

4) ENGINE CONTROLLER

MEC20 Controller , Manual, data sheets & drawings.

5) SOFTWARE

THS 2000 Information & Manual

12.0 TRANSFER/BYPASS SYSTEMS

12.1 Transfer Switch Basics

- .1) The automatic transfer switch (ATS) is the “heart” of the Standby Power Generation system or Emergency Power System. It is the first (and last!) link in the emergency power supply network. The ATS must:
 - (a) Sense the out of limits condition of the normal power source.
 - (b) Initiate the starting of the generator set.
 - (c) Disconnect the normal source from the load.
 - (d) Connect the generator set source to the load when its output is within acceptable limits (transfer load).
 - (e) Sense the return and stabilization of the normal source to within the desired limits.
 - (f) Retransfer loads from the generator set to the normal source.
 - (g) Provide off-load cool-down period for the generator set. (Optional)
 - (h) Signal the generator set to stop.
- .2) In addition to the foregoing control and switching functions the ATS must also:
 - (a) Positively isolate the two sources to ensure **no** possibility of inadvertent paralleling.
 - (b) Allow (and withstand) system fault currents to pass through the switch contacts and power conductors from the source to the fault location.
- .3) There are many manufacturers and types of transfer switches. Some of the common transfer mechanisms utilized are:
 - (a) Interlocked Contactors. This scheme utilizes two standard industrial electrical contactors or motor starter contactors. Two contactors are mounted together and are **mechanically** and **electrically** interlocked so that **only** one contactor can be closed at any one time. Reversing motor starters are similarly arranged and it is common to utilize a standard

reversing motor starter as the basic mechanism for a transfer switch.

This type of switch is commonly built up using a wide variety of reversing contactors.

- Allen Bradley
- MTE
- Klockner Moeller
- Westinghouse
- GE
- etc.




FIGURE 12.1.1

- (b) **Breaker Type ATS.** Mechanically interlocked electrically operated dual circuit breakers or switches. These are commonly non automatic (no thermal trips) molded case breakers or switches with single or multiple yoke drive arms or a walking beam type operator. These designs inherently incorporate a mechanical interlock means within the mechanical linkages or placement of the breakers/switches. Most common are Thomson Technology Inc. and Westinghouse Robonic. Many manufacturers use the basic Robonic mechanism with their own controls. Klockner

Moeller, Zenith, ITE and others also build ATS's with similar arrangement.

- (c) **Two Position ATS.** Transfer contacts specifically arranged for ATS duty. Usually two sets of contacts on a common operating arm (or two mechanically linked operating arms) with a solenoid or motor operated positioner. Contacts are arranged so that one set opens before the other set closes.

This arrangement is typical of Asco electric Co. ATS's. Other firms such as Zenith, Onan, etc. build similar devices.

- (d) High voltage transfer switches typically utilize appropriate standard high voltage contactors or power circuit breakers. Devices are arranged so as to permit mechanical interlocking.
- (e) Low voltage transfer arrangements can also be built up using interlocked power circuit breakers.

12.2 Transfer Switch Sensing/Control Systems

- 1) Normal source voltage sensing may be achieved in a variety of ways. The requirements are:
 - (a) Sense each line to line (or line to neutral) phase voltage.
 - (b) Provide for initiation of start up and transfer to generator source when any phase voltage deviates from normal by some amount.
 - (c) Relay(s) must sense when all phases return to within the normal range.
- 2) Commercially available transfer switches usually include adjustable low voltage sensing relays (VSR). The VSRs are typically adjusted to pickup when the source voltage rises above 90% of nominal. The VSRs are typically adjusted to allow dropout should the sources voltage drop below 80% of nominal. All phases are required to rise above 90% of nominal before the system is considered normal, however only 1 phase needs to drop below 80% of nominal to become deemed out of limit.

Most systems utilize two relays to monitor 3 phases. This provides adequate protection for most site applications. However where 3 phase electric motors represent a large portion of the connected load, 3 separate VSRs with close differential can be

utilized. However even 3 separate VSRs may not sense for a partial low voltage condition on one phase. VSRs may not dropout in this condition resulting from regenerative voltage or Back EMF from a light loaded electric motor. Alternatively a 47N (phase balance) relay can be added to sense for this condition. The 47N relay can provide single phase protection for motors. Operating electric motors with a L-L voltage differential greater than 5-6% (recommended max.) will result in an increase in current flow for the motors to deliver the desired output. Premature motor failures will result.





FIGURE 12.2.2

- 3) Some systems utilize a "built-up" ATS consisting of reversing contactors or power circuit breakers. This type of ATS may incorporate a similar sensing arrangement as previously described or may include a 3 phase under/over voltage relay such as the Westinghouse CP reverse phase voltage relay or a Basler BE1-27/59/47 (under/over/neg. sequence) relay. These relays can provide for 3 phase monitoring with inverse time delay on low or high voltage conditions. Voltage pickup points are adjustable. The inverse time delay is not adjustable. The greater the deviation from the setpoint, the faster the relay will operate.

- .4) The VSR contact(s) are used to initiate engine startup. There may be an additional start delay timer included to allow a delay of 2 or 3 seconds to avoid startup on momentary excursions. (Particularly if VSRs do not include time delay.)
- .5) In some applications the emergency source voltage is also monitored, the same as normal source. If, while running, the emergency voltage exceeds adjustable high and low limits the generator set is shutdown. This monitoring is usually part of the engine/generator sensing devices, and is **not** actually part of the control or functioning of the ATS. It is an electrical protective device in the generator set controls.
- .6) The ATS controls utilized, depend on the type of transfer mechanism.
 - (a) Electrically held contactor type ATS's require continuous control signal to maintain the required source. This is typical of reversing contactor type ATS's. These are typically utilized on single phase and some low power non critical 3 phase applications.
 - (b) Electrically operated, mechanically held ATS's require momentary open/close or pulse signals to the appropriate transfer mechanism. This is typical of TTI, Robonic or Asco type transfer switches.
 - (c) Electrically operated, electrically tripped contactor or breaker type ATS's require momentary close signals and momentary trip signals to both normal and emergency.
- .7) Some systems require that the normal source be immediately disconnected on overvoltage conditions. This is readily accomplished with electrically held or tripped breaker or contactor type ATS's. For mechanically held ATS's it entails special circuitry or a separate device (such as an electrically operated normal source breaker).

Depending on the application it may be desirable to also immediately disconnect the normal source on a low voltage condition (rather than wait until emergency source is ready to assume the load). Again the method employed will depend on the ATS arrangement utilized.

12.3 Bypass System Basics



***NOTE:** SLIDE BAR ARRANGEMENT ALLOWS NORMAL BYPASS SWITCH TO CLOSE ONLY IF LOAD ISOLATE SWITCH IS OPEN.

FIGURE 12.3.1

- 1) All transfer switches ultimately require service and maintenance. The switch must then be isolated from live sources, and may require physical removal. When connected loads cannot be disrupted, some alternative route for power flow to the load is required in order to service the transfer switch while maintaining power supply to the load.

Figure 12.3.1 depicts a common arrangement where draw-out breakers are utilized for the ATS. Two additional breakers are required to achieve the bypass capability. This arrangement only allows bypass with the normal source. The emergency source cannot be utilized while the ATS is being serviced.

- 2) For some ATS's the bypass and isolation system requires a somewhat different approach as shown in *Figure 12.3.2*. Again, this arrangement does not allow for use of the emergency source during ATS maintenance.
- 3) Another bypass isolation arrangement which includes either emergency or normal bypass is shown in *Figure 12.3.3*. This is of a Bumpless arrangement. To provide the bumpless transfer of the current source, the alternate source isolate switch must first be opened. Slide the slide bar to allow the bypass switch of the source to be bypassed (i.e. NB to bypass NI switch) to be closed; once

this breaker has been closed, the source and load isolate switches can be opened. With the switches in these positions, the transfer switch and it's controls are void of AC voltage. Should the power fail during service, the 2 bypass switches can be utilized as a manual transfer switch. The switches in the bypass arrangement have the same withstand ratings as the switches in the transfer switch.





FIGURE 12.3.2



***NOTE:** SLIDE BAR ARRANGEMENT ALLOWS BUMPLESS BYPASS FOR EITHER EMERGENCY OR NORMAL SOURCE, AND PERMITS MANUAL TRANSFER OPERATION WHILE SERVICING THE ATS.

FIGURE 12.3.3

- .4) Bypass arrangements can be achieved with fixed or drawout breakers or with manual switches. The system protection devices and potential fault currents are a major factor in selecting the bypass arrangement. A properly configured bypass arrangement should remove all sources of voltage from the transfer switch controls and mechanism for servicing.

12.4 Low Voltage Systems (Under 750V)

- .1) The following enclosed drawings depict some typical Low Voltage transfer and bypass arrangements. Both single line and control schematic diagrams are included for review and discussion.

—
—

12.5 High Voltage Systems (Over 750v)

- .1) Typical High Voltage transfer/bypass panel arrangements and related power, control and metering schematics are shown on enclosed drawings:

—
—

12.6 Thomson Technology Inc. Equipment

- .1) Thomson Technology Inc.(TTI) manufacture a complete range of low and high voltage transfer switches (up to 15kV). These can be supplied in various arrangements, electrically operated mechanically held, stored energy air circuit breaker and contactor type. A comprehensive arrangements of bypasses for the transfer switches are also available. TTI transfer switches and bypasses are specified and applied in a wide variety of applications. TTI product data enclosed includes:

—
—
—

12.7 Westinghouse Robonic and Derivatives

- .1) Westinghouse manufactures a low voltage Automatic Transfer switch using two mechanically interlocked molded case circuit breakers with an electrically operated (motor driven) walking beam operating mechanism.

Westinghouse also markets the basic switching mechanism (breakers, operator and interlock) to various electrical equipment manufacturers. They in turn build a completed transfer switch using their own sensing and controls, enclosure and optional accessories mated to the basic Robonic mechanism. (These are **not** Westinghouse Robonic transfer switches!)

Robonic switches (and derivatives) generally utilize non automatic circuit breakers (no long time overload trips).

Various bypass arrangements can be utilized to permit service.

Actual schematic drawings must be utilized for service, troubleshooting and adjustments.

12.8 Contactor Schemes

- .1) Electrically held mechanically interlocked contactor arrangements are commonly utilized on a wide variety of systems, but typically limited to low amperage ranges. Since 1978 when CSA's standards were upgraded, contactor schemes have largely been eliminated because they generally have inadequate withstand ratings and are difficult to apply.
- .2) Suitable contactors (and reversing starter contactors) are available from a number of manufacturers.

12.9 General

- .1) The basic principles of all automatic transfer and bypass systems are similar. The methods and equipment utilized to achieve the results are many and varied. Different manufacturers using identical components will often utilize different methods to achieve the same result.
- .2) All ATS electrical and troubleshooting must commence with actual diagrams and instructions for the specific ATS equipment.

12.10 Self Test

- ___ 1. A transfer switch must positively isolate the two sources from the load at all times and under all conditions. TRUE FALSE
- ___ 2. In an automatic transfer switch the priority position is usually the:
 (a) Normal source.
___ (b) Emergency source.
___ (c) Neutral or all open position.
- ___ 3. A single phase 3 wire (properly called 2 phase) transfer switch requires 3 voltage sensing relays to properly sense out of tolerance supply conditions. TRUE FALSE
- ___ 4. Electrically held contactor type transfer switches require:
___ (a) Mechanical interlocks.
___ (b) Continuous control power.
 (c) Electrical interlocks.
- ___ 5. The voltage sensing relays of an ATS should normally be set to about:
___ (a) 90% drop out, 110% pickup.
 (b) 80% drop out, 90% pickup.
___ (c) 30% drop out, 60% pickup.
- ___ 6. A transfer switch must have a frequency sensing relay on the normal and emergency sources. TRUE FALSE
- ___ 7. The purpose of a transfer bypass system is to permit ATS maintenance while powering the load. TRUE FALSE
- ___ 8. When using the bypass feature of a transfer and bypass panel, the bypass system will automatically transfer to the alternate source if one source fails. TRUE FALSE
- ___ 9. An ATS of a critical emergency power system should be functionally tested:
 (a) Weekly.
___ (b) Monthly.
___ (c) Annually.
___ (d) At least every 5 years.



TSC 800

TRANSFER SWITCH CONTROLLER

(WITH REMOTE COMMUNICATION OPTION)

INSTALLATION, OPERATING & SERVICE MANUAL



PM049 REV 5 00/07/31

TABLE OF CONTENTS

1. INSTALLATION	1
1.1. GENERAL INFORMATION	1
1.2. NOTES TO INSTALLER	1
1.3. MOUNTING LOCATION/INSTALLATION	2
1.4. AC VOLTAGE SENSING INPUT	2
1.5. AC CONTROL POWER INPUT	3
1.6. FOUR POSITION TEST SWITCH INPUTS (FTS4)	3
1.7. OUTPUTS	4
1.8. EXTERNAL PANEL CONTROL WIRING	6
1.9. REMOTE START CONTACT FIELD WIRING	6
1.10. COMMUNICATION CABLE	6
1.11. FACEPLATE MOUNTING DIMENSIONS	7
1.12. DIELECTRIC TESTING	8
2. DESCRIPTION	9
2.1. LEXAN FACEPLATE	10
2.2. PRINTED CIRCUIT BOARD	11
3. REMOTE COMMUNICATION OPTION	13
4. TSC 800 DISPLAY MENUS	16
4.1. SYSTEM TIME MENU	16
4.2. MANUAL TEST MENU	17
4.3. TSC 800 PROGRAM MENU	17
4.4. SYSTEM STATUS MENU	18
4.5. TIMER COUNTDOWN MENUS	20
4.6. UTILITY SUPPLY MENU	20
4.7. GENERATOR SUPPLY MENU	21

5. OPERATING INSTRUCTIONS	22
5.1. DISPLAY MENUS	22
5.2. TESTING INSTRUCTIONS	22
5.3. TIME CLOCK ADJUSTMENT	23
6. PROGRAMMING INSTRUCTIONS	23
6.1. EXERCISE TIMER	25
6.2. SYSTEM CONFIGURATION	26
6.3. VOLTAGE SENSING	27
6.4. FREQUENCY SENSING	29
6.5. TIME DELAYS	31
6.6. VOLTAGE SENSING CALIBRATION	37
7. TSC 800 PROGRAMMING DATA SHEETS	40
8. MAIN MENU PROGRAMMING SHEET	41
9. CALIBRATION DATA SHEET	42
10. TSC 800 TYPICAL CONNECTION DIAGRAM	43
11. TSC 800 SPECIFICATIONS	44
12. TROUBLESHOOTING	45
13. NOTES	46

1. INSTALLATION

1.1. GENERAL INFORMATION

NOTE:

Installations should be done in accordance with all applicable electrical regulation codes as required.

The following installation guidelines are provided for general information only pertaining to typical site installations. For specific site installation information, consult Thomson Technology Inc. as required. **Note:** Factory installations of TTI supplied transfer switches that have been tested and proven may deviate from these recommendations.

1.2. NOTES TO INSTALLER

If the transfer switch has programmable/multi-tap system voltage capability (refer to electrical schematic), confirm the transfer switch has been configured for the system voltage.

WARNING

Failure to confirm and match transfer switch voltage with the system voltage could cause serious equipment damage.

If the transfer switch requires reconfiguring, the TSC 800 controller will require reprogramming as well.

CAUTION!!!

All installation and/or service work performed must be done by qualified personnel only. Failure to do so may cause personal injury or death.

1.3. MOUNTING LOCATION/INSTALLATION

The TSC 800 transfer controller is designed for mounting directly onto a transfer switch door. Considerations should be given for the following:

The controller should be installed in a dirt free, dry location away from extreme heat sources.

The LCD window should be installed at an optimum height for operator viewing.

Adequate space should be provided around the rear of the TSC 800 circuit board for control wiring.

Verify that the intended AC voltage input to the controller does not exceed the maximum allowable level on the control panel door as per the applicable control panels certification standard.

The TSC 800 controller can be installed onto a door of a transfer switch using two different methods:

- The first method requires a special door cutout for the LCD display and LED's as shown in FIGURE 5. This mounting method requires the Lexan faceplate to be mounted directly onto the door of the transfer switch enclosure via its adhesive tape on the rear of the Lexan. The controller must be disassembled to mount on the door, then re-assembled.
- The second method of controller mounting requires a factory supplied adapter faceplate as shown in FIGURE 6. This method only requires a simple large rectangular hole to be cut out of the door as shown in FIGURE 6(a). The controller is then inserted into this hole and the faceplate is mounted on top of the door with studs as supplied with the faceplate. Note: #8-32 AWG nuts will be required to attach the faceplate to the door.

1.4. AC VOLTAGE SENSING INPUT

The TSC 800 can accept direct AC voltage sensing inputs on the generator and utility supplies from 120-600Vac (nominal). **Note:** Direct input voltage sensing can only be used when the system utilizes a 3 phase, 4 wire distribution system which has the neutral conductor *solidly* grounded. For 3 phase, 3 wire systems (i.e. no neutral) or high voltage systems, potential transformers must be used. Refer to FIGURES 1-4 for voltage sensing connections.

1.5. AC CONTROL POWER INPUT

The TSC 800 is factory supplied for either 115Vac or 230Vac (nominal) control power input voltage. Independent AC control power is required from both utility and generator supplies. AC control power is utilized for internal TSC 800 control circuits and external control device loads. The TSC 800 requires approximately 12VA AC power for internal control circuits. The maximum external load is limited by output contact ratings (i.e. 10A resistive, 120VAC). Total AC control power requirements for each supply must be determined by adding both internal and external load requirements.

1.6. FOUR POSITION TEST SWITCH INPUTS (FTS4)

The function of the Four Position Test Switch Input is to allow operators to select various operating scenarios for test or maintenance purposes, in addition to the use of the faceplate mounted pushbuttons.

NOTE: When an external FTS4 switch is used, the TSC 800 operation as selected from the faceplate pushbuttons will be overridden.

OFF: Disables the engine start output from the transfer switch. If the primary source is available, and within normal limits, the TSC 800 will initiate a transfer to the primary source. The transfer switch will not automatically transfer to the secondary (alternate) source should the primary source fail.

AUTO: All automatic functions are enabled.

ENGINE START: (No load test) An engine start signal will be initiated and will remain on until the FTS4 is placed in another position. The engine will start if the engine's auto start controller is in the "Auto" mode. If the primary source fails in this mode, and the secondary source is within parameters, the TSC 800 will initiate a transfer to the secondary source.

TEST: (Full load test) A primary source failure is simulated and an engine start signal will be initiated. When the secondary source is within normal limits, the TSC 800 will initiate a transfer to the secondary source. The system will remain in this state until the FTS4 is placed in another position or the secondary supply fails. Upon a secondary supply failure, if the primary supply is available, the TSC 800 will initiate a transfer to the primary supply.

1.7. OUTPUTS

The TSC 800 provides the following types of output circuits:

Engine Start Contact	Isolated Form C contact (10A, 120VAC Resistive)
Programmable Output Contact	Isolated Form C contact (10A, 120VAC Resistive)
Transfer to Utility Output	120VAC ¹ , 10A (Resistive) powered output contact
Transfer to Generator output	120VAC ¹ , 10A (Resistive) powered output contact
Pre/post-transfer to utility	120VAC ¹ , 3A (Resistive) powered output contact
Pre/post-transfer to generator	120VAC ¹ , 3A (Resistive) powered output contact
Load on utility	120VAC ¹ , 3A (Resistive) powered output contact
Load on generator	120VAC ¹ , 3A (Resistive) powered output contact


¹ **Note:** Output voltage is dependent upon AC control power input voltage (i.e. 120VAC or 230VAC nominal).

Interposing relays are required between the TSC 800 outputs and the end device if loads exceed the output current rating.

Transient suppression devices are required for all inductive devices sharing wiring or if physically located near the transfer switch controller.

For AC operated relays or solenoids, use a suitably rated metal oxide varistor (MOV) or capacitor/resistor suppressor.

TSC 800



VOLTAGE INPUTS

600VAC L-L, 347VAC L-N
 480VAC L-L, 277VAC L-N
 380VAC L-L, 220VAC L-N
 208VAC L-L, 120VAC L-N


▽ PT REQUIRED FOR TRANSFER SWITCH MECHANISM POWER (MUST BE SIZED TO SUIT POWER REQUIREMENTS).

FIG:1

3Ø, 4W 208/380/480/600VAC DIRECT SENSING

NOTE: UTILITY VOLTAGE SENSING AND CONTROL POWER SHOWN ONLY.

TSC 800



VOLTAGE INPUTS


240VAC L-L, 120VAC L-N

FIG:2

1Ø, 3W 120/240VAC DIRECT SENSING

NOTE: UTILITY VOLTAGE SENSING SHOWN ONLY.

TSC 800



SECONDARY PT VOLTAGE

208VAC L-L, 120VAC L-N
 120VAC L-L, 69VAC L-N


▽ PT REQUIRED FOR TRANSFER SWITCH MECHANISM POWER (MUST BE SIZED TO SUIT POWER REQUIREMENTS)

FIG:3

3Ø, 4W WYE PT's

NOTE: UTILITY VOLTAGE SENSING SHOWN ONLY.

TSC 800



SECONDARY PT VOLTAGE

120VAC L-L [NO NEUTRAL]

NOTE: ØB IS GROUNDED

▽ PT REQUIRED FOR TRANSFER SWITCH MECHANISM POWER (MUST BE SIZED TO SUIT POWER REQUIREMENTS)

FIG:4

3Ø, 3W DELTA PT's

NOTE: UTILITY VOLTAGE SENSING SHOWN ONLY.

1.8. EXTERNAL PANEL CONTROL WIRING

As a minimum, all control wiring shall conform to the local regulatory authority on electrical installations. Specific wire sizes for typical circuits (of distances up to 100ft (30m)¹) are as follows:

Utility or Generator Voltage Sensing	#14 AWG (2.5mm ²)
Transfer output signals	#14 AWG (2.5mm ²)
Remote Start Contact for Engine Controls	#14 AWG (2.5mm ²)

¹ For distances exceeding 100 ft. (30m) consult Thomson Technology Inc.

1.9. REMOTE START CONTACT FIELD WIRING

Field wiring of a remote start contact from a transfer switch to a control panel should conform to the following guidelines to avoid possible controller malfunction and/or damage.

- 1.8.1. Remote start contact wires (2 #14 AWG (2.5mm²)) should be run in a separate conduit.
- 1.8.2. Avoid wiring near AC power cables to prevent pick-up of induced voltages.
- 1.8.3. An interposing relay may be required if field wiring distance is excessively long (i.e. greater than 100 feet (30m)) and/or if a remote contact has a resistance of greater than 5.0 ohms.
- 1.8.4. The remote start contact must be voltage free (i.e. dry contact). The use of a "powered" contact will damage the transfer controller.

1.10. COMMUNICATION CABLE

Communication cable wiring from the controller's com port must be suitably routed to protect it from sources of electrical interference. Guidelines for protection against possible electrical interference are as follows:

- Use high quality, 8 conductor shielded cable only with drain wire grounded at the controller end only.
- Route the communication cable at least 3 M (10') away from sources of electrical noise such as variable speed motor drives, high voltage power conductors, UPS systems, transformers, rectifiers etc.
- Use separate, dedicated conduit runs for all communication cables. Do not tightly bundle communication cables together in the conduit. Conduit should be ferromagnetic type near sources of possible electrical interference. The entire length of conduit should be grounded to building earth ground.

- When communication cables must cross over low or high voltage AC power conductors, the communication cables must cross at right angles and not in parallel with the conductors.

For additional information on protection against electrical interference, contact TTI factory.

1.11. FACEPLATE MOUNTING DIMENSIONS

Refer to FIGURE 5 for the TSC 800 faceplate mounting dimension information.




FIGURE 5

REFER TO:

G:\ENGINEER\PRODUCTS\TSC800\85611.VSD




FIGURE 6: ADAPTER FACEPLATE




FIGURE 6(a): DOOR CUTOUT FOR ADAPTER FACEPLATE


G:\ENGINEER\PRODUCTS\TSC800\852620.VSD DRAWING SCALE = .333:1

1.12. DIELECTRIC TESTING

Do not perform any high voltage dielectric testing on the transfer switch with the TSC 800 controller connected into the circuit as serious damage will occur to the controller. All AC control fuses or control circuit isolation plugs connected to the TSC 800 must be removed if high voltage dielectric testing is performed on the transfer switch.

2. DESCRIPTION

The TSC 800 controller utilizes microprocessor-based design technology which provides high accuracy for all voltage sensing and timing functions. The TSC 800 is factory configured to control all the operational functions and display features of the automatic transfer switch. All standard and optional control features of the TSC 800 are fully programmable from the front panel LCD display and are security password protected. The LCD display screen prompts are in plain English, providing a user-friendly operator interface with many display options available. The microprocessor design provides many standard features which were previously only available as add-on optional features. The TSC 800 controller consists of two parts; a Lexan faceplate which is mounted externally on the transfer switch door, and a printed circuit board (PCB) which is mounted inside the transfer switch door.



FULL FILENAME

DATE 00/07/13 2:20 PM

G:\ENGINEER\PRODUCTS\TSC800\852614.VSD

FIGURE 7


2.1. LEXAN FACEPLATE

The Lexan faceplate is shown as in FIGURE 7. The Lexan pushbuttons are connected to the main PCB via plug-in ribbon cable. The main features of the Lexan faceplate are described as follows with reference to FIGURE 7.

- ① LCD viewing window. The LCD display is mounted on the main PCB which is visible from the lexan faceplate.
- ② EXIT push-button. The EXIT function is used to scroll backwards through the status menus or programming prompts to the previous item. The EXIT function is used to "exit" the programming menu by holding this button down for approximately 2 seconds while in the programming mode.
- ③ DECREMENT push-button. The DECREMENT function is used to change a programming value while in the programming mode. When this push-button is held down, the displayed value will be "decremented" to a lower value as desired. Note: The longer the push-button is held down, the faster the value will be decremented.
- ④ INCREMENT push-button. The INCREMENT function is used to change a programming value while in the programming mode. When this push-button is held down, the displayed value will be "incremented" to a higher value as desired. Note: The longer the push-button is held down, the faster the value will be incremented.
- ⑤ ENTER push-button. The ENTER function is used to scroll forwards through the status menus or programming prompts to the next item. The ENTER function is used to "enter" a programming or test mode as well as accepting changed programming values. **Note:** In the programming mode, the longer the ENTER push-button is held down, the faster the next menu prompt will appear.
- ⑥ Load on Utility supply LED light viewing window
- ⑦ Load on Generator supply LED light viewing window

2.1.1. LAMP TEST

A lamp test feature is provided to test all LED lights as well as the LCD display. To activate the lamp test feature, simultaneously push the INCREMENT and DECREMENT push-buttons. All LED's and LCD display should illuminate for approximately 2 seconds then return to their original status.



©ENGINEERPRODUCTSITSC8008526136 V50

FIGURE 8

2.2. PRINTED CIRCUIT BOARD

The printed circuit board (PCB) is shown in FIGURE 8. The PCB contains the following user interface items:

2.2.1. VOLTAGE SELECTION

The voltage selection is made via two connector plugs which are located on the PCB and are identified as HD1 and HD2. A different plug assembly is required for a voltage change.

The TSC 800 is factory configured for a specific power supply voltage input as designated by voltage header plugs labeled as follows:

115V - designates a 115V power supply input voltage

230V - designates a 230V power supply input voltage

2.2.2. TERMINAL BLOCKS

Three terminal blocks are located on the PCB as follows:

TB1 high voltage sensing terminal block (120-600VAC)

WARNING

Voltage sensing circuits are capable of lethal voltages while energized. Standard safety procedures should be followed and be performed by qualified personnel only. Failure to do so may cause personnel injury and/or death.

TB2 transfer control terminal block for output contacts and low voltage inputs

TB3 transfer control terminal block for 115/230v input and output circuits

2.2.3. DIAGNOSTIC LED'S

The TSC 800 controller provides four diagnostic LED lights which are mounted on the rear of the printed circuit board as per FIGURE 8. Their functions are described as follows:

WATCHDOG This LED flashes on and off at irregular intervals which indicates that the microprocessor is functioning normally.

TRANSFER TO UTILITY This LED is illuminated whenever the TSC 800 is initiating a Transfer to Utility signal.

TRANSFER TO GEN This LED is illuminated whenever the TSC 800 is initiating a Transfer to Generator signal.

ENGINE START This LED is illuminated whenever the TSC 800 is initiating a Engine Start signal.

Note: All LED's will be illuminated whenever a lamp test function is performed.

2.2.4. COMMUNICATION PORT

A communication port is provided to interconnect to a remote communication system for remote monitoring and control of the transfer switch. Refer to section 3 for additional information.

2.2.5. CONTRAST ADJUSTMENT

A contrast adjustment potentiometer is located on the PCB and is factory set for ambient temperatures of 15° to 30° Celsius. For different ambient temperatures, consult the factory for adjustment procedures.

3. REMOTE COMMUNICATION OPTION

The TSC 800 transfer switch controller is available with an optional remote communication feature. The remote communication feature allows a TSC 800 controller to be monitored and controlled from a remote location via serial communication link to a personal computer (PC). PC's may be connected locally via serial communication cable to the TSC 800 or remotely via modem and telephone systems. Remote communication can be via customer supplied equipment or with an external communication interface module (CIM) as manufactured by Thomson Technology Inc.


NOTE:

The CIM module may be located in the engine control panel provided the maximum distance between the CIM and TSC 800 controller is not exceeded as per the following information. Refer to the installation section of this manual for further information.

The CIM module utilizes an internal modem and contains Modbus™ protocol to interface with different remote monitoring software programs. Refer to separate literature for detailed information on the CIM module. The TSC 800 remote communication option must be ordered and be factory enabled prior to shipment. The communication feature cannot be user enabled once shipped from the factory.


The TSC 800 communication port utilizes a RS422 data transmission signal which is directly interconnected to the CIM module via 8 conductor, shielded cable with plug-in RJ45 connectors. Refer to FIGURES 9 & 10 for detailed information on direct connected or remote connected PC applications with CIM module.

™ Trademarks belong to their respective parties.



G:\ENGINEER\PRODUCTS\TSC800\852621.VSD

FIGURE #9 TSC 800 WITH CIM MODULE & DIRECT CONNECTED PC (RS232)



G:\ENGINEER\PRODUCTS\TSC800\852622.VSD


FIGURE #10 TSC 800 WITH CIM MODULE & REMOTE CONNECTED PC

The TSC 800 RS422 communication port allows multiple TSC 800 controllers to be directly interconnected together to form a single network system. Up to 10 TSC 800 controllers may be interconnected to a single CIM module.

NOTE:

TSC 800 controllers and MEC 20 engine/generator controllers may be interconnected together via the same communication network provided the maximum number of controllers and interconnection distances are not exceeded. For additional information, refer to associated product instruction manuals.

Each TSC 800 controller is programmed with a unique communication node address number for the remote communication system to reference. The network system may be connected to a local PC or to a remote PC via telephone system and CIM module. Refer to FIGURE #11 for a typical TSC 800 network system with CIM module.




G:\ENGINEER\PRODUCTS\TSC800\852623.VSD

FIGURE #11 NETWORKED TSC 800 INTERCONNECTION DIAGRAM

4. TSC 800 DISPLAY MENUS

The TSC 800 contains a Liquid Crystal Display (LCD) which is visible on the front faceplate. The LCD has preprogrammed display menus which may be selected by pressing the *ENTER* or *EXIT* push-buttons in succession until the desired menu is displayed. The display menu types and order in which they are programmed are as follows:



4.1. SYSTEM TIME MENU

The system time menu is used to show current system time. The TSC 800 controller uses its internal time clock to reference when an automatic exercising operation (if pre-programmed) is to occur. To change the system time, refer to the "time clock adjustment" section of this manual.

LCD DISPLAY

SYSTEM TIME
MON^⓪ 12:24:31^⓪


^⓪ Displays the day of the week

^⓪ Displays the current time in hours (24-hour clock): hour: min: seconds

4.2. MANUAL TEST MENU

The Manual Test Menu may be selected to initiate a specific type of generator testing operation.

The test sub-menus are organized as follows:



LCD DISPLAY

MAN TEST MENU
NO[Ⓞ]

[Ⓞ] Displays two messages which may be toggled between YES or NO by pressing the *INCREMENT* push-button. Their functions are described as follows:

- **NO** Testing operation menu is disabled when NO is displayed.
- **YES** Testing operation menu is enabled when YES is displayed and entered.

The following Test Mode options are provided:

- NONE** Testing operation is disabled when the NONE prompt is selected. To terminate a previously-set testing mode, select NONE and enter.
- OFF LOAD** When OFF LOAD prompt is selected and entered, the generator will immediately start and operate off load and will not permit a load transfer. **Note:** If the utility supply fails during this test mode, the generator will transfer on load. The generator will remain running until a different test mode is selected and entered.
- ON LOAD** When the ON LOAD prompt is selected and entered, the generator will immediately start and transfer on load. The generator will remain on load until a different test mode is selected and entered.

4.3. TSC 800 PROGRAM MENU

The programming menu is used to access the TSC 800's programmable functions such as time delays, voltage/frequency setpoints, calibration and time clock adjustments.

Access to the programming sub-menus can only be obtained with a security password number. The sub menus are organized as follows:



LCD DISPLAY



⓪ Displays two messages which may be toggled between YES or NO by pressing the INCREMENT push-button. Their functions are described as follows:

- NO Programming sub-menus are disabled when NO is displayed.
- YES Programming sub-menus are enabled when YES is displayed.


4.4. SYSTEM STATUS MENU

The system status menu provides the operator with information as to current status of both the utility and generator supplies.

NOTE:

The system status menu screen may be momentarily replaced with a time delay countdown screen when a transfer sequence is initiated. The display will automatically return to the previous menu following expiry of the timing sequence.

The system status sub-menus are organized as follows:



LCD DISPLAY

UTIL	NORMAL [Ⓞ]
GEN	OFF [Ⓞ]

[Ⓞ] Displays utility supply status conditions. There are three status conditions:

NORMAL	Load is on the utility supply and the utility's voltage and frequency is normal.
FAILED	Utility supply voltage and/or frequency is outside the nominal programmed limits(i.e. failed condition).
READY	Load is on the generator supply and the utility supply is ready to transfer. This is a temporary condition due to either a test mode being selected or during a utility return time delay.

[Ⓞ] Displays generator supply status conditions. There are seven status conditions as follows:

OFF	Load is on the utility supply and the generator is off, ready to start upon utility failure condition.
NORMAL	The generator is running due to a failed utility supply.
OFF LOAD TEST	The generator is running off load due to manually initiated test mode via the front-panel push-buttons or exercise timer mode.
ON LOAD TEST	The generator is running on load due to a manually initiated test mode via the front panel push-buttons or an automatic test mode as programmed in the time clock exercising menu.
GEN SW OFF	The four position test switch has been set to the OFF position, disabling generator starting and transferring operation.
FAILED	Generator is signaled to operate, however its voltage and/or frequency is outside the nominal programmed limits (i.e. failed condition).
STARTING	Engine start signal has been initiated, and the TSC 800 sensors are waiting for generator voltage to build up.

4.5. TIMER COUNTDOWN MENUS

Timer countdown menus are automatically displayed when a specific time delay function occurs during a transfer sequence. When a time delay begins, the LCD display will indicate the time delay function name (e.g. GEN. START DELAY) and the current time remaining in the countdown sequence. When the timing function is complete, the LCD display will automatically change to either the next timing sequence countdown display or return to the original system status screen menu.

LCD DISPLAY

**GEN START
DELAY[⊙] 45 SEC[⊙]**

- ⊙ Displays specific time delay function currently in operation
- ⊙ Displays current time in seconds or minutes that are left in the specific timing sequence.

NOTE:

During a timer countdown sequence, a different display menu may be selected by pressing the *ENTER* push-button.

The following timer countdown screens are provided:

GEN START DELAY	XX SEC.
GEN WARMUP DELAY	XX SEC.
GEN COOLING DELAY	XX SEC.
UTILITY RETURN DELAY	XX MIN.
PRE-TRANSFER DELAY	XX SEC.
NEUTRAL DELAY	XX SEC.
POST-TRANSFER DELAY	XX SEC.

4.6. UTILITY SUPPLY MENU

The utility supply menu allows the operator to view the utility supply voltage and frequency values.

LCD DISPLAY

UTIL	60:0 HZ ^⓪
600 ^⓪	600 ^⓪ 600 ^⓪

- ⓪ Displays utility supply frequency in hertz (HZ). The frequency is displayed with a resolution of 1/10 of a hertz.
- ⓪ Displays utility supply voltage as follows:
 - 3-phase system: LINE TO LINE VOLTAGE--Phases A to B
 - 1-phase system: LINE TO LINE VOLTAGE--Phases L1 to L2
- ⓪ Displays utility supply voltage as follows:
 - 3-phase system: LINE TO LINE VOLTAGE--Phases B to C
 - 1-phase system: LINE TO NEUTRAL VOLTAGE--Phases L1-N
- ⓪ Displays utility supply voltage as follows:
 - 3-phase system: LINE TO LINE VOLTAGE--Phases C-A
 - 1-phase system: LINE TO NEUTRAL VOLTAGE--Phases L2-N

4.7. GENERATOR SUPPLY MENU

The generator supply menu allows the operator to view the generator supply voltage and frequency values.

LCD DISPLAY

GEN	60.0 HZ ^⓪
600 ^⓪	600 ^⓪ 600 ^⓪

- ⓪ Displays generator supply frequency in hertz (HZ). The frequency is displayed with a resolution of 1/10 of a hertz.
- ⓪ Displays generator supply voltage as follows:
 - 3-phase system: LINE TO LINE VOLTAGE--Phases A to B
 - 1-phase system: LINE TO LINE VOLTAGE--Phases L1 to L2
- ⓪ Displays generator supply voltage as follows:
 - 3-phase system: LINE TO LINE VOLTAGE--Phases B to C
 - 1-phase system: LINE TO NEUTRAL VOLTAGE--Phases L1-N

® Displays generator supply voltage as follows:

- 3-phase system: **LINE TO LINE VOLTAGE--Phases C-A**
- 1-phase system: **LINE TO NEUTRAL VOLTAGE--Phases L2-N**

5. OPERATING INSTRUCTIONS

To operate the TSC 800 controller and associated transfer switch using the front faceplate push-buttons, refer to the following detailed operating instruction sub-section descriptions.

5.1. DISPLAY MENUS

The TSC 800 will display the last selected menu when normal utility or generator power is energized. To view another display menu, press the *ENTER* push-button to scroll to the next available menu. Keep pressing the *ENTER* push-button to view the complete list of display menu types. Note that the menu list will automatically loop back to the first menu item when the end of the list is reached.

5.2. TESTING INSTRUCTIONS

To perform a testing operation on the transfer switch using the front faceplate push-buttons, follow the procedure listed below.

To Initiate the Test Mode:

- Using the *ENTER* push-button, scroll to the **MANUAL TEST MENU**.
- Using the *INCREMENT* push-button, select the **YES** message and press the *ENTER* push-button.
- Using the *INCREMENT* push-button, select the **ON LOAD** or **OFF LOAD** test option as required.
- Press the *ENTER* push-button.

To Exit the Test Mode:

- Using the *ENTER* push-button, scroll to the **MANUAL TEST MENU**.
- Using the *INCREMENT* push-button, select the **YES** message and press the *ENTER* push-button.
- Using the *INCREMENT* push-button, select the **NONE** test option.
- Press the *ENTER* push-button.

5.3. TIME CLOCK ADJUSTMENT

To adjust the TSC 800 controllers internal time clock, follow the detailed procedure below. Note normal utility or generator power must be energized to enable adjustment.

- Using the *ENTER* push-button, scroll to the **PROGRAM MENU**.
- Using the *INCREMENT* push-button, select the **YES** message and press the *ENTER* push-button.
- Press the *ENTER* push-button when the **PASSWORD** message is displayed.
- Using the *INCREMENT* push-button, select the current **day** of the week message and press the *ENTER* push-button.
- Using the *INCREMENT* push-button, select the current **hour** of the day (i.e. 24 hour clock) and press the *ENTER* push-button.
- Using the *INCREMENT* push-button, select the current **minute** of the day (i.e. 60 minute) and press the *ENTER* push-button.
- Press the **EXIT** push-button and hold for 2 seconds to exit the time clock adjustment mode.

6. PROGRAMMING INSTRUCTIONS

Access to the programmable parameters of the **TSC 800** Transfer Controller is via a security password number. Three levels of security passwords are provided as described below:

READ ONLY MODE

User can view the programmable parameters only and cannot change any values.

The Factory default number for the read-only level is one (1).

READ / WRITE MODE

User can view and modify any programming parameter as required. The Factory default number for the read/write level is two (2).

MASTER READ / WRITE MODE

User can view/modify any programming parameter as well as view/modify the security password level numbers. Consult TTI factory for master password number if required.

To enter the programming mode, follow the procedure as shown:



Select the Program Menu by scrolling through the display menus using the ENTER push-button. When displayed, use the INCREMENT push-button to select the YES prompt and push the ENTER button .



Use the INCREMENT or DECREMENT push-buttons to ramp the displayed number up or down to the desired password access number. Press the ENTER push-button when the correct number is displayed.

NOTE:
If an invalid number is entered, programming access will be limited to time clock adjustment only. To exit the programming mode, press the EXIT push-button and hold for two seconds until the display changes.

When the programming mode is accessed, the programming parameters will be displayed in the same order as the Programming Sheet. To skip over parameters that do not require changes, push and hold the ENTER push-button until the desired function is displayed. The EXIT push-button may be used to scroll backwards through the programming parameter loop.

To change a programmed parameter, use the INCREMENT or DECREMENT push-buttons to scroll through the available options or to adjust a value up or down to the desired number. When the desired option or number is displayed, press the ENTER push-button to accept the new value.

NOTE:
If the programming mode is terminated before the last change had been entered, the programming parameter will remain unchanged.

To exit the programming mode, press the EXIT push-button and hold for two seconds until the display changes.

6.1. EXERCISE TIMER

The TSC 800 controller has a built-in exercise timer which is programmable for a single occurrence, weekly exercise time period. The timer is fully programmable for time of day, duration of the test and type of test mode (i.e. On-Load or Off-Load). The exercise timer utilizes the TSC 800's internal time clock for referencing all timing functions. The time clock has a 10 minute power reserve feature to retain correct time settings during short duration utility power failures. Note: During any On-Load exercise test mode, the transfer switch will automatically re-transfer back to the utility supply if the generator set fails. To program the exercise timer prompts refer to the following descriptions:

6.1.1. AUTO TEST START DAY

Select the day of the week (e.g. Monday, Tuesday, etc.) that the generator set is to be started to begin its exercise period.

6.1.2. AUTO TEST START HOUR

Select the hour of the day (i.e. 0-23 hour) that the generator set is to be started to begin its exercise period.

6.1.3. AUTO TEST START MINUTE

Select the minute of the day (i.e. 0-59 minutes) that the generator set is to be started to begin its exercise period.

6.1.4. AUTO TEST STOP DAY

Select the day of the week (e.g. Monday, Tuesday, etc.) that the generator set is to be stopped following its exercise period.

6.1.5. AUTO TEST STOP HOUR

Select the hour of the day (i.e. 0-23 hour) that the generator set is to be stopped following its exercise period.

6.1.6. AUTO TEST STOP MINUTE

Select the minute of the day (i.e. 0 to 59 minutes) that the generator set is to be stopped following its exercise period.

6.1.7. AUTO TEST MODE

Select type of test mode desired. Three test modes are available as follows:

6.1.7.1. NONE: The exercise test mode is de-activated.

6.1.7.2. OFF LOAD: The generator set will be started during the exercise period but no transfer will occur. Note: the generator will transfer on load if the utility supply fails during the test period.

6.1.7.3. ON LOAD: The generator will be started and will transfer on load. Note: During the On-Load exercise test mode, the transfer switch will automatically re-transfer back to the utility supply if the generator set fails.

6.2. SYSTEM CONFIGURATION

The TSC 800 controller provides a flexible control system to allow specific operation for a wide range of power distribution types. To program the system configuration, refer to the following descriptions:

6.2.1. NODE ADDRESS

Set to unique controller address (1-255) for use with network connected TSC 800 controllers.

Note: This programming feature is only active when the remote communication option is enabled. Default setting for single TSC 800 applications is 1.

6.2.2. SYSTEM VOLTAGE

Set to nominal system voltage as expressed in "phase to phase" voltage.(i.e. a 347/600 volt system would be entered as "600". The programmable range of values is 120V-15,000V.

6.2.3. VOLTAGE SENSING RATIO

For direct voltage sensing wiring connections from 208 to 600 volts, enter a ratio of "1:1". When potential transformers are utilized for voltage sensing, enter the transformer ratio.(e.g. when using a 600:120 transformer, enter a ratio of "5:1".

6.2.4. SYSTEM FREQUENCY

Set to nominal system frequency of either 50 HZ or 60 HZ.

6.2.5. SYSTEM PHASES

Set to match the power distribution system used on the automatic transfer switch (i.e. either 1 phase or 3 phase system).

6.3. VOLTAGE SENSING

The TSC 800 controller provides 3-phase overvoltage and undervoltage sensing on both utility and generator supplies. Each sensor is individually programmable for pickup and dropout voltage setpoints (i.e. adjustable hysteresis) in addition to transient time delay settings. To program the voltage sensing features, refer to the following descriptions:

6.3.1. UTILITY UNDERVOLTAGE SENSOR PICKUP

Set to the desired utility undervoltage setpoint at which the internal voltage sensor *picks up* (i.e. the sensor energizes to a normal state when the utility voltage is above the setpoint). The setting is entered based on a phase to phase voltage value within a range of 70% to 100% of nominal system voltage. Note: The difference between the pickup and dropout setting is considered the dead band or hysteresis value.

6.3.2. UTILITY UNDERVOLTAGE SENSOR DROPOUT

Set to the desired utility undervoltage setpoint at which the internal voltage sensor *drops out* (i.e. the sensor de-energizes to an abnormal state when the utility voltage is below the setpoint). The setting is entered based on a phase to phase voltage value within a range of 70% to 100% of nominal system voltage. Note: The difference between the pickup and dropout setting is considered the dead band or hysteresis value.

6.3.3. UTILITY UNDERVOLTAGE SENSOR TIME DELAY (DROPOUT)

Select the desired utility undervoltage time delay setting. The setting is entered in seconds within a range of 0 to 10 seconds. If no delay is required, set this time delay to zero.

6.3.4. UTILITY OVERVOLTAGE SENSOR PICKUP

Note: This feature is optional and must be factory ordered with the transfer switch. Set to the desired utility overvoltage setpoint at which the internal voltage sensor *picks up* (i.e. the sensor energizes to an abnormal state when the utility voltage is above the setpoint). The setting is entered based on a phase to phase voltage value within a range of 100% to 130% of nominal system voltage. **Note:** The

difference between the pickup and dropout setting is considered the dead band or hysteresis value.

6.3.5.UTILITY OVERVOLTAGE SENSOR DROPOUT

Note: This feature is optional and must be factory ordered with the transfer switch. Set to the desired utility overvoltage setpoint at which the internal voltage sensor *drops out* (i.e. the sensor de-energizes to a normal state when the utility voltage is below the setpoint). The setting is entered based on a phase to phase voltage value within a range of 100% to 130% of nominal system voltage. **Note:** The difference between the pickup and dropout setting is considered the dead band or hysteresis value.

6.3.6.UTILITY OVERVOLTAGE SENSOR TIME DELAY (PICKUP)

Note: This feature is optional and must be factory ordered with the transfer switch. Select the desired utility overvoltage time delay setting. The setting is entered in seconds within a range of 0 to 5 seconds. If no delay is required, set this time delay to zero.

6.3.7.GENERATOR UNDERVOLTAGE SENSOR PICKUP

Set to the desired generator undervoltage setpoint at which the internal voltage sensor *picks up* (i.e. the sensor energizes to a normal state when the generator voltage is above the setpoint). The setting is entered based on a phase to phase voltage value within a range of 70% to 100% of nominal system voltage. **Note:** The difference between the pickup and dropout setting is considered the dead band or hysteresis value.

6.3.8.GENERATOR UNDERVOLTAGE SENSOR DROPOUT

Set to the desired generator undervoltage setpoint at which the internal voltage sensor *drops out* (i.e. the sensor de-energizes to an abnormal state when the generator voltage is below the setpoint). The setting is entered based on a phase to phase voltage value within a range of 70% to 100% of nominal system voltage. **Note:** The difference between the pickup and dropout setting is considered the dead band or hysteresis value.

6.3.9.GENERATOR UNDERVOLTAGE SENSOR TIME DELAY (DROPOUT)

Select the desired generator undervoltage time delay setting. The setting is entered in seconds within a range of 0 to 10 seconds. If no delay is required, set this time delay to zero.

6.3.10.GENERATOR OVERVOLTAGE SENSOR PICKUP

Note: This feature is optional and must be factory ordered with the transfer switch. Set to the desired generator overvoltage setpoint at which the internal voltage sensor *picks up* (i.e. the sensor energizes to an abnormal state when the generator voltage is above the setpoint). The setting is entered based on a phase to phase voltage value within a range of 100% to 130% of nominal system voltage. **Note:** The difference between the pick up and drop out setting is considered the dead band or hysteresis value.

6.3.11.GENERATOR OVERVOLTAGE SENSOR DROPOUT

Note: This feature is optional and must be factory ordered with the transfer switch. Set to the desired generator overvoltage setpoint at which the internal voltage sensor *drops out* (i.e. the sensor de-energizes to a normal state when the generator voltage is below the setpoint). The setting is entered based on a phase to phase voltage value within a range of 100% to 130% of nominal system voltage. **Note:** The difference between the pickup and dropout setting is considered the dead band or hysteresis value.

6.3.12.GENERATOR OVERVOLTAGE SENSOR TIME DELAY (PICKUP)

Note: This feature is optional and must be factory ordered with the transfer switch. Select the desired generator overvoltage time delay setting. The setting is entered in seconds within a range of 0 to 5 seconds. If no delay is required, set this time delay to zero.

6.4. FREQUENCY SENSING

The TSC 800 controller provides under and over frequency sensing on both utility and generator supplies. Each sensor is individually programmable for pickup and dropout frequency setpoints (i.e. adjustable hysteresis) in addition to transient time delay settings. To program the frequency sensing features, refer to the following descriptions:

6.4.1.UTILITY UNDERFREQUENCY SENSOR

Note: This feature is optional and must be factory ordered with the transfer switch.

Set to the desired utility underfrequency setpoint at which the internal frequency sensor *drops out* (i.e. the sensor de-energizes to an abnormal state when the utility frequency is below the setpoint). The setting is entered in a frequency value within a range of 40.0 to 60.0 HZ.

6.4.2.UTILITY UNDERFREQUENCY SENSOR TIME DELAY (DROPOUT)

Note: This feature is optional and must be factory ordered with the transfer switch.

Select the desired utility underfrequency time delay setting. The setting is entered in seconds within a range of 0 to 10 seconds. If no delay is required, set this feature to zero.

6.4.3.UTILITY OVERFREQUENCY SENSOR

Note: This feature is optional and must be factory ordered with the transfer switch.

Set to the desired utility overfrequency setpoint at which the internal frequency sensor *picks up* (i.e. the sensor energizes to an abnormal state when the utility frequency is above the setpoint). The setting is entered in a frequency value within a range of 50.0 to 70.0 HZ.

6.4.4.UTILITY OVERFREQUENCY SENSOR TIME DELAY (PICKUP)

Note: This feature is optional and must be factory ordered with the transfer switch.

Select the desired utility overfrequency time delay setting. The setting is entered in seconds within a range of 0 to 5 seconds. If no delay is required, set this time delay to zero.

6.4.5.GENERATOR UNDERFREQUENCY SENSOR

Set to the desired generator underfrequency setpoint at which the internal frequency sensor *drops out* (i.e. the sensor de-energizes to an abnormal state when the generator frequency is below the setpoint). The setting is entered in a frequency value within a range of 40.0 to 60.0 HZ.

6.4.6.GENERATOR UNDERFREQUENCY SENSOR TIME DELAY (DROPOUT)

Select the desired generator underfrequency time delay setting. The setting is entered in seconds within a range of 0 to 10 seconds. If no delay is required, set this time delay to zero.

6.4.7.GENERATOR OVERFREQUENCY SENSOR

Set to the desired generator overfrequency setpoint at which the internal frequency sensor *picks up* (i.e. the sensor energizes to an abnormal state when the generator frequency is above the setpoint). The setting is entered in a frequency value within a range of 50.0 to 70.0 HZ.

6.4.8.GENERATOR OVERFREQUENCY SENSOR TIME DELAY (PICKUP)

Select the desired generator overfrequency time delay setting. The setting is entered in seconds within a range of 0 to 5 seconds. If no delay is required, set this time delay to zero.

6.5. TIME DELAYS

The TSC 800 provides many time delay control functions which are individually programmable as described below.

6.5.1.GENERATOR START DELAY

The generator (i.e. engine) start signal will be initiated following expiry of the start delay timer. Select desired generator start delay time in seconds. The range of setting is 0 to 60 seconds. If no delay is required, set this time delay to zero. **Note:** The output relay is normally energized when the utility power is within limits and de-energizes to start the generator.

6.5.2.GENERATOR WARM UP DELAY

A transfer to the generator supply will be initiated when the voltage and frequency are within limits and upon expiry of the warm up delay timer. Select desired generator warm up delay time in seconds. The range of settings is 0 to 1800 seconds. If no delay is required, set this time delay to zero.

6.5.3.GENERATOR COOLDOWN DELAY

The generator (i.e. engine) cooldown period will be initiated once the load has transferred from the generator supply. The engine start signal will be maintained until expiry of the cooldown delay timer. Select desired generator cooldown delay time in minutes. The range of settings is 0 to 30 minutes. If no delay is required, set this time delay to zero.

6.5.4.UTILITY RETURN DELAY

The utility return delay period will be initiated once the utility supply has returned within limits following a utility power failure condition. Select desired utility return delay time in minutes. The range of settings is 0 to 30 minutes. If no delay is required, set this time delay to zero. **Note:** The utility return delay will be bypassed should the generator fail during the time delay period.

6.5.5. PRE/POST TRANSFER DELAY (LDC)

Note: This feature is optional and must be factory ordered with the transfer switch.

The pre/post transfer delay period will be initiated upon a impending transfer in either direction. The pre/post transfer output relays will momentarily energize (as per the pre-transfer time setting) prior to a load transfer and will stay energized until the post-transfer delay time period expires. Select desired pre- and post-delay time in seconds. The range of settings is 0 to 30 seconds. If no delay is required, set this time delay to zero.

6.5.6. MINIMUM FIND NEUTRAL DELAY

The TSC 800 transfer control logic includes an adjustable time delay feature to compensate for the minimum time that a transfer switch mechanism takes to operate when load sensing voltage is lost due to a power failure. This time delay is set to a time value which is approximately *equal* to the time that the transfer mechanism typically takes to operate from one supply position to the neutral position. This feature is factory set to match the specific transfer switch mechanism as supplied with the unit.

6.5.7. MAXIMUM FIND NEUTRAL DELAY

The TSC 800 transfer control logic includes an adjustable time delay feature to compensate for the maximum time that a transfer switch mechanism takes to operate when load sensing voltage is used to detect the neutral position. This time delay is set to a time value which is *greater than* the typical time that the transfer mechanism typically takes to operate from one supply position to the neutral position. When the TSC 800 controller is supplied from the factory with a TTI transfer mechanism the Maximum Find Neutral Delay will be factory set for correct operation. Note: When the TSC 800 controller is supplied loose without a transfer mechanism, the Maximum Find Neutral Delay function must be user set for correct operation with the applicable transfer mechanism. For applications using electrically held contactors, the Maximum Find Neutral Delay function must typically be set for 0.0 seconds for correct operation.

6.5.8. NEUTRAL DELAY TIMER (NDT)

The neutral delay time period will be initiated once both of the supply breakers are open during a transfer sequence. Select desired neutral delay time in seconds. The range of settings is 0 to 60 seconds. If no delay is required, set

this time delay to zero. **Note:** The neutral delay will be bypassed should the operating power fail for longer than the timer setting.

NOTE: Model TS 890 transfer switches may use NDT timers which are external to the TSC 800 controller. In this case the TSC 800 NDT function is not used and must be set at zero seconds. Refer to TS 890 drawings for further information.

6.5.9. MAXIMUM TRANSFER TIME

The TSC 800 transfer control logic includes an adjustable time delay feature to detect when a transfer switch mechanism fails to operate. This time delay is set to a time value which is *greater than* the typical time that the transfer mechanism typically takes to operate from one supply position to the opposite supply position. This feature is factory set to match the specific transfer switch mechanism as supplied with the unit.

6.5.10. TRANSFER FAIL

Note: This feature is user selectable in TSC 800 software version 1.3 (or greater).

The TSC 800 transfer controller contains a "TRANSFER SWITCH FAIL" detection feature which is user selectable for enabled or disabled. Operating logic is as follows:

DISABLED: The "TRANSFER SWITCH FAIL" feature is disabled in this mode. The TSC 800 controller will not verify that the transfer mechanism has operated correctly.

ENABLED: The "TRANSFER SWITCH FAIL" feature is enabled in this mode. The TSC 800 controller will verify that the transfer switch mechanism has correctly transferred or is in the correct position. If the TSC 800 controller senses an abnormal condition (i.e. load voltage and transfer switch position contacts are not at the normal levels or states) the controller will activate an alarm message to the LCD display. The transferring output signals from the controller will be de-activated and the engine start contact will remain in its last state (before the alarm was activated). The controller has an internal 30 sec. timer to provide an alarm bypass to enable correct operating sequences. To reset the alarm condition, the "lamp test" function must be activated.

Note: The "TRANSFER SWITCH FAIL" feature will typically be enabled when supplied from the factory.

6.5.11. TRANSFER LOGIC

Note: This feature is user selectable in TSC 800 software version 1.3 (or greater).

The TSC 800 transfer controller software contains a user selectable function for type of transfer logic required for specific applications. This feature will be factory set for specific type of application and transfer mechanism used and therefore should not require resetting.

Selectable operating logic is as follows:

MAINTAINED: The TSC 800 transfer output signals will stay in the 'MAINTAINED' energized state upon a source failure and will only de-energize when the alternate source becomes available. Note: the transfer output signal will de-energize upon a total loss of source voltage.

DROPOUT: The TSC 800 transfer output signals will "DROPOUT" (or de-energize) when the connected source goes out of normal voltage or frequency limits. The transfer output signal will only re-energize when the connected source returns to normal limits.

6.5.12. PROGRAMMABLE OUTPUT

The TSC 800 transfer controller includes a standard programmable output relay signal. The output relay energizes when one of the following conditions occurs. Note: Only one function may be programmed.

LOAD ON UTILITY	Output energizes when the utility transfer breaker is closed and load voltage is present.
LOAD ON GENERATOR	Output energizes when the generator transfer breaker is closed and load voltage is present.
LOAD SHED	Output energizes when generator is on load and frequency drops below underfrequency setpoint for longer than the time delay setting.
UTILITY SUPPLY NORMAL	Output relay energizes when the utility supply is energized and is within voltage and frequency limits.
FAIL TO TRANSFER	Output relay energizes when the transfer switch mechanism fails to operate for the given time delay period. Note: This output feature is only activated when the "TRANSFER SWITCH FAIL" feature is enabled. (Refer to programming item #11 for additional information.)

6.5.13.UTILITY FAIL CALLOUT

When the remote communication option is enabled, this programming prompt will appear. This feature may be enabled or disabled by programming selection.

ENABLED: The controller will initiate a callout signal via the communication port to a remote connected device when a Utility (Source 1) power failure is detected. The callout signal will be reset when the Utility (Source 1) power returns to normal condition.

DISABLED: The controller will not initiate a callout when a Utility (Source 1) power failure is detected.

6.5.14.LOAD ON GENERATOR CALLOUT

When the remote communication option is enabled, this programming prompt will appear. This feature may be enabled or disabled by programming selection.

ENABLED: The controller will initiate a callout signal via the communication port to a remote connected device when the load is connected to the generator supply. The callout signal will be reset when the load transfers back to the utility supply.

DISABLED: The controller will not initiate a callout when the load transfers to the generator supply.

6.5.15.TRANSFER FAIL CALLOUT

When the remote communication option is enabled, this programming prompt will appear. This feature may be enabled or disabled by programming selection.

ENABLED: The controller will initiate a callout signal via the communication port to a remote connected device when the transfer switch fails to operate. The callout signal will only reset when the "Fail to Transfer" alarm is manually reset via local push-buttons or with the remote communication software.

DISABLED: The controller will not initiate a callout when a "Fail to Transfer " alarm condition occurs.

6.5.16.AUTO TEST CALLOUT

When the remote communication option is enabled, this programming prompt will appear. This feature may be enabled or disabled by programming selection.

ENABLED: The controller will initiate a callout signal via the communication port to a remote connected device when a automated test is initiated at the controller via the TSC 800 exercise time clock. The callout signal will reset when the Auto Test condition is terminated.

DISABLED: The controller will not initiate a callout an Auto Test condition is initiated.

6.5.17.MAN TEST CALLOUT

When the remote communication option is enabled, this programming prompt will appear. This feature may be enabled or disabled by programming selection.

ENABLED: The controller will initiate a callout signal via the communication port to a remote connected device when a manual test is initiated at the controller via the TSC 800 push-buttons or external control switch. The callout signal will reset when the Manual Test condition is terminated.

DISABLED: The controller will not initiate a callout a Manual Test condition is initiated.

6.5.18.SWITCH NOT IN AUTO CALLOUT

When the remote communication option is enabled, this programming prompt will appear. This feature may be enabled or disabled by programming selection.

ENABLED: The controller will initiate a callout signal via the communication port to a remote connected device when the TSC 800 controllers' operating mode is "Not In Auto" as locally selected via the four position external control switch. The callout signal will reset when the control switch is returned to the Auto position.

DISABLED: The controller will not initiate a callout if the TSC 800 controller is not in the Auto mode of operation.

6.5.19.BACK LIGHT TIME OUT

The LCD back light function can be programmed so it will automatically turn off after the selected time.

6.6. VOLTAGE SENSING CALIBRATION

Voltage sensing calibration for the utility, generator and load sensors is provided by the TSC 800 software program. All voltage sensing circuits are factory calibrated to specific voltage levels prior to shipment of the transfer switch.

Should field calibration of any voltage sensing circuit be required, the following procedure may be used.

WARNING

Voltage sensing circuits are capable of lethal voltages while energized. Standard safety procedures should be followed and be performed by qualified personnel only. Failure to do so may cause personnel injury and/or death.

6.6.1. GENERAL

6.6.1.1. To access the TSC 800's software programming loop for programming, the program menu must be selected, the YES prompt entered and read/write security password level (or higher) must be entered.

6.6.1.2. Once the programming loop has been accessed, scroll to the voltage calibration screens as shown below.

UTIL AB[®] ZERO[®]

99[®] 600V[®]

- ① Displays the selected supply's phase voltages to be calibrated.
- ② Displays the type of calibration function, either ZERO or SPAN.
- ③ Displays the calibration correction factor number (0-255) used to obtain the correct voltage reading. **Note:** To correctly calibrate any of the voltage sensors, the ZERO function must be calibrated before the SPAN function.
- ④ Displays the actual voltage measurement which will be the same value as shown on the TSC 800 display menus for generator or utility supplies. This voltage reading may be calibrated higher or lower by changing the correction factor number.

NOTE:

To accurately calibrate the TSC 800's voltage sensors, an external test voltage meter is required, with an accuracy of 0.5% or better.

6.6.2. UTILITY VOLTAGE CALIBRATION

To adjust the utility supply voltage sensors, perform the following procedure:

6.6.2.1. ZERO CALIBRATION

- 6.6.2.1.1. Energize the generator supply to power up the controller and de-energize the utility supply.
- 6.6.2.1.2. Scroll to the desired utility supply voltage phases with the **ZERO** function selected.
- 6.6.2.1.3. Use the INCREMENT or DECREMENT push-buttons to adjust the correction factor number while observing the displayed voltage level. Adjust the correction factor number to obtain 0 VAC on the display.
- 6.6.2.1.4. With the correct voltage displayed, press the ENTER push-button to accept the correction factor number. Record the correction factor number on the TSC 800 programming sheet for future reference if required.
- 6.6.2.1.5. Repeat the above procedure for all remaining phases of the utility supply as required.

6.6.2.2. SPAN CALIBRATION

- 6.6.2.2.1. Energize the utility supply voltage to the controller at nominal level. The generator supply may be de-energized.
- 6.6.2.2.2. In the programming mode, scroll to the desired utility supply voltage phases with the **SPAN** function selected.
- 6.6.2.2.3. Connect an external AC voltmeter of adequate voltage range and accuracy to the TSC 800 controller terminal associated with the voltage phases to be calibrated.

WARNING

Voltage sensing circuits are capable of lethal voltages while energized. Standard safety procedures should be followed and be performed by qualified personnel only. Failure to do so may cause personal injury and/or death.

6.6.2.2.4. Use the INCREMENT or DECREMENT push-buttons to adjust the correction factor number while observing the displayed voltage level on the TSC 800. Adjust the correction factor number to obtain an identical voltage reading as measured with the external AC voltmeter.

6.6.2.2.5. With the correct voltage displayed, press the *ENTER* push-button to accept the correction factor number. Record the correction factor number on the TSC 800 programming sheet for future reference if required.

6.6.2.2.6. Repeat the above procedures for all remaining phases of the utility supply as required.

NOTE:

Once the span calibration setting has been done, do not readjust any zero calibration points as this will cause incorrect voltage readings.

7. TSC 800 PROGRAMMING DATA SHEETS

SUMMARY CONFIGURATION DATA SHEET		
WORK ORDER #: _____	REV. _____	REV. DATE: _____
INITIATED BY: _____	CUSTOMER: _____	DEFAULT PROGRAM #: _____
DATE: _____	PROJECT: _____	TPS VERSION: _____
NOTES: _____		
SYSTEM AC INPUTS		
SYSTEM AC VOLTS: _____	PHASES: _____	FREQUENCY: _____
CONTROL TYPE: _____		
DIGITAL DISPLAY FEATURES		
<input type="checkbox"/> GEN AC VOLTAGE	<input type="checkbox"/> UTILITY AC VOLTAGE	<input type="checkbox"/> TIME CLOCK
<input type="checkbox"/> GEN AC FREQUENCY	<input type="checkbox"/> UTILITY AC FREQUENCY	
STANDARD FEATURES	OPTIONAL FEATURES	
<input type="checkbox"/> Level 1 Features <ul style="list-style-type: none"> • 3 phase Utility (SRC 1) Undervoltage Sensing • 3 phase Gen (SRC 2) Undervoltage Sensing • Generator Underfrequency Sensing • Generator Start Delay Timer • Generator Cooldown Timer • Utility Return Timer • Generator Warm-up Timer • Automatic Exercise Timer • Neutral Delay Timer <input type="checkbox"/> Level 2 Features (Level 1 features plus) <ul style="list-style-type: none"> • Utility/Gen 3 Phase Overvoltage Sensing • Utility Overfrequency Sensing <input type="checkbox"/> Level 3 Features (Level 1 & 2 features plus) <ul style="list-style-type: none"> • Dual Source Logic 	<input type="checkbox"/> Utility/Gen 3 Phase Overvoltage Sensing <input type="checkbox"/> Utility Overfrequency Sensing <input type="checkbox"/> Load Disconnect Contact <input type="checkbox"/> COM Port Enabled	
STANDARD PROGRAMMABLE OUTPUTS		
OUTPUT NAME	OUTPUT FUNCTION	
<input type="checkbox"/> Programmable Output	<input type="checkbox"/> Load on Gen	
_____	<input type="checkbox"/> Load on Utility	
_____	<input type="checkbox"/> Utility Normal	
_____	<input type="checkbox"/> Transfer Fail	
_____	<input type="checkbox"/> Load Shed	


8. MAIN MENU PROGRAMMING SHEET

PARAMETER	VALUE	RANGE	
		LOW	HIGH
CONTROL TYPE	STD ATS / DUAL SOURCE		
AUTO TEST START DAY			
AUTO TEST START HOUR			
AUTO TEST START MIN			
AUTO TEST STOP DAY			
AUTO TEST STOP HOUR			
AUTO TEST STOP MIN			
AUTO TEST MODE			
COMMUNICATION OPTION	<i>toggle enabled/disabled</i>		
NODE ADDRESS	#	1	255
SYSTEM VOLTAGE	[***VAC]		
VOLTAGE SENSING RATIO	RATIO	1	208
SYSTEM FREQUENCY	[***Hz]	0	125
SYSTEM PHASES	TOGGLE 1 OR 3 PHASE		
UTILITY UNDERVOLTAGE SENSORS PICK UP	[***VAC]	0	0
UTILITY UNDERVOLTAGE SENSORS DROP OUT	[***VAC]	0	0
UTILITY UNDERVOLTAGE SENSORS TIME DELAY DROP OUT	[**SEC]	0	10
UTILITY OVERVOLTAGE SENSORS PICK UP	[***VAC]	0	0
UTILITY OVERVOLTAGE SENSORS DROP OUT	[***VAC]	0	0
UTILITY OVERVOLTAGE SENSORS TIME DELAY PICK UP	[**SEC]	0	5
UTILITY UNDER FREQUENCY SENSORS	[***Hz]	48.0	60.0
UTILITY UNDER FREQUENCY SENSORS TIME DELAY DROPOUT	[**SEC]	0	10
UTILITY OVER FREQUENCY SENSORS	[***Hz]	50.0	70.0
UTILITY OVER FREQUENCY SENSORS TIME DELAY PICK UP	[**SEC]	0	5
GENERATOR UNDERVOLTAGE SENSORS PICK UP	[***VAC]	0	0
GENERATOR UNDERVOLTAGE SENSORS DROP OUT	[***VAC]	0	0
GENERATOR UNDERVOLTAGE SENSORS TIME DELAY DROP OUT	[**SEC]	0	10
GENERATOR OVERVOLTAGE SENSORS PICK UP	[***VAC]	0	0
GENERATOR OVERVOLTAGE SENSORS DROP OUT	[***VAC]	0	0
GENERATOR OVERVOLTAGE SENSORS TIME DELAY PICK UP	[**SEC]	0	5
GENERATOR UNDER FREQUENCY SENSORS	[***Hz]	40.0	60.0
GENERATOR UNDER FREQUENCY SENSORS TIME DELAY DROP OUT	[**SEC]	0	10
GENERATOR OVER FREQUENCY SENSORS	[***Hz]	50.0	70.0
GENERATOR OVER FREQUENCY SENSORS TIME DELAY PICK UP	[**SEC]	0	5
GENERATOR START DELAY	[****SEC]	0	60
GENERATOR WARM-UP DELAY	[****SEC]	0	1800
GENERATOR COOLDOWN DELAY	[****MIN]	0	30
UTILITY RETURN DELAY	[****MIN]	0	30
PRE-TRANSFER DELAY	[****SEC]	0	30
MIN FIND NEUTRAL DELAY	[****SEC]	0.0	20.0
MAX FIND NEUTRAL DELAY	[****SEC]	0.0	20.0
NEUTRAL DELAY	[****SEC]	0	60
MAX TRANSFER TIME	[****SEC]	0	30
POST TRANSFER DELAY	[****SEC]	0	30
TRANSFER FAIL	<i>toggle enabled/disabled</i>		
TRANSFER OUTPUT LOGIC	<i>toggle maintained/dropout</i>		
PROGRAMMABLE OUTPUT	A=LD ON UTIL,B= LD ON GEN,C= LD SHED,D= UTIL NORMAL,E=FAIL TO XFER	A	E
UTILITY FAIL CALLOUT	<i>toggle enabled/disabled</i>		
LOAD ON GEN CALLOUT	<i>toggle enabled/disabled</i>		
TRANSFER FAIL CALLOUT	<i>toggle enabled/disabled</i>		
AUTO TEST CALLOUT	<i>toggle enabled/disabled</i>		
MAN TEST CALLOUT	<i>toggle enabled/disabled</i>		
SWITCH NOT IN AUTO CALLOUT	<i>toggle enabled/disabled</i>		
BACKLIGHT	[****SEC]	0	999

9. CALIBRATION DATA SHEET

UTILITY PHASE A - B ZERO	["CORRECTION FACTOR"]	0 to 255
UTILITY PHASE A - B SPAN	["CORRECTION FACTOR"]	0 to 255
UTILITY PHASE B - C ZERO	["CORRECTION FACTOR"]	0 to 255
UTILITY PHASE B - C SPAN	["CORRECTION FACTOR"]	0 to 255
UTILITY PHASE C - A ZERO	["CORRECTION FACTOR"]	0 to 255
UTILITY PHASE C - A SPAN	["CORRECTION FACTOR"]	0 to 255
GENERATOR PHASE A - B ZERO	["CORRECTION FACTOR"]	0 to 255
GENERATOR PHASE A - B SPAN	["CORRECTION FACTOR"]	0 to 255
GENERATOR PHASE B - C ZERO	["CORRECTION FACTOR"]	0 to 255
GENERATOR PHASE B - C SPAN	["CORRECTION FACTOR"]	0 to 255
GENERATOR PHASE C - A ZERO	["CORRECTION FACTOR"]	0 to 255
GENERATOR PHASE C - A SPAN	["CORRECTION FACTOR"]	0 to 255
LOAD PHASE A - B ZERO	["CORRECTION FACTOR"]	0 to 255
LOAD PHASE A - B SPAN	["CORRECTION FACTOR"]	0 to 255

10. TSC 800 TYPICAL CONNECTION DIAGRAM



FULL FILENAME

REVISED 00-07-14 09:40 AM

G:\ENGINEER\PRODUCTS\TSC800\852616.VSD

11. TSC 800 SPECIFICATIONS

- **POWER SUPPLY:**
 - 115 or 230 VAC nominal (+10% -30%)
 - 50/60 Hz
 - 100ma nominal (no external load connected)

- **VOLTAGE SENSING:**
 - Direct 120-600 VAC nominal, single or three phase
 - 50/60 Hz
 - +/- 0.5% accuracy of setting @ 25°C

- **OPERATING TEMPERATURE:**
 - 0°C to +50°C

- **OUTPUT CONTACTS (Form C, 10A, 120/240VAC resistive)**
 - Engine start
 - Programmable function (not available with dual source system logic)

- **OUTPUT SIGNALS (120/240 VAC resistive load)**
 - Transfer to utility 10A
 - Transfer to generator 10A
 - Pre/post-transfer to utility 3A
 - Pre/post-transfer to generator 3A
 - Load on utility 3A
 - Load on generator 3A

12. TROUBLESHOOTING

A number of problems can cause the TSC 800 controller not to function properly. Refer to the following list of typical problems. Consult the factory for any detailed information or for any problems not listed.

CAUTION!!!

Before opening the enclosure to perform any service task, it is imperative to isolate the transfer switch from any possible source of power. Failure to do so may result in serious personal injury or death due to electrical shock.

Service procedures must be undertaken by qualified personnel only!

Symptom

Possible Causes

- | | |
|--|--|
| <ul style="list-style-type: none"> - Will not re-transfer to utility source upon restoration | <ul style="list-style-type: none"> - a test mode has been activated (check TSC 800 status LCD display) - utility voltage or frequency is outside the pre-programmed limits (check utility source for adequate voltage & frequency) - a loose control connection - faulty contactor auxiliary contact - defective utility contactor coil - defective TSC 800 controller (verify output signals with circuit board mounted diagnostic LED's) |
| <ul style="list-style-type: none"> - Will not transfer to generator source upon failure of utility source | <ul style="list-style-type: none"> - generator set not producing enough voltage/frequency or output circuit breaker open - warm-up time delay function has not timed out yet (verify TSC 800 timer setting) - a loose control connection - faulty contactor auxiliary contact - defective generator contactor coil - defective TSC 800 controller (verify output signals with circuit board mounted diagnostic LED's) |
| <ul style="list-style-type: none"> - Transfer to generator source without a power failure in the utility source | <ul style="list-style-type: none"> - a test mode has been activated (check TSC 800 status LCD display) - defective TSC 800 controller (verify output signals with circuit board mounted diagnostic LED's) - loose or broken wire to the utility voltage sensing terminals on the TSC 800 controller |
| <ul style="list-style-type: none"> - Generator does not start up or stop when it should | <ul style="list-style-type: none"> - verify remote engine control panel is set for automatic mode |
| <ul style="list-style-type: none"> - No time delay when there should be | <ul style="list-style-type: none"> - verify time delay function in the TSC 800 program setting as per programming sheets as supplied with the transfer switch |
| <ul style="list-style-type: none"> - Engine runs for no apparent reason | <ul style="list-style-type: none"> - Verify the TSC 800 has not been set for test operation. If yes, select manual test "NONE". Refer to section 4.2 for operation details |

DEFECTIVE COMPONENTS

Return defective components to Thomson Technology Inc. for repair. **Be sure to advise model and serial number of the transfer switch.**

Level 1 Read only

Level 2 Read/write

Level 3 Read/write security Passwords



TSC800

MICROPROCESSOR TRANSFER SWITCH CONTROLLER

SUMMARY CONFIGURATION DATA SHEET

TSC800 Software ver. 1.6

WORK ORDER #: 00000-00-01-TS REV.: 0 REV. DATE: 99/05/10
 INITIATED BY: Admin CUSTOMER: TEST DEFAULT PROGRAM: P1-480
 DATE: 99/05/10 PROJECT NAME: DEFAULT / P1-480 TPS VER: C
 NOTES:

SYSTEM AC INPUTS

SYSTEM AC VOLTS: 480 PHASES: 3 FREQUENCY: 60 CONTROL TYPE: STD ATS

DIGITAL DISPLAY FEATURES

- GENERATOR AC VOLTAGE UTILITY AC VOLTAGE TIME CLOCK
- GENERATOR FREQUENCY UTILITY FREQUENCY

STANDARD FEATURES

OPTIONAL FEATURES

- Level 1 Features
- 3 Phase Utility (Src 1) Undervoltage Sensing
 - 3 Phase Generator (Src 2) Undervoltage Sensing
 - Generator Underfrequency Sensing
 - Generator Start Delay Timer
 - Generator Cooldown Delay Timer
 - Utility Return Delay Timer
 - Generator Warm-up Timer
 - No Load Test PB Function
 - Full Load Test PB Function
 - Automatic Exercise Test Clock

STANDARD PROGRAMMABLE OUTPUTS

OUTPUT NAME	OUTPUT TYPE
Programmable Output #1	LD on Gen



Main Menu Program

TSC800 TSC800 Software ver. 1.6

WORK ORDER: 00000-00-01-TS

REVISION #: 0

REVISION DATE: 99/05/10

START DATE: 99/05/10

START BY: Admin

DEFAULT PROGRAM: P1-480

TPS VERSION: C

CUSTOMER: TEST
PROJECT: DEFAULT / P1-480
PRODUCT: TSC800

Control Type:	STD ATS	
Auto Test Start Day:	Sunday	<input type="checkbox"/> Day of the week
Auto Test Start Hour:	00	<input type="checkbox"/> 00 - 23 hours
Auto Test Start Minute:	00	<input type="checkbox"/> 00 - 59 minutes
Auto Test Stop Day:	Sunday	<input type="checkbox"/> Day of the week
Auto Test Stop Hour:	00	<input type="checkbox"/> 00 - 23 hours
Auto Test Stop Minute:	00	<input type="checkbox"/> 00 - 59 minutes
Auto Test Mode:	None	<input type="checkbox"/> None, On Load, or Off Load
Communications Option:	No	<input type="checkbox"/> Toggle between Yes/No
Node Address:		<input type="checkbox"/> <- Option not enabled
System Voltage:	480	<input type="checkbox"/> Line to line voltage 120 - 15000
Voltage Sensing Ratio:	1	<input type="checkbox"/> 1 - 208 ratio number
System Frequency:	60	<input type="checkbox"/> Toggle between 50/60 Hz
System Phases:	3	<input type="checkbox"/> Toggle between 1 & 3 phase
Util UV Pickup:	432	<input type="checkbox"/> 335 - 480 VAC
Util UV Dropout:	384	<input type="checkbox"/> 335 - 480 VAC
Util UV Dropout Delay:	1	<input type="checkbox"/> 0 - 10 seconds
Util OV Pickup:		<input type="checkbox"/> <- Option not enabled
Util OV Dropout:		<input type="checkbox"/> <- Option not enabled
Util OV Pickup Delay:		<input type="checkbox"/> <- Option not enabled
Util UF:		<input type="checkbox"/> <- Option not enabled
Util UF Dropout Delay:		<input type="checkbox"/> <- Option not enabled
Util OF:		<input type="checkbox"/> <- Option not enabled
Util OF Pickup Delay:		<input type="checkbox"/> <- Option not enabled
Gen UV Pickup:	432	<input type="checkbox"/> 335 - 480 VAC
Gen UV Dropout:	384	<input type="checkbox"/> 335 - 480 VAC
Gen UV Dropout Delay:	5	<input type="checkbox"/> 0 - 10 seconds
Gen OV Pickup:		<input type="checkbox"/> <- Option not enabled
Gen OV Dropout:		<input type="checkbox"/> <- Option not enabled
Gen OV Pickup Delay:		<input type="checkbox"/> <- Option not enabled
Gen UF:	57.0	<input type="checkbox"/> 0 - 125 Hz
Gen UF Dropout Delay:	5	<input type="checkbox"/> 0 - 10 seconds
Gen OF:	63.0	<input type="checkbox"/> 0 - 125 Hz
Gen OF Pickup Delay:	5	<input type="checkbox"/> 0 - 5 seconds
Gen Start Delay:	2	<input type="checkbox"/> 0 - 60 seconds
Gen Warmup Delay:	2	<input type="checkbox"/> 0 - 1800 seconds
Gen Cooldown Delay:	2	<input type="checkbox"/> 0 - 30 minutes
Util Return Delay:	2	<input type="checkbox"/> 0 - 30 minutes
Pre Transfer Delay:		<input type="checkbox"/> <- Option not enabled
Min Find Neutral Time:	0.0	<input type="checkbox"/> 0.0 - 20.0 seconds
Max Find Neutral Time:	6.0	<input type="checkbox"/> 0.0 - 20.0 seconds
Neutral Delay:		<input type="checkbox"/> <- Option not enabled
Max Transfer Time:	15	<input type="checkbox"/> 0 - 30 seconds
Post Transfer Delay:		<input type="checkbox"/> <- Option not enabled
Transfer Fail:	Enabled	<input type="checkbox"/> Toggle between Enable/Disable

10 A/B
30 A/B/C



Main Menu Program
TSC800 TSC800 Software ver. 1.6

WORK ORDER: 00000-00-01-TS

REVISION #: 0

REVISION DATE: 99/05/10

START DATE: 99/05/10

START BY: Admin

DEFAULT PROGRAM: P1-480

TPS VERSION: C

CUSTOMER: TEST
 PROJECT: DEFAULT / P1-480
 PRODUCT: TSC800

Transfer Output Logic:	Maintain	<input checked="" type="checkbox"/>	Toggle between Dropout/Maintain
Programmable Output:	LD on Gen	<input type="checkbox"/>	Choose from list
Util Fail Callout:		<input type="checkbox"/>	<- Option not enabled
Load on Gen Callout:		<input type="checkbox"/>	<- Option not enabled
Transfer Fail Callout:		<input type="checkbox"/>	<- Option not enabled
Auto Test Callout:		<input type="checkbox"/>	<- Option not enabled
Main Test Callout:		<input type="checkbox"/>	<- Option not enabled
Switch Not in Auto Callout:		<input type="checkbox"/>	<- Option not enabled
Backlight:	120	<input type="checkbox"/>	0-999 seconds



Calibration
TSC800 TSC800 Software ver. 1.6

CUSTOMER: TEST
PROJECT: DEFAULT / P1-480
PRODUCT: TSC800

WORK ORDER: 00000-00-01-TS
REVISION #: 0
REVISION DATE: 99/05/10
START DATE: 99/05/10
START BY: Admin
DEFAULT PROGRAM: P1-480
TPS VERSION: C

Calibration:	
Util AB Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Util AB Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Util BC Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Util BC Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Util CA Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Util CA Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Gen AB Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Gen AB Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Gen BC Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Gen BC Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Gen CA Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Gen CA Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Load AB Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Load AB Span	<input type="checkbox"/> 0 - 255 Calibration correction number



TSC800

MICROPROCESSOR TRANSFER SWITCH CONTROLLER

SUMMARY CONFIGURATION DATA SHEET

TSC800 Software ver. 1.6

WORK ORDER #: 00000-00-02-TS REV.: 0 REV. DATE: 99/05/10
INITIATED BY: Admin CUSTOMER: TEST DEFAULT PROGRAM: P2-480
DATE: 99/05/10 PROJECT NAME: DEFAULT / P2 - 480 TPS VER: C
NOTES:

SYSTEM AC INPUTS

SYSTEM AC VOLTS: 480 PHASES: 3 FREQUENCY: 60 CONTROL TYPE: STD ATS

DIGITAL DISPLAY FEATURES

GENERATOR AC VOLTAGE UTILITY AC VOLTAGE TIME CLOCK
 GENERATOR FREQUENCY UTILITY FREQUENCY

STANDARD FEATURES

OPTIONAL FEATURES

Level 2 Features
3 Phase Utility (Src 1) Undervoltage Sensing
3 Phase Generator (Src 2) Undervoltage Sensing
Generator Underfrequency Sensing
Generator Start Delay Timer
Generator Cooldown Delay Timer
Utility Return Delay Timer
Generator Warm-up Timer
No Load Test PB Function
Full Load Test PB Function
Automatic Exercise Test Clock
Neutral Delay Timer
Utility (Src 1) Overvoltage Sensing (all phases)
Generator (Src 2) Overvoltage Sensing (all phases)
Utility (Src 1) Under/Over Frequency Sensing

STANDARD PROGRAMMABLE OUTPUTS

OUTPUT NAME	OUTPUT TYPE
Programmable Output #1	LD on Gen



Main Menu Program

TSC800 TSC800 Software ver. 1.6

WORK ORDER: 00000-00-02-TS

REVISION #: 0

REVISION DATE: 99/05/10

START DATE: 99/05/10

START BY: Admin

DEFAULT PROGRAM: P2-480

TPS VERSION: C

CUSTOMER: TEST
PROJECT: DEFAULT / P2 - 480
PRODUCT: TSC800

Control Type:	STD	ATS	
Auto Test Start Day:	Sunday	<input type="checkbox"/>	Day of the week
Auto Test Start Hour:	00	<input type="checkbox"/>	00 - 23 hours
Auto Test Start Minute:	00	<input type="checkbox"/>	00 - 59 minutes
Auto Test Stop Day:	Sunday	<input type="checkbox"/>	Day of the week
Auto Test Stop Hour:	00	<input type="checkbox"/>	00 - 23 hours
Auto Test Stop Minute:	00	<input type="checkbox"/>	00 - 59 minutes
Auto Test Mode:	None	<input type="checkbox"/>	None, On Load, or Off Load
Communications Option:	No	<input type="checkbox"/>	Toggle between Yes/No
Node Address:		<input type="checkbox"/>	<- Option not enabled
System Voltage:	480	<input type="checkbox"/>	Line to line voltage 120 - 15000
Voltage Sensing Ratio:	1	<input type="checkbox"/>	1 - 208 ratio number
System Frequency:	60	<input type="checkbox"/>	Toggle between 50/60 Hz
System Phases:	3	<input type="checkbox"/>	Toggle between 1 & 3 phase
Util UV Pickup:	432	<input type="checkbox"/>	335 - 480 VAC
Util UV Dropout:	384	<input type="checkbox"/>	335 - 480 VAC
Util UV Dropout Delay:	1	<input type="checkbox"/>	0 - 10 seconds
Util OV Pickup:	528	<input type="checkbox"/>	0 - 3000 VAC
Util OV Dropout:	518	<input type="checkbox"/>	0 - 3000 VAC
Util OV Pickup Delay:	2	<input type="checkbox"/>	0 - 5 seconds
Util UF:	58.0	<input type="checkbox"/>	0 - 125 Hz
Util UF Dropout Delay:	2	<input type="checkbox"/>	0 - 10 seconds
Util OF:	62.0	<input type="checkbox"/>	0 - 125 Hz
Util OF Pickup Delay:	2	<input type="checkbox"/>	0 - 5 seconds
Gen UV Pickup:	432	<input type="checkbox"/>	335 - 480 VAC
Gen UV Dropout:	384	<input type="checkbox"/>	335 - 480 VAC
Gen UV Dropout Delay:	5	<input type="checkbox"/>	0 - 10 seconds
Gen OV Pickup:	528	<input type="checkbox"/>	0 - 3000 VAC
Gen OV Dropout:	518	<input type="checkbox"/>	0 - 3000 VAC
Gen OV Pickup Delay:	2	<input type="checkbox"/>	0 - 5 seconds
Gen UF:	57.0	<input type="checkbox"/>	0 - 125 Hz
Gen UF Dropout Delay:	5	<input type="checkbox"/>	0 - 10 seconds
Gen OF:	63.0	<input type="checkbox"/>	0 - 125 Hz
Gen OF Pickup Delay:	5	<input type="checkbox"/>	0 - 5 seconds
Gen Start Delay:	2	<input type="checkbox"/>	0 - 60 seconds
Gen Warmup Delay:	2	<input type="checkbox"/>	0 - 1800 seconds
Gen Cooldown Delay:	2	<input type="checkbox"/>	0 - 30 minutes
Util Return Delay:	2	<input type="checkbox"/>	0 - 30 minutes
Pre Transfer Delay:		<input type="checkbox"/>	<- Option not enabled
Min Find Neutral Time:	0.0	<input type="checkbox"/>	0.0 - 20.0 seconds
Max Find Neutral Time:	6.0	<input type="checkbox"/>	0.0 - 20.0 seconds
Neutral Delay:	3	<input type="checkbox"/>	0 - 60 seconds
Max Transfer Time:	15	<input type="checkbox"/>	0 - 30 seconds
Post Transfer Delay:		<input type="checkbox"/>	<- Option not enabled
Transfer Fail:	Enabled	<input type="checkbox"/>	Toggle between Enable/Disable



Main Menu Program

TSC800 TSC800 Software ver. 1.6

WORK ORDER: 00000-00-02-TS

REVISION #: 0

REVISION DATE: 99/05/10

START DATE: 99/05/10

START BY: Admin

DEFAULT PROGRAM: P2-480

TPS VERSION: C

CUSTOMER: TEST
PROJECT: DEFAULT / P2 - 480
PRODUCT: TSC800

Transfer Output Logic: Maintain	<input type="checkbox"/>	Toggle between Dropout/Maintain
Programmable Output: LD on Gen	<input type="checkbox"/>	Choose from list
Util. Fail Callout:	<input type="checkbox"/>	< Option not enabled
Load on Gen Callout:	<input type="checkbox"/>	<- Option not enabled
Transfer Fail Callout:	<input type="checkbox"/>	< Option not enabled
Auto Test Callout:	<input type="checkbox"/>	<- Option not enabled
Man Test Callout:	<input type="checkbox"/>	< Option not enabled
Switch Not in Auto Callout:	<input type="checkbox"/>	<- Option not enabled
Backlight: 120	<input type="checkbox"/>	0-9999 seconds



Calibration
TSC800 TSC800 Software ver. 1.6

CUSTOMER: TEST
PROJECT: DEFAULT / P2 - 480
PRODUCT: TSC800

WORK ORDER: 00000-00-02-TS
REVISION #: 0
REVISION DATE: 99/05/10
START DATE: 99/05/10
START BY: Admin
DEFAULT PROGRAM: P2-480
TPS VERSION: C

Calibration:	
Util AB Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Util AB Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Util BC Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Util BC Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Util CA Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Util CA Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Gen AB Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Gen AB Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Gen BC Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Gen BC Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Gen CA Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Gen CA Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Load AB Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Load AB Span	<input type="checkbox"/> 0 - 255 Calibration correction number



TSC800

MICROPROCESSOR TRANSFER SWITCH CONTROLLER

SUMMARY CONFIGURATION DATA SHEET

TSC800 Software ver. 1.6

WORK ORDER #: 00000-00-03-TS

REV.: 0

REV. DATE: 99/05/10

INITIATED BY: Admin

CUSTOMER: TEST

DEFAULT PROGRAM: P3-480

DATE: 99/05/10

PROJECT NAME: DEFAULT / P3-480

TPS VER: C

NOTES:

SYSTEM AC INPUTS

SYSTEM AC VOLTS: 480

PHASES: 3

FREQUENCY: 60

CONTROL TYPE: Dual Prime

DIGITAL DISPLAY FEATURES

SRC #2 AC VOLTAGE

SRC #1 AC VOLTAGE

TIME CLOCK

SRC #2 FREQUENCY

SRC #1 FREQUENCY

STANDARD FEATURES

OPTIONAL FEATURES

Level 3 Features

Source 1 & 2 Under/Over Voltage Sensing (all phases)

Source 1 & 2 Under/Over Frequency Sensing

Source 1 & 2 Start Delay Timer

Source 1 & 2 Warmup Delay Timer

Source 1 & 2 Cooldown Delay Timer

Source 1 & 2 Return Delay Timer

No Load Test PB Function

Full Load Test PB Function

Automatic Exercise Test Clock

Preferential Source Selection



Main Menu Program

TSC800 TSC800 Software ver. 1.6

WORK ORDER: 00000-00-03-TS

REVISION #: 0

REVISION DATE: 99/05/10

START DATE: 99/05/10

START BY: Admin

DEFAULT PROGRAM: P3-480

TPS VERSION: C

CUSTOMER: TEST
PROJECT: DEFAULT / P3-480
PRODUCT: TSC800

ControlType:	Dual Prime		
Auto Test Start Day:	Sunday	<input type="checkbox"/>	Day of the week
Auto Test Start Hour:	00	<input type="checkbox"/>	00 - 23 hours
Auto Test Start Minute:	00	<input type="checkbox"/>	00 - 59 minutes
Auto Test Stop Day:	Sunday	<input type="checkbox"/>	Day of the week
Auto Test Stop Hour:	00	<input type="checkbox"/>	00 - 23 hours
Auto Test Stop Minute:	00	<input type="checkbox"/>	00 - 59 minutes
Auto Test Mode:	None	<input type="checkbox"/>	None, On Load, or Off Load
Communications Option:	No	<input type="checkbox"/>	Toggle between Yes/No
Node Address:		<input type="checkbox"/>	< - Option not enabled
System Voltage:	480	<input type="checkbox"/>	Line to line voltage 120 - 15000
Voltage Sensing Ratio:	1	<input type="checkbox"/>	1 - 208 ratio number
System Frequency:	60	<input type="checkbox"/>	Toggle between 50/60 Hz
System Phases:	3	<input type="checkbox"/>	Toggle between 1, 2, 3 phase
Src #1 UV Pickup:	432	<input type="checkbox"/>	335 - 480 VAC
Src #1 UV Dropout:	384	<input type="checkbox"/>	335 - 480 VAC
Src #1 UV Dropout Delay:	5	<input type="checkbox"/>	0 - 10 seconds
Src #1 OV Pickup:	528	<input type="checkbox"/>	0 - 3000 VAC
Src #1 OV Dropout:	518	<input type="checkbox"/>	0 - 3000 VAC
Src #1 OV Pickup Delay:	5	<input type="checkbox"/>	0 - 5 seconds
Src #1 UF:	57.0	<input type="checkbox"/>	0 - 125 Hz
Src #1 UF Dropout Delay:	5	<input type="checkbox"/>	0 - 10 seconds
Src #1 OF:	63.0	<input type="checkbox"/>	0 - 125 Hz
Src #1 OF Pickup Delay:	5	<input type="checkbox"/>	0 - 5 seconds
Src #2 UV Pickup:	432	<input type="checkbox"/>	335 - 480 VAC
Src #2 UV Dropout:	384	<input type="checkbox"/>	335 - 480 VAC
Src #2 UV Dropout Delay:	5	<input type="checkbox"/>	0 - 10 seconds
Src #2 OV Pickup:	528	<input type="checkbox"/>	0 - 3000 VAC
Src #2 OV Dropout:	518	<input type="checkbox"/>	0 - 3000 VAC
Src #2 OV Pickup Delay:	5	<input type="checkbox"/>	0 - 5 seconds
Src #2 UF:	57.0	<input type="checkbox"/>	0 - 125 Hz
Src #2 UF Dropout Delay:	5	<input type="checkbox"/>	0 - 10 seconds
Src #2 OF:	63.0	<input type="checkbox"/>	0 - 125 Hz
Src #2 OF Pickup Delay:	5	<input type="checkbox"/>	0 - 5 seconds
Src #1 Start Delay:	2	<input type="checkbox"/>	0 - 60 seconds
Src #1 Warmup Delay:	2	<input type="checkbox"/>	0 - 1800 seconds
Src #1 Cooldown Delay:	2	<input type="checkbox"/>	0 - 30 minutes
Src #2 Start Delay:	3	<input type="checkbox"/>	0 - 160 seconds
Src #2 Warmup Delay:	5	<input type="checkbox"/>	0 - 1800 seconds
Src #2 Cooldown Delay:	2	<input type="checkbox"/>	0 - 30 minutes
Src #1 Return Delay:	2	<input type="checkbox"/>	0 - 30 minutes
Src #2 Return Delay:	2	<input type="checkbox"/>	0 - 30 minutes
Pre Transfer Delay:		<input type="checkbox"/>	< - Option not enabled
Min Find Neutral Time:	0:0	<input type="checkbox"/>	0:0 - 20:0 seconds



Main Menu Program

TSC800 TSC800 Software ver. 1.6

WORK ORDER: 00000-00-03-TS

REVISION #: 0

REVISION DATE: 99/05/10

START DATE: 99/05/10

START BY: Admin

DEFAULT PROGRAM: P3-480

TPS VERSION: C

CUSTOMER: TEST
PROJECT: DEFAULT / P3-480
PRODUCT: TSC800

Max Find Neutral Time:	6.0	<input type="checkbox"/>	0.0 - 20.0 seconds
Neutral Delay:		<input checked="" type="checkbox"/>	< Option not enabled
Max Transfer Time:	15	<input type="checkbox"/>	0 - 30 seconds
Post Transfer Delay:		<input checked="" type="checkbox"/>	< Option not enabled
Transfer Fail:	Enabled	<input type="checkbox"/>	Toggle between Enable/Disable
Transfer Output Logic:	Maintain	<input type="checkbox"/>	Toggle between Dropout/Maintain
Programmable Output:		<input type="checkbox"/>	Option not Available
Util Fail Callout:		<input type="checkbox"/>	< Option not enabled
Load on Gen Callout:		<input type="checkbox"/>	<- Option not enabled
Transfer Fail Callout:		<input type="checkbox"/>	< Option not enabled
Auto Test Callout:		<input type="checkbox"/>	<- Option not enabled
Man Test Callout:		<input type="checkbox"/>	< Option not enabled
Switch Not in Auto Callout:		<input type="checkbox"/>	<- Option not enabled
Backlight:	120	<input type="checkbox"/>	0 - 999 seconds



Calibration
TSC800 TSC800 Software ver. 1.6

CUSTOMER: TEST
PROJECT: DEFAULT / P3-480
PRODUCT: TSC800

WORK ORDER: 00000-00-03-TS
REVISION #: 0
REVISION DATE: 99/05/10
START DATE: 99/05/10
START BY: Admin
DEFAULT PROGRAM: P3-480
TPS VERSION: C

Calibration:	
Src #1 AB Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Src #1 AB Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Src #1 BC Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Src #1 BC Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Src #1 CA Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Src #1 CA Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Src #2 AB Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Src #2 AB Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Src #2 BC Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Src #2 BC Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Src #2 CA Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Src #2 CA Span	<input type="checkbox"/> 0 - 255 Calibration correction number
Load AB Zero	<input type="checkbox"/> 0 - 255 Calibration correction number
Load AB Span	<input type="checkbox"/> 0 - 255 Calibration correction number



TS 850

AUTOMATIC TRANSFER SWITCHES

INSTALLATION, OPERATING & SERVICE MANUAL



PM042 Rev 5 00/12/01

TABLE OF CONTENTS

1. CAUTION!	1
2. NOTES TO INSTALLER	1
3. GENERAL DESCRIPTION	3
4. GENERAL THEORY OF OPERATION	3
4.1. STANDARD AUTOMATIC TRANSFER SWITCH	3
4.2. SERVICE ENTRANCE AUTOMATIC TRANSFER SWITCH	4
4.3. TEST CONDITION	7
5. TYPE A AND TYPE B DEFINITIONS	7
6. GENERAL NOTES ON SERVICING MECHANISM	8
7. STYLE "T" TRANSFER SWITCH MECHANISM - 400 - 1200 AMP	9
7.1. MANUAL OPERATION (or to reset a typical breaker)	9
8. STYLE "M" TRANSFER SWITCH MECHANISM - MAXIMUM 250 AMP	10
8.1. MANUAL OPERATION (or to reset a typical breaker)	10
9. RECOMMENDED MAINTENANCE (STYLE "T" & STYLE "M" MECHANISMS)	11
10. FRONT VIEW (TYPICAL) 3 / 4 POLE STYLE "T" TRANSFER MECHANISM	12
11. STYLE "T" CONFIGURATION OPTIONS	13
12. FRONT VIEW (TYPICAL) 3 / 4 POLE STYLE "M" - 100/150/250A	14
13. FRONT VIEW (TYPICAL) 3 POLE STYLE "M" - 200A	15
14. TROUBLESHOOTING (SEE CAUTION! ON PAGE #1)	16
15. CABLE TERMINAL INFORMATION	17
16. REQUIREMENTS FOR UPSTREAM CIRCUIT PROTECTIVE DEVICES	18
17. NOTES	19

1. CAUTION!

Before opening the transfer switch enclosure to perform any service task, or to manually transfer the mechanism, it is imperative to isolate the transfer switch from any possible source of power. Failure to do so may result in serious personal injury or death due to electrical shock.

Service procedures must be undertaken by qualified personnel only!

NOTE: - All information contained in this manual is for reference only and is subject to change without notice.

Contact Thomson Technology Inc. for clarification of current revisions or if in doubt about any matter relating to installation, operation or maintenance.

NOTE: This manual makes reference to a 600A transfer switch model TS 850-TCK-600 which was introduced in August of Year 2000. For 600A transfer switches manufactured prior to this date (e.g. Model TS 850-TCJ-600) refer to manual revision 0 – 3

For detailed information on Dual Source systems (Option LEV-3 refer to Information Supplement PM043.

2. NOTES TO INSTALLER

To ensure satisfactory installation of this equipment be sure to observe "Recommended Connection Tightness" and "Requirements for Upstream Circuit Protective Devices" located in this manual.

All mechanical and electrical connections must be checked for tightness prior to placing this equipment in service to ensure proper operation and to validate applicable warranty coverage.

If the transfer switch has programmable multi-tap voltage capability (refer to electrical schematic), confirm the transfer switch has been configured for the system voltage prior to installation.

Warning

Failure to confirm and match transfer switch voltage with the system voltage could cause serious equipment damage.

The voltage selections and connections are shown on the electrical schematics attached to each transfer switch. The factory default settings will be indicated on the calibration label attached on the inside of the enclosure door (supplied loose on open style models). A blank label is included to record the applicable settings if the configuration is changed from the factory default settings.

To change the transfer switch configuration the following must be accomplished:

- Change voltage taps of PT's to system voltage (refer to schematics)
- Change TSC 800 programming (refer to sections 6.2.2, 6.2.4, 6.2.5, 6.3, and 6.4 of the TSC 800 instruction manual). The following settings may require reprogramming (depending on options purchased):
 - System voltage
 - System frequency
 - System phase
 - Utility undervoltage pickup (typically 90% of system voltage)
 - Utility undervoltage dropout (typically 80% of system voltage)
 - Utility overvoltage pickup (typically 110% of system voltage)
 - Utility overvoltage dropout (typically 105% of system voltage)
 - Utility underfrequency (typically 95% of system frequency)
 - Utility overfrequency (typically 105% of system frequency)
 - Generator undervoltage pickup (typically 90% of system voltage)
 - Generator undervoltage dropout (typically 80% of system voltage)
 - Generator overvoltage pickup (typically 110% of system voltage)
 - Generator overvoltage dropout (typically 105% of system voltage)
 - Generator underfrequency (typically 95% of system frequency)
 - Generator overfrequency (typically 105% of system frequency)

Record any changed setting on the TSC 800 Programming Data Sheets for future reference.

Complete the blank calibration label and attach to the inside of the transfer switch enclosure door.

INSTALLATION OF OPEN TYPE TRANSFER SWITCHES - Please refer to the factory for additional information.

3. GENERAL DESCRIPTION

(See CAUTION! on Page #1)

The automatic transfer switch employs two moulded-case switching devices which may be:

- a) non-automatic circuit interrupters ("type A" transfer switch)
- b) automatic circuit interrupters with integral trip units; ("type B" transfer switch)

In this manual, the switching devices will be referred to as "breakers". The breakers are operated by a mechanism driven with an electric motor. The transfer switch provides automatic transfer of an electrical load to a standby power supply in the event of drop or loss of voltage of any or all phases of the primary power supply. Upon restoration of the primary supply, the electrical load is automatically retransferred to the primary power supply (after an adjustable time delay). All necessary control components for automatic transferring are located in the control compartment and on the enclosure door.

The transfer motor utilizes the power from the source to which the electrical load is being transferred. The mechanism provides a positive mechanical interlock to prevent both breakers from being closed at the same time. The mechanism is also designed to leave both breakers "trip free" in the closed position, permitting incorporation of overload and/or short-circuit protection in either or both breakers ("type B"). After tripping, the breaker of a "type B" transfer switch must be manually reset.

Note: For the purpose of this manual, the term UTILITY indicates the primary power, and the term GENERATOR indicates the standby power.

4. GENERAL THEORY OF OPERATION

4.1. STANDARD AUTOMATIC TRANSFER SWITCH

4.1.1. NORMAL OPERATION

When utility supply voltage drops below a preset nominal value (adjustable from 70% to 100% of nominal) on any phase, an engine start delay circuit will be initiated and the transfer to utility supply signal will be removed (i.e. contact opening). Following expiry of the engine start delay period (adjustable from 0 to 60 sec.) an engine start signal (contact closure) will be given.

Once the engine starts, the transfer switch controller will monitor the generator voltage and frequency levels. Once the generator voltage and frequency rises above preset values (adjustable from 70% to 100% of nominal), the engine warmup timer will be initiated. Once the warmup timer expires (adjustable from 0 to 60 sec.), the Transfer to Generator Supply signal (contact closure) will be given to the transfer switch mechanism. The load will then transfer from the utility supply to the generator supply via the motor driven mechanism. Note: An optional neutral delay timer circuit will delay the transfer sequence in the neutral position (i.e. both breakers open) until the selected time expires (adjustable from 0 to 60 sec.).

The generator will continue to supply the load until the utility supply has returned. The retransfer sequence is completed as follows: when the utility supply voltage is restored to above the preset values (adjustable from 70% to 100% of nominal) on all phases, a transfer return delay circuit will be initiated. Following expiry of the Transfer Return Timer (adjustable from 0 to 30 min.), the Transfer to Generator Supply signal will be removed (contact opening), then the Transfer to Utility Supply signal (contact closure) will be given to the transfer switch mechanism. The load will then retransfer the load from the generator supply back to the utility supply. Note: An optional neutral delay timer circuit will delay the transfer sequence in the neutral position (i.e. both breakers open) until the selected time expires (adjustable from 0 to 60 sec.).

An engine cooldown timer circuit will be initiated once the load is transferred from the generator supply. Following expiry of the cooldown delay period (adjustable from 0 to 30 min.), the engine start signal will be removed (contact opening) to initiate stopping of the generator set.

4.2. SERVICE ENTRANCE AUTOMATIC TRANSFER SWITCH

(Note: This applies only to service entrance transfer switches supplied with a Padlockable Disconnect Switch. Contact TTI for other types.)

4.2.1. NORMAL OPERATION

Under normal conditions, the load is energized from the utility supply through the closed utility transfer breaker. If the utility power fails, the generator will start and the load will be re-energized via the closed generator transfer breaker.

In the normal operating mode, the Service Disconnect switch shall be in the "energized" position.

4.2.2. SERVICE DISCONNECT PROCEDURE

To perform a service disconnect (i.e. to disconnect the utility and generator supplies), the following procedure is required:

1. Move the "Service Disconnect" control switch located on the door of the transfer switch to the "Disconnected" position.
2. Verify that the "Service Disconnected" pilot light is illuminated. *If the Light is illuminated, the service has been successfully disconnected and it is safe to perform any maintenance procedures as required.* In this condition, the transfer switch is in the neutral position, with both utility and transfer breakers open. The transfer switch will remain in this condition, regardless of condition of the utility and generator supplies (i.e. if the utility power fails, the generator will not receive a start condition, nor will the transfer switch move to the generator position). *If the Light is not illuminated, further procedures are required (refer to the following procedure #4).*
3. Attach safety lockout padlock to the "Service Disconnect" control switch to prevent unauthorized change in operating condition and verify transfer switch door is locked closed. If the door is not locked, turn and remove door key.
4. If the "Service Disconnected" pilot light is **not** illuminated, the service will **not** have been successfully disconnected and it is therefore **not** safe to perform any maintenance until the following additional procedures are performed:

Warning

Qualified personnel must undertake the following procedures only! Failure to do so may result in serious personal injury or death due to electrical shock.

- Open the door to the transfer switch using a suitable tool and opening the door lock with the key.
- Visually inspect the actual position of the transfer switch mechanism. *If the position of the transfer switch mechanism is clearly in the "neutral position", the service has been successfully disconnected.*

Notes: 1) If the position of the transfer switch mechanism is clearly in the "neutral position, the "service disconnected" pilot light may not have illuminated due to the following reasons:

- a) Utility and generator supply voltages are not present (the pilot light requires AC supply voltage to be present).
- b) The pilot light may be burnt out. The bulb should be immediately replaced with a suitably rated bulb.
- c) Failure of one or more of the sensing/logic contacts. A qualified service technician is required to trouble shoot this specific condition. *Unplug the control circuit isolation plug to de-energize all AC power to the control circuits.* Note: The AC power conductors will still remain energized. Once the control circuit isolation plug is removed the "Service Disconnected" pilot light will not illuminate due to loss of control power.

Note: to return the transfer switch back to normal operation, the control circuit isolation plug must be reconnected for correct operation.

- The transfer switch door should then be securely closed using a suitable tool and locked in the closed position with the key. Once the transfer switch door has been positively locked closed and secured and only then is, it is safe to perform any maintenance procedures as required.
- *If the position of the transfer switch mechanism is **not** in the "neutral position" further procedures are required (refer to the following procedure)*

Warning

*Failure to positively lock closed and secure the transfer switch door may result in **serious personal injury or death** due to electrical shock.*

- If the position of the transfer switch mechanism is **not** in the "neutral position" the transfer switch mechanism must be manually operated as follows. To operate manually, pull the manual release plunger on the mechanism, releasing the motor drive rod from motor drive arm and move the knob and yoke to the marked "**Neutral**" position.

Warning

Failure to move the mechanism to the Neutral Position may result in serious personal injury or death due to electrical shock.

The transfer switch door should then be securely closed using a suitable tool and locked in the closed position with the key. Once the Transfer switch door has been positively locked closed and secured and only then is, it is safe to perform any maintenance procedures as required.

Warning

Failure to positively lock closed and secure the transfer switch door may result in serious personal injury or death due to electrical shock.

To re-energize the load, the padlock(s) should be removed from the "Service Disconnect" control switch, and move the switch to the "Energized" position. The transfer switch will immediately return to the utility or generator supply if within normal operating limits.

4.3. TEST CONDITION

The transfer switch may be tested utilizing the TSC 800 controller push-buttons or optional four position test switch. A simulated utility power failure condition will be activated when the test mode is selected. The transfer switch will operate as per a normal utility power fail condition. Note the test mode is operator selectable for "On-Load" or "Off-Load" testing scenarios.

The transfer switch will remain on generator supply until the test mode is terminated. It will then immediately transfer back to the utility supply and then continue to operate the generator set for its cooldown period then stop. Note: the transfer switch will automatically return to the utility supply (if within nominal limits) if the generator set fails while in the test mode.

5. TYPE A AND TYPE B DEFINITIONS

"Type A" transfer switch means an automatic transfer switch that does not employ integral overcurrent devices.

"Type B" transfer switch means an automatic transfer switch that does employ integral overcurrent protection in at least one of its two breakers.

"Type A" transfer switches are not equipped with trip units, and require properly coordinated upstream protection. Information on closing and withstand ratings, and recommendations for maximum upstream protective devices for "type A" units are in this manual. (Note: Some "Type A" models employ "high-magnetic" trips in the breakers, however these are set to trip at a higher than normal current for that amperage circuit, therefore the possibility of tripping is very remote. Since these trips are not intended to provide overcurrent protection, but are rather employed to ensure the integrity of the transfer switch under all circumstances, they are still classed as "Type A").

"Type B" transfer switches are typically equipped with standard thermal-magnetic trips which will provide the required overload and short circuit protection. "Type B" can also be built using solid state trip breakers, which can include ground fault tripping as well as overload and short circuit protection.

It should be noted that a "Type B" transfer switch with overcurrent protection in only one breaker will require the same consideration for upstream protection in the feeder of the breaker with no trip (as applies to a "Type A" transfer switch).

6. GENERAL NOTES ON SERVICING MECHANISM

(See CAUTION! on Page #1)

When performing any service work on the transfer mechanism, it is imperative that the following be observed:

6.1. To maintain mechanical integrity, ensure that:

- All limit switches linkages are correctly adjusted to provide full travel of the breaker toggles *without* exerting unnecessary forces associated with excessive travel. Ensure that breakers travel far enough to reset any internal trip unit (it is more important for the toggle to go fully in the "off" direction, than in the "on" direction).
- Mechanical interlocking is correct one breaker must be well open before the other should close.
- All fasteners are adequately tightened.
- The operating linkages are not damaged or bent, and that all bearing points operate *freely*.

6.2. To maintain electrical integrity, ensure that:

- All electrical connections, especially power connections, are clean and adequately tightened. Corroded or loose power connections will cause destructive heating, and may cause premature tripping in "type B" units.
- All insulating devices are in place and in good condition.
- No moisture or other contamination is present.
- Electrical conductors are adequately secured away from moving parts.

6.3. To maintain operational integrity, ensure that:

- All control devices are in good condition and correctly calibrated.
- All control devices are adequately secured in their plug-in fixtures.

Service work should be undertaken only by qualified personnel. Failure to correctly maintain an automatic transfer switch may present a hazard to life and equipment. Full operational testing must be done prior to placing a transfer switch in service subsequent to any maintenance or repair. Any service work involving electrical components requires high-potential testing to ensure that required insulation levels have been maintained.

7. STYLE "T" TRANSFER SWITCH MECHANISM - 400 - 1200 Amp

The transfer mechanism consists primarily of the transfer motor, a hub assembly, two operating rods and two breaker operating yokes.

The reversible transfer motor drives the hub assembly, which in turn moves the operating rods which are connected to the breaker operating yokes. The breaker toggles are set inside the yokes and are moved by them. There are two limit switches which are contacted by the operating yokes (one for each direction of travel) which disconnect the transfer motor power supply when the breakers have attained full travel. The operating point of these limit switches is determined by the adjuster screws located on the yokes. Should adjustment be required, it is advisable to consult TTI for further information.

The transfer switch mechanism has three possible positions:

- a) Utility breaker closed and generator breaker open;
- b) Generator breaker closed and utility breaker open;
- c) Both utility and generator breakers open, but NEVER both utility and generator breakers closed at the same time.

7.1. MANUAL OPERATION (or to reset a typical breaker) (See CAUTION on Page 1)

Isolate the transfer switch from all sources of supply before opening the enclosure for manual operation. The control circuit isolation plug (PL12) should be unplugged to prevent subsequent operation.

To operate manually, pull the release plunger and operate the handle in the desired direction.

Automatic operation may be regained by replacing the isolation. The drive system is self engaging and will operate the transfer switch to the required position. (See manual operation instruction on front of transfer switch mechanism.)

8. STYLE "M" TRANSFER SWITCH MECHANISM - Maximum 250 Amp

The transfer mechanism consists of the transfer motor and drive assembly, which operates a common yoke which in turn operates both utility and generator breakers. Since the breakers are oriented opposite to each other, the action of turning one breaker off will result in turning the other breaker on. The geometry of the mechanism ensures that one breaker always opens before the other closes, thus maintaining the required mechanical interlocking.

The unidirectional motor, operating through the motor drive arm and rod assembly, which is normally held captive to the yoke via the manual release plunger assembly, acts upon the yoke drive arm. Both breaker toggles are set inside the common yoke and are moved by it. There are two limit switches which are contacted by the yoke at its extremes of travel, disconnecting the motor circuit at the point of full breaker toggle travel in the intended direction. Adjustment of the limit switches is accomplished by loosening the two mounting screws securing each switch and sliding them in the desired direction. Should adjustment be required it is advisable to consult TTI for further information.

The transfer switch mechanism has three possible positions:

- a) Utility breaker closed and generator breaker open;
- b) Generator breaker closed and utility breaker open;
- c) Both utility and generator breakers open, but NEVER both utility and generator breakers closed at the same time.

8.1. MANUAL OPERATION (or to reset a typical breaker)

(See CAUTION! on Page #1)

Isolate the transfer switch from all sources of supply before opening the enclosure for manual operation. The control circuit isolation plug (PL12) should be unplugged to prevent subsequent operation.

To operate manually, pull the manual release plunger, releasing the motor drive rod from the motor drive arm and push the yoke in the desired direction.

Automatic operation may be regained by turning the release plunger until locked and replacing the isolation plug. The mechanism drive will operate until the motor drive rod is engaged and the transfer switch yoke is moved into the required position. (See manual operation instruction on door of transfer switch mechanism).


9. RECOMMENDED MAINTENANCE (STYLE "T" & STYLE "M" MECHANISMS)

(See CAUTION! on Page #1)


- 9.1. DO NOT perform dielectric tests on the equipment with the control components in the circuit.
- 9.2. Check if control components are tight in sockets.
- 9.3. Periodically inspect all terminals (load, line and control) for tightness. Re-torque all bolts, nuts and other hardware. Clean or replace any contact surfaces which are dirty, corroded or pitted.
- 9.4. Transfer switches should be in a clean, dry and moderately warm location. If signs of moisture are present, dry and clean transfer switch. If there is corrosion, try to clean it off. If cleaning is unsuitable, replace the corroded parts. Should dust and/or debris gather on the transfer switch, brush, vacuum, or wipe clean. DO NOT blow dirt into breakers.
- 9.5. Test the transfer switch operation. While the unit is exercising, check for freedom of movement, hidden dirt, corrosion or any excessive wear on the mechanical operating parts. Ensure that the breaker travel is correct.
- 9.6. Verify all program settings on the TSC 800 controller as per the programming sheet as supplied with the transfer switch.
- 9.7. Style "M": confirm that the yoke operates freely on the yoke pivot bushings. Should lubrication be required, apply medium weight (SAE 20) oil sparingly at these points.
- 9.8. Style "T": ensure that the manual handle moves freely on the hub when the lock pin is disengaged. If lubrication is necessary, apply medium weight (SAE 20) oil sparingly.
- 9.9. Style "T": yoke pivot bearings and rod ends are permanently lubricated and do not require maintenance.
- 9.10. The motor and gearbox are permanently lubricated, and should not require attention under normal operating circumstances.

10. FRONT VIEW (TYPICAL) 3 / 4 POLE STYLE "T" TRANSFER MECHANISM

CONFIGURATION "SL" SHOWN. REFER TO DWG. EPA5015/30 FOR VARIATIONS PER JOB REQUIREMENTS.




TSC800 CONTROLLER FOR DOOR MOUNTING




72" CONDUCTOR FOR OPEN STYLE. LENGTH AS REQ'D FOR TTI SUPPLIED ENCLOSURE.

11. STYLE "T" CONFIGURATION OPTIONS




NOTE: FOR GENERAL LAYOUT ONLY, PHASING ORDER MAY CHANGE.
3 PHASE CONNECTION SHOWN. FOR SINGLE PHASE CONNECT TO A & B ONLY.



7	ADDED REFERENCE TO SINGLE PHASE CONNECTION.	RG	NS	96-01-15	DRAWINGS AND OR OTHER TECHNICAL INFORMATION BY THOMSON TECHNOLOGY INC AS A PART OF A EQUIPMENT ARE FOR THE PURCHASERS USE SOLELY IN JUNCTION WITH THAT EQUIPMENT, UNLESS AGREED TO OTHERWISE AS A PART OF THE TERMS OF
6	UP-DATED TITLE BLOCK, ETC.	RG	NS	95-05-16	
No.	REVISIONS	BY	AUTH	DATE	

	"T" STYLE TRANSFER SWITCH CONFIGURATIONS STANDARD TRANSFER SWITCHES			CUSTOMER TTI	
	CAD FILE NAME	DWN	AUTH	DATE	
	A501530	RG	NS	88-05-24	
DRAWING No.	SHEET	REV			
EPA 5015/30	1/1	7			

12. FRONT VIEW (TYPICAL) 3 / 4 POLE STYLE "M" - 100/150/250A
TRANSFER MECHANISM




	FRONT VIEW (TYPICAL)		CUSTOMER			
	3/4 POLE STYLE 'M'		TTI			
	TRANSFER MECHANISM - 100/150/250A		CAD FILE NAME	DWN	AUTH	DATE
			7A001302	SH	GS	00-01-27
		DRAWING NO.	SHEET		REV	
		7A001302	1/1		0	

FORM CAD No. ASHT

© THE INFORMATION ON THIS DRAWING IS THE PROPERTY OF THOMSON TECHNOLOGY INC. IT IS NOT TO BE USED DETRIMENTALLY TO OUR INTERESTS.

13. FRONT VIEW (TYPICAL) 3 POLE STYLE "M" - 200A
TRANSFER MECHANISM



NOTE: 3 PHASE CONNECTION SHOWN.
FOR SINGLE PHASE CONNECT TO A & B ONLY



FRONT VIEW (TYPICAL)
3 POLE STYLE 'M'
TRANSFER MECHANISM - 200A

CUSTOMER		TTI	
CAD FILE NAME	OWN	AUTH	DATE
8A000301	RG	GS	98-07-29
DRAWING No.	SHEET		REV
8A000301	1/1		1

FORM CAD No. ASHT

© THE INFORMATION ON THIS DRAWING IS THE PROPERTY OF THOMSON TECHNOLOGY INC. IT IS NOT TO BE USED DETRIMENTALLY TO OUR INTERESTS.

14. TROUBLESHOOTING (See CAUTION! on Page #1)

Symptom

- will not re-transfer to utility source upon restoration

- will not transfer to generator source upon failure of utility source

- transfer to generator source without a power failure in the utility source

- generator does not start up or stop when it should

- no time delay when there should be

- power is not available at the load terminals but the utility or generator breaker appears to be closed to a live source

- the transfer switch has completed a transfer, but the motor has overheated and the internal thermal protector has opened

Possible Causes

- isolation plug out

- a test mode has been activated (check TSC 800 status LCD display)
- utility voltage or frequency is outside the pre-programmed limits (check utility source for adequate voltage & frequency)
- a loose control connection
- faulty motor limit switch
- defective motor
- defective TSC 800 controller (verify output signals with circuit board mounted diagnostic LED's)

- isolation plug out

- generator set not producing enough voltage/frequency or output circuit breaker open
- warmup time delay function has not timed out yet (verify TSC 800 timer setting)
- a loose control connection
- faulty motor limit switch
- defective motor
- defective TSC 800 controller (verify output signals with circuit board mounted diagnostic LED's)

- a test mode has been activated (check TSC 800 status LCD display)
- defective TSC 800 controller (verify output signals with circuit board mounted diagnostic LED's)

- verify remote engine control panel is set for automatic mode

- verify time delay function in the TSC 800 program setting as per programming sheets as supplied with the transfer switch

- the breaker's trip unit (Type B style only) has tripped on a fault on the system. Correct the fault, and manually reset the breaker in the transfer switch by moving it off and then on again with the manual operating handle
- limit switch incorrectly adjusted

- limit switch failure or improper adjustment has failed to disconnect motor
- binding or jamming of the transfer mechanism

DEFECTIVE COMPONENTS

Return defective components to Thomson Technology Inc. for repair. Be sure to advise model and serial number of the transfer switch.

15. CABLE TERMINAL INFORMATION

CABLE TERMINAL INFORMATION AND RECOMMENDED TIGHTNESS							
Basic Transfer Switch Style	Transfer Switch Rating (Amps)	Cable Terminal Rating				Connection Tightness (In-Lbs)	
		Utility & Generator Supply		Load & Neutral		Terminal Mounting Screw	Cable Clamp
		Qty Per Phase	Range	Qty Per Phase	Range		
MCE	100 150	1 1	#4-4/0 #4-4/0	1 1	#4-4/0 #4-4/0	-- 20	100 (Socket) 50 (Slot)
MS3	200	1	#6-350MCM	1	#6-350MCM	72	275
MCE	250	1	#1-350MCM	1	#1-350MCM	90	275
TCJ	400 ¹	3	250-500MCM ³	2	2/0-500MCM 4/0-500MCM	275	375
TCK	600 ¹	3	250-500MCM ³	2	2/0-500MCM 4/0-500MCM	275	375
TCK	800 ¹	3	250-600 MCM	3	250-600 MCM	275	375
TCK	1000/1200 ¹	4 4	3/0-500MCM 4/0-500MCM	4 4	3/0-500MCM 4/0-500MCM	275	375
TCK	1600 ²	4	#2-600MCM	4	#2-600MCM	275	375

1. Optional Terminal Ratings are available in some models – Consult TTI.
2. IEC only.
3. 600MCM lug size is available subject to restricted cable entry locations.

16. REQUIREMENTS FOR UPSTREAM CIRCUIT PROTECTIVE DEVICES

Closing and Withstand Rating (Amps RMS Sym) With Upstream Fuse Protection

Basic Model	Max. Voltage	Rated Current (A)	SHORT CIRCUIT CURRENT RATING (AVAILABLE SYMMETRICAL AMPS (RMS)) ₁				
			With Upstream Circuit Breaker Protection			With Upstream Fuse Protection	
			@240V	@480V	@600V	@ Up to 600V	Fuse Type
TS 850 - MCE- 100	600	100	65,000	25,000	18,000	100,000	T, J
TS 850 - MCE- 150	600	150	65,000	25,000	18,000	100,000	T, J
TS 850 - MS3- 200	240	200	100,000	N/A	N/A	N/A	T, J
TS 850 - MCJL-250	600	250	65,000	35,000	25,000	100,000	T, J
TS 850 - TCJ- 400	600	400	65,000	35,000	25,000	100,000	T, J
TS 850 - TCK- 600	600	600	65,000	50,000	35,000	100,000	T, J
TS 850 - TCK- 800	600	800	65,000	50,000	35,000	100,000	Consult Factory
TS 850 - TCK-1000	600	1000	65,000	50,000	35,000	100,000	"
TS 850 - TCK-1200	600	1200	65,000	50,000	35,000	100,000	"

1. Standard ratings only are shown. Consult TTI for versions with higher short circuit current ratings.

Fuse ratings shown are maximum allowable to permit use of the transfer switch in application with available fault current not exceeding that shown. Consideration must be given to fuse sizing when fuses also provide overload protection.

Please refer to the factory for further information on upstream protection requirements if required.

17. NOTES



TSB 850

BYPASS ISOLATION SWITCHES

INSTALLATION, OPERATING & SERVICE MANUAL



PM051 Rev 4 00/12/01

NOTE:

For detailed information on Dual Source systems (Option LEV-3) refer to Information Supplement PM043.

GENERAL DESCRIPTION

Bypass isolation switches are used in conjunction with automatic load transfer switches. They enable an operator to bypass a source to the load and isolate the transfer switch for maintenance or testing.

The mechanism utilizes molded case switching devices and a positive mechanical interlock to prevent two sources from being connected at the same time and true isolation of the transfer switch.

Thomson Technology Inc. offers three types of isolation-bypass switches.

1) SINGLE SIDED BYPASS MODEL TSBU 850 (Utility), TSBG 850 (Generator)

This device may be either a utility or generator side bypass. The bypass consists of a source isolate breaker (either utility or generator), a load isolate breaker and a source bypass breaker (either utility or generator). This device provides an interrupted bypass to the selected source. The alternate source must be isolated upstream to provide complete isolation of the transfer switch.

2) DOUBLE SIDED BYPASS (MODEL TSBD 850)

This device allows bypass to either source and complete isolation of the transfer switch. The bypass consists of two source isolate breakers, two source bypass breakers (both utility and generator sides) and a load isolate breaker. This switch provides for either an interrupted or uninterrupted bypass to either source. A test circuit allows for transfer switch operation in the bypassed mode.

CAUTION: Before opening the transfer switch or bypass isolation enclosure to perform any service task or to manually transfer the mechanism, it is imperative to isolate the transfer switch from any possible source of power. Failure to do so may result in serious personal injury or death due to electrical shock.

NOTE: All information contained in this manual is for reference only and is *subject to change without notice*.

Contact Thomson Technology Inc. for clarification of current revision or if in doubt about any matter relating to installation, operation or maintenance.

NOTE TO INSTALLER

To ensure satisfactory installation of this equipment be sure to observe "Recommended Connection Tightness" and "Requirements for Upstream Circuit Protective Devices" located in this manual.

All mechanical and electrical connections must be checked for tightness prior to placing this equipment in service to ensure proper operation and to validate applicable warranty coverage.

If the transfer switch has programmable multi-tap voltage capability (refer to electrical schematic), confirm the transfer switch has been configured for the system voltage prior to installation.

Warning

Failure to confirm and match transfer switch voltage with the system voltage could cause serious equipment damage.

The voltage selections and connections are shown on the electrical schematics attached to each transfer switch. The factory default settings will be indicated on the calibration label attached on the inside of the enclosure door (supplied loose on open style models). A blank label is included to record the applicable settings if the configuration is changed from the factory default settings.

To change the transfer switch configuration the following must be accomplished:

- Change voltage taps of PT's to system voltage (refer to schematics)
- Change TSC 800 programming (refer to sections 6.2.2, 6.2.4, 6.2.5, 6.3, and 6.4 of the TSC 800 instruction manual). The following settings may require reprogramming (depending on options purchased):
 - System voltage
 - System frequency
 - System phase
 - Utility undervoltage pickup (typically 90% of system voltage)
 - Utility undervoltage dropout (typically 80% of system voltage)
 - Utility overvoltage pickup (typically 110% of system voltage)
 - Utility overvoltage dropout (typically 105% of system voltage)
 - Utility underfrequency (typically 95% of system frequency)
 - Utility overfrequency (typically 105% of system frequency)
 - Generator undervoltage pickup (typically 90% of system voltage)
 - Generator undervoltage dropout (typically 80% of system voltage)
 - Generator overvoltage pickup (typically 110% of system voltage)
 - Generator overvoltage dropout (typically 105% of system voltage)
 - Generator underfrequency (typically 95% of system frequency)
 - Generator overfrequency (typically 105% of system frequency)

Record any changed setting on the TSC 800 Programming Data Sheets for future reference.

Complete the blank calibration label and attach to the inside of the transfer switch enclosure door.

GENERAL NOTES ON SERVICING

When performing any service work on the bypass isolation switch, it is imperative that the following be observed:

- a) To maintain mechanical integrity, ensure that:
 - Mechanical interlocking is correct and movement is free; proper sequence of breaker opening/closing must be maintained.
 - All fasteners are adequately tightened.

- b) To maintain electrical integrity, ensure that:
 - All electrical connections are clean and adequately tightened.
 - All insulating devices are in place and in good condition.
 - No moisture or other contamination is present.

Service work should be undertaken only by qualified personnel. Failure to correctly maintain a bypass isolation switch may represent a hazard to life and equipment. Full operational testing must be done prior to placing a switch in service subsequent to any maintenance or repair. Any service work involving electrical components requires high potential testing to ensure that required insulation levels have been maintained.

OPERATION

(Refer to the operating description for the model and type of equipment installed).

NOTE: a) In this manual, the breakers are designated as follows:

UI-Utility isolate: This breaker isolates the utility supply input from the transfer switch.

GI-Generator isolate: This breaker isolates the generator supply input from the transfer switch.

LI-Load isolate: This breaker isolates the load from the transfer switch.

UB-Utility bypass: This breaker connects the utility supply directly to the load.

GB-Generator bypass: This breaker connects the generator supply directly to the load.

b) Normal position is defined as when neither source is bypassed and the load is being supplied from either source through the transfer switch.

1) SINGLE SIDED BYPASS (MODEL TSBU (Utility), TSBG (Generator))

NOTE: Transfer switch is not completely isolated unless isolate breakers and alternate supply breakers are open.

The sequence of operation for a utility side bypass is as follows:

- Normal position: Utility isolate (UI) and Load isolate (LI) closed; Utility bypass (UB) open.
- Before bypassing, turn engine control switch to OFF if startup is not desired and/or isolate generator circuit breaker to ensure complete transfer switch isolation.
- To bypass and isolate transfer switch: Open Utility isolate (UI) and Load isolate (LI).
- Move sidebar interlock to allow closure of Utility bypass (UB).
- Close UB.
- The load is now connected directly to the utility supply and the transfer switch is isolated from the utility supply. Isolation of the transfer switch from the generator supply must be done upstream.
- To return to normal position, reverse the above steps.

The sequence of operation for a generator side bypass is as follows:

- Normal position: Generator isolate (GI) and Load isolate (LI) closed; Generator bypass (GB) open.
- Before bypassing, the generator should be running and connected to the Load through the transfer switch (to ensure complete transfer switch isolation) and/or open utility supply feeder breaker.
- To bypass and isolate transfer switch: Open Generator isolate (GI) and Load isolate (LI).
- Move sidebar interlock to allow closure of Generator bypass (GB).
- Close GB.
- The load is now connected directly to the generator supply and the transfer switch is isolated from the generator supply. Isolation of the utility supply must be done upstream.
- To return to normal position, reverse the above steps.

2) DOUBLE SIDED BYPASS (MODEL TSBD)

The sequence of operation for uninterrupted bypass is as follows:

a) **Utility Bypass**

- Normal position: Utility isolate (UI), Generator isolate (GI) and Load isolate (LI) are closed; Utility bypass (UB) and Generator bypass (GB) are open.
- Before bypassing, turn engine control switch to OFF if startup is not desired.
- To bypass and isolate transfer switch: Open Generator isolate (GI).
- Move sidebar interlock to allow closure of Utility bypass (UB).
- Close UB. The utility source is now parallel connected to the load through the transfer switch and UB.
- Open Utility isolate (UI).
- Open Load isolate (LI). The transfer switch is now isolated from both sources and the load.
- If the lockable sidebar is used, move sidebar to isolate position and lock to prevent accidental energization of the transfer switch.
- To return to normal position, reverse the above steps.

b) Generator Bypass

NOTE: The generator should be running and connected to the load through the transfer switch.

- Normal position: Utility isolate (UI), Generator isolate (GI) and Load isolate (LI) are closed: Utility bypass (UB) and Generator bypass (GB) are open.
- To bypass and isolate transfer switch: Open Utility isolate (UI).
- Move sidebar interlock to allow closure of Generator bypass (GB).
- Close GB. The generator source is now parallel connected to the load through the transfer switch and GB.
- Open Generator isolate (GI).
- Open Load isolate (LI). The transfer switch is now isolated from both sources and the load.
- If the lockable sidebar is used, move sidebar to isolate position and lock to prevent accidental energization of the transfer switch.

CAUTION: In either mode, the transfer switch is not isolated unless all three isolation breakers (UI, LI, GI) are open.

The previous sequences are for uninterrupted bypass. An interrupted bypass can be accomplished by opening all isolation breakers prior to closing the selected bypass breaker.

Note:

The transfer switch may be tested in the bypassed mode by connecting the transfer to the test plug. This allows for energization of the control circuits **only** for transfer switch function or maintenance testing. **The neutral delay control feature of the transfer switch (if supplied) will not be functional while using the test plug.**

RECOMMENDED MAINTENANCE

- 1) Do not perform dielectric tests on the equipment with any control components in the circuit.
- 2) Periodically inspect all terminals (load, line) for tightness. Re-torque all bolts, nuts and other hardware.
- 3) Bypass isolation switches should be in clean, dry and indoor location. If signs of moisture are present, attempt to remove. If cleaning is unsuitable, replace the corroded parts. Should dust or debris gather on the switch, brush, vacuum or wipe clean. **DO NOT** blow dirt into breakers or terminals.
- 4) Check for ease and correctness of interlock movement.

DEFECTIVE COMPONENTS

Return defective components to Thomson Technology Inc. for repair. Be sure to advise model and serial number of the unit.

CABLE TERMINAL INFORMATION AND RECOMMENDED TIGHTNESS

Basic Transfer Switch Style	Transfer Switch Rating (Amps)	Cable Terminal Rating				Connection Tightness (In-Lbs)	
		Utility & Generator Supply		Load & Neutral		Terminal Mounting Screw	Cable Clamp
		Qty Per Phase	Range	Qty Per Phase	Range		
MCE	100	1	#4-4/0	1	#4-4/0	--	100 (Socket)
	150	1	#4-4/0	1	#4-4/0	20	50 (Slot)
MS3	200	1	#6-350MCM	1	#6-350MCM	72	275
MCE	250	1	#1-350MCM	1	#1-350MCM	90	275
TCJ	400 ¹	3	250-500MCM ³	2	2/0-500MCM 4/0-500MCM	275	375
TCK	600 ¹	3	250-500MCM ³	2	2/0-500MCM 4/0-500MCM	275	375
TCK	800 ¹	3	250-600 MCM	3	250-600 MCM	275	375
TCK	1000/1200 ¹	4	3/0-500MCM	4	3/0-500MCM	275	375
		4	4/0-500MCM	4	4/0-500MCM		
TCK	1600 ²	4	#2-600MCM	4	#2-600MCM	275	375

1. Optional Terminal Ratings are available in some models - Consult TTI.
2. IEC only.
3. 600MCM lug size is available subject to restricted cable entry locations.

REQUIREMENTS FOR UPSTREAM CIRCUIT PROTECTIVE DEVICES

Closing and Withstand Rating (Amps RMS Sym) With Upstream Fuse Protection

Basic Model	Max. Voltage	Rated Current (A)	SHORT CIRCUIT CURRENT RATING (AVAILABLE SYMMETRICAL AMPS (RMS)) ₁				
			With Upstream Circuit Breaker Protection			With Upstream Fuse Protection	
			@240V	@480V	@600V	@ Up to 600V	Fuse Type
TSB 850 - MCE-100	600	100	65,000	25,000	18,000	100,000	T, J
TSB 850 - MCE-150	600	150	65,000	25,000	18,000	100,000	T, J
TSB 850 - MS3-200	240	200	100,000	N/A	N/A	N/A	T, J
TSB 850 - MCJL-250	600	250	65,000	35,000	25,000	100,000	T, J
TSB 850 - TCJ-400	600	400	65,000	35,000	25,000	100,000	T, J
TSB 850 - TCJ-600	600	600	65,000	50,000	35,000	100,000	T, J
TSB 850 - TCK-800	600	800	65,000	50,000	35,000	100,000	Consult Factory
TSB 850 - TCK-1000	600	1000	65,000	50,000	35,000	100,000	"
TSB 850 - TCK-1200	600	1200	65,000	50,000	35,000	100,000	"

1. Standard ratings only are shown. Consult TTI for versions with higher short circuit current ratings.

Fuse ratings shown are maximum allowable to permit use of the transfer switch in application with available fault current not exceeding that shown. Consideration must be given to fuse sizing when fuses also provide overload protection.

Please refer to the factory for further information on upstream protection requirements, if required.



DRAWINGS SUBJECT TO CHANGE WITHOUT NOTICE.

MODEL TS 653 - M - A -

SCHEMATIC DIAGRAM AUTOMATIC TRANSFER SWITCH

TRANSFER SW. CONTROLLER


UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12



OPTIONAL DIRECT COMMUNICATION (WITHOUT C.M.)

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2

TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12

OPTIONAL DISCONNECT CONTACT

TRANSFER SW. CONTROLLER

UTILITY SOURCE 1 POWER CHASSIS

UTILITY SOURCE 2


TRANSFER SWITCH WIRING OPTIONS

PROGRAMMABLE CONTACT [SELECT ONE ONLY]

DATE: 06-10-11
 DRAWING NO.: 65033301
 SHEET: 1/1
 OF: 12



DRAWINGS SUBJECT TO CHANGE WITHOUT NOTICE.



SCHEMATIC DIAGRAM AUTOMATIC TRANSFER SWITCH

MODEL TS B53 - T - - - - A - - - - A, V, 3 Ø, 3 W, Hz

DISPOSITION ON THIS DRAWING IS THE PROPERTY OF THOMSON TECHNOLOGY. IT IS NOT TO BE USED DERIVATIVELY TO OUR INTERESTS.

REFER TO MANUAL FOR CABLE CONNECTION INFORMATION.

LEGEND

ISOLATION P.L.U.S. OPTIONAL ITEMS

OUTDOOR

DATE: 06-09-11

DRAWING NO.: 06080801

DATE: 1/1

SCALE: 1/1

NO. OF SHEETS: 10

DATE: 06-09-11

DRAWING NO.: 06080801

DATE: 1/1

SCALE: 1/1

NO. OF SHEETS: 10

DATE: 06-09-11

DRAWING NO.: 06080801

DATE: 1/1

SCALE: 1/1

NO. OF SHEETS: 10

DATE: 06-09-11

DRAWING NO.: 06080801

DATE: 1/1

SCALE: 1/1

NO. OF SHEETS: 10

DATE: 06-09-11

DRAWING NO.: 06080801

DATE: 1/1

SCALE: 1/1

NO. OF SHEETS: 10

DATE: 06-09-11

DRAWING NO.: 06080801

DATE: 1/1

SCALE: 1/1

NO. OF SHEETS: 10

DATE: 06-09-11

DRAWING NO.: 06080801


DATE: 1/1

SCALE: 1/1

NO. OF SHEETS: 10

DATE: 06-09-11

DRAWING NO.: 06080801



TRANSFER SWITCH WIRING OPTIONS	PROGRAMMABLE CONTACT (SELECT ONE ONLY)	<input type="checkbox"/> AIR-4(SRC2)1(OTY 1)	<input type="checkbox"/> AIR-4(SRC1)1(OTY 1)	<input type="checkbox"/> FAIL TO TRANSFER
FTS4	CONTROL TYPE	<input type="checkbox"/> DUAL SOURCE	<input type="checkbox"/> AUTOMATIC TRANSFER SWITCH	<input type="checkbox"/>
AIR-4/SRC2 AIR CONTACTS	[OTY 1] [MAX 2]	<input type="checkbox"/>	AIR-4/SRC1 AIR CONTACTS	[OTY 1] [MAX 2]
UPA UTIL/SRC1 PAR AV. CONT'S	[OTY 1] [MAX 2]	<input type="checkbox"/>	GPA GEN/SRC2 PAR AV. CONT'S	[OTY 1] [MAX 2]
LD(Load Disconnect Contact)	<input type="checkbox"/>		PROG COMMUNICATION OPTION (VTR CUM)	<input type="checkbox"/>

TOE TSSM CONTROLLER OPTIONS. REFER TO PROGRAMMING SHEETS	SYSTEM MUST UTILIZE A WHEN DUAL SOURCE OPTION SELECTED. PROGRAMMABLE CONTACT 1 & 2 MUST BE USED IN THIS CASE. CONTACTS 5 & 6 (CLOSE TO START) SHOW, FOR SINGLE PHASE CARRIER A AND B ONLY.
REFER TO MANUAL FOR CABLE CONNECTION INFORMATION	LESSON
OPTIONAL PLUG	OPTIONAL ITEMS
DATE 98-09-11	DESIGNER
DRAWING NO. 68080761	PROJECT
SHEET 1/1	REVISION
REV 7	


THOMSON TECHNOLOGY INC.

MODEL TS 85-T-A

SCHEMATIC DIAGRAM AUTOMATIC TRANSFER SWITCH

DISFORMATION ON THIS DRAWING IS THE PROPERTY OF THOMSON TECHNOLOGY. IT IS NOT TO BE USED DETRIMENTALLY TO OUR INTERESTS.

FRANZES SUBJECT TO CHANGE WITHOUT NOTICE



(TYPICAL) FRONT VIEW
FINISH: ASA #61 GREY

SIDE VIEW

DIMENSIONS IN INCHES, [] = MILLIMETERS

No.	REVISIONS	BY	DATE
4	UPDATED TO LATEST ST'D.	RG NS	97-11-21
3	ADDED SWITCH FEATURES	SN NS	96-11-06
2	KNOCK DOWN BOX DESIGN	SN NS	96-10-03
1	MODIFIED FOR TSCB06	SN NS	96-09-17




THOMSON TECHNOLOGY INC.
AUTOMATIC TRANSFER SWITCH
ENCLOSURE DIMENSIONS
MODEL TS 850M
100A, 150A, 250A

THE INFORMATION ON THIS DRAWING IS THE PROPERTY OF THOMSON TECHNOLOGY INC. IT IS NOT TO BE USED DETRIMENTALLY TO OUR INTERESTS.

CAD FILE NAME (DWG)	AUTH	DATE
88008901	SN NS	96-10-03
88008901	SN NS	96-10-03

CUSTOMER
DRAWINGS AND/OR OTHER TECHNICAL INFORMATION SUPPLIED BY THOMSON TECHNOLOGY INC. IS THE PROPERTY OF THOMSON TECHNOLOGY INC. IT IS NOT TO BE USED DETRIMENTALLY TO OUR INTERESTS. UNLESS SPECIFICALLY AGREED TO OTHERWISE AS A PART OF THE TERMS OF SALE.

- NEMA 1
 - NEMA 1A
 - C/V DRIPPOOD
 - 100A
 - 150A
 - 250A
- SWITCH FEATURES**
- PREFERRED SOURCE SELECTOR SWITCH (ONLY WITH DUAL STANDBY SOURCE SYSTEMS)
 - OPTIONAL FOUR POSITION TEST SWITCH - FTS4 - ONLY WITH A15 SYSTEMS
 - NO SWITCH REQUIRED



SIZE (AMPS)	A	B	C	D	E
250A, 400A, 600A	57 [1448]	30 [762]	12 [305]	26 [660]	58.75 [1492]
800A, 1000A, 1200A	84 [2134]	34 [864]	12 [305]	30 [762]	85.75 [2178]

DIMENSIONS IN INCHES, [] = MILLIMETERS

No.	REVISIONS	BY	DATE
5	B00-1200A KNOCKDOWN ENC.	RG	98-09-23
4	250-600A KNOCK DOWN ENC.	HW	98-06-22
3	PRODUCTION UPDATES	JC	98-03-06
2	UPDATED TO LATEST ST'D.	RJ	97-11-21
1	MODIFIED FOR TSCB00	SN	96-09-16



THOMSON
TECHNOLOGY INC.
AUTOMATIC TRANSFER SWITCH
ENCLOSURE DIMENSIONS
MODEL TS 850T
250 - 1200A

THE INFORMATION ON THIS DRAWING IS THE PROPERTY OF THOMSON TECHNOLOGY INC. IT IS NOT TO BE USED DETRIMENTALLY TO OUR INTERESTS.

- NEMA 1
- NEMA 1A C/W DRIPHOO
- 250A
- 400A
- 600A
- 800A
- 1000A
- 1200A

TRANSFER SWITCH CONFIGURATION

- SL
- SR
- XL
- XR

DRAWINGS AND/OR OTHER TECHNICAL INFORMATION SUPPLIED BY THOMSON TECHNOLOGY INC AS A PART OF A SALE OF EQUIPMENT ARE FOR THE PURCHASER'S USE ONLY. THOMSON TECHNOLOGY INC. SHALL NOT BE RESPONSIBLE FOR THE USE OF THIS INFORMATION UNLESS SPECIFICALLY AGREED TO OTHERWISE AS A PART OF THE TERMS OF SALE.




CAD FILE NAME	DATE	AUTH	DATE
60009001	SN	NS	98-09-16
60009001	SN	NS	98-09-16

SHEET 1/1 REV 5

- NOTES**
- FOR TRANSFER SWITCH OPTIONS SEE DRAWINGS 680083301 or 680084401 or 680085501.
 - FOR CLOSED TRANSITION UTILITY BYPASS SEE DRAWING 680081001.
 - NEUTRAL PRESENT ONLY ON 3 POLE VERSIONS.
 - PRESENT ONLY ON 120/208V, 240V 1Ø UNITS. REF. DRAWING 68008401.

BREAKER	BYPASS POSITION	NORMAL POSITION
NI	NI	NI
LI	LI	LI
NS	NS	NS

X = BREAKER CLOSED ALLOWED



SINGLE LINE DIAGRAM

INTERIOR VIEW

FRONT VIEW

SIDE VIEW

* = CUSTOMER CONNECTION

DEPTH: 12" (305)
 COLOR: ASA #51 GREY
 DIMENSIONS IN [] = MILLIMETERS

GROUND LUGS : 3 x 10 #6-2/8 AL/CU (ALL UNITS).
 NEUTRAL LUGS: FOR 3 POLE UNITS, 3 x 10 #6-2/8 AL/CU.
 LOAD UTILITY & GENERATOR LUGS: 1 x 10 #4-4/8 CU ONLY PER POLE (NEUTRAL POLES IF 4 POLE)



DRAWINGS SUBJECT TO CHANGE WITHOUT NOTICE.

1 LINE DIAGRAM & PHYSICAL LAYOUT
AUTOMATIC TRANSFER SWITCH AND 3 BREAKER UTILITY BYPASS SYSTEM

MODEL: TSBU 85 -MCE-

RESERVE AND ON OTHER TECHNICAL INFORMATION. BY THOMSON TECHNOLOGY INC. AS A PART OF A SALE OF EQUIPMENT AND/OR ACCESSORIES TO THE BUYER. THESE DRAWINGS ARE TO BE USED AS A PART OF THE TERMS OF SALE.

PROJECT: _____
 SERIAL NUMBER: _____

DATE	96-09-18	DN	AM
DRAWING No.	68009101	SN	NS
REV	1/1	REV	6

LEGEND

ISOLATION PUD

OPTIONAL ITEMS

AS BUILT BY / TESTED BY

AS BUILT DATE

REFER TO MANUAL FOR COLE CONNECTION INFORMATION





OPTIONS INCLUDED IN BYPASS SWITCH ENCLOSURE OPTIONS

- EMAC 1
- EMAC 2
- EMAC 3
- SOLID NEUTRAL SN
- THREE POLE 3P
- FOUR POLE 4P

- ▽ NOTES
- FOR TRANSFER SWITCH OPTIONS SEE DRAWINGS 68009301 or 38009401 or 68009501.
 - ONLY PRESENT ON 120/208 AND 240/160 UNITS. REFERENCE DRAWING 68009401.
 - NEUTRAL PRESENT ONLY ON 3 POLE VERSIONS.

BREAKER	BYPASS POSITION	ISOLATE POSITION
NI		
LI		
NS		

X * BREAKER CLOSURE ALLOWED



GROUND LUGS: 3 x 1C #6-2/8 AL/CU
 NEUTRAL LUGS: 3 POLE UNITS)
 3 x 1C #6-3/8INCH AL/CU
 GENERATOR LUGS: 1 x 1C #8-25INCH AL/CU PER POLE
 1 x 1C #8-25INCH AL/CU PER POLE
 LOAD AND UTILITY LUGS: 1 x 1C #3-3/8INCH AL/CU PER POLE
 NEUTRAL LUGS: 1 x 4 POLE)

THOMSON TECHNOLOGY INC.

DRAWINGS SUBJECT TO CHANGE WITHOUT NOTICE.

1 LINE DIAGRAM & PHYSICAL LAYOUT
 AUTOMATIC TRANSFER SWITCH AND 3 BREAKER UTILITY BYPASS SYSTEM

MODEL T8BU 95 -MCL-250

250 A, V, 3 Ø, W, Hz

INFORMATION ON THIS DRAWING IS THE PROPERTY OF THOMSON TECHNOLOGY. IT IS NOT TO BE USED DETRIMENTALLY TO OUR INTERESTS.

DRAWINGS AND OTHER TECHNICAL INFORMATION SPECIFIED EQUIPMENT ARE FOR THE PURCHASER'S USE ONLY. IN COMPLIANCE WITH THE NATIONAL ELECTRICAL CODE, THIS DRAWING IS APPROVED TO OTHERS AS A PART OF THE TERMS OF SALE.

N-SLIDE M-SIDE 250A 3 L & 4 POLE

AS BUILT BY/ AS BUILT DATE	TESTED BY
DATE 96-03-18	DATE SN NS
68009103	1/1 NS 3

ENTER TO MAKE FOR CABLE CONNECTION INFORMATION

LEGEND


OPT. ISOLATION PLUS

OPTIONAL ITEMS





- OPTIONS INCLUDED IN BYPASS SWITCH ENCLOSURE OPTIONS
- ESMAC 1
 - ESMAC 2
 - 5/8" DRIPPOD & GASKETING
 - SOLID NEUTRAL
 - SN
 - THREE POLE
 - 3P
 - FOUR POLE
 - 4P

NOTES

- FOR 4 BREAKER UTILITY BYPASS DELETE GB AND ASSOCIATED CIRCUITS IN BYPASS SWITCH.
- FOR 4 BREAKER GENERATOR BYPASS DELETE NB AND ASSOCIATED CIRCUITS IN BYPASS SWITCH.
- FOR TRANSFER SWITCH OPTIONS SEE DRAWINGS 68009331 & 680094401 OR 68009501.
- PRESENT ONLY ON 120/200V, 240V 1Ø UNITS. REFERENCE DRAWING 68009401.
- C LINE NOT PRESENT ON 1Ø SYSTEMS.



BREAKER POSITION	UTILITY BYPASS				
	1	2	3	4	5
1	X	X	X	X	X
2	X	X	X	X	X
3	X	X	X	X	X
4	X	X	X	X	X
5	X	X	X	X	X



DRAWINGS SUBJECT TO CHANGE WITHOUT NOTICE.

MODEL 7580 65 -M - - - - -

1 LINE DIAGRAM & PHYSICAL LAYOUT
AUTOMATIC TRANSFER SWITCH AND 5 BREAKER BYPASS SYSTEM

DISCREPANCY ON THIS DRAWING IS THE PROPERTY OF THOMSON TECHNOLOGY. IT IS NOT TO BE USED DETRIMENTALLY TO OUR INTERESTS.

DATE	BY	CHK	APP
96-09-18	SN	NS	
68009104	SEIT	REV	
	1/1	5	

AS BUILT BY/ DATE	TESTED BY

LEGEND	REFER TO MANUAL FOR CABLE CONNECTION INFORMATION
OPTIONAL ITEMS	

ENCLOSURE OPTIONS	INCLUDED IN BYPASS SWITCH
EMAC 1	<input type="checkbox"/>
EMAC 2	<input type="checkbox"/>
EMAC 3	<input type="checkbox"/>
EMAC 4	<input type="checkbox"/>
EMAC 5	<input type="checkbox"/>
EMAC 6	<input type="checkbox"/>
EMAC 7	<input type="checkbox"/>
EMAC 8	<input type="checkbox"/>
EMAC 9	<input type="checkbox"/>
EMAC 10	<input type="checkbox"/>
EMAC 11	<input type="checkbox"/>
EMAC 12	<input type="checkbox"/>
EMAC 13	<input type="checkbox"/>
EMAC 14	<input type="checkbox"/>
EMAC 15	<input type="checkbox"/>
EMAC 16	<input type="checkbox"/>
EMAC 17	<input type="checkbox"/>
EMAC 18	<input type="checkbox"/>
EMAC 19	<input type="checkbox"/>
EMAC 20	<input type="checkbox"/>
EMAC 21	<input type="checkbox"/>
EMAC 22	<input type="checkbox"/>
EMAC 23	<input type="checkbox"/>
EMAC 24	<input type="checkbox"/>
EMAC 25	<input type="checkbox"/>
EMAC 26	<input type="checkbox"/>
EMAC 27	<input type="checkbox"/>
EMAC 28	<input type="checkbox"/>
EMAC 29	<input type="checkbox"/>
EMAC 30	<input type="checkbox"/>
EMAC 31	<input type="checkbox"/>
EMAC 32	<input type="checkbox"/>
EMAC 33	<input type="checkbox"/>
EMAC 34	<input type="checkbox"/>
EMAC 35	<input type="checkbox"/>
EMAC 36	<input type="checkbox"/>
EMAC 37	<input type="checkbox"/>
EMAC 38	<input type="checkbox"/>
EMAC 39	<input type="checkbox"/>
EMAC 40	<input type="checkbox"/>
EMAC 41	<input type="checkbox"/>
EMAC 42	<input type="checkbox"/>
EMAC 43	<input type="checkbox"/>
EMAC 44	<input type="checkbox"/>
EMAC 45	<input type="checkbox"/>
EMAC 46	<input type="checkbox"/>
EMAC 47	<input type="checkbox"/>
EMAC 48	<input type="checkbox"/>
EMAC 49	<input type="checkbox"/>
EMAC 50	<input type="checkbox"/>
EMAC 51	<input type="checkbox"/>
EMAC 52	<input type="checkbox"/>
EMAC 53	<input type="checkbox"/>
EMAC 54	<input type="checkbox"/>
EMAC 55	<input type="checkbox"/>
EMAC 56	<input type="checkbox"/>
EMAC 57	<input type="checkbox"/>
EMAC 58	<input type="checkbox"/>
EMAC 59	<input type="checkbox"/>
EMAC 60	<input type="checkbox"/>
EMAC 61	<input type="checkbox"/>
EMAC 62	<input type="checkbox"/>
EMAC 63	<input type="checkbox"/>
EMAC 64	<input type="checkbox"/>
EMAC 65	<input type="checkbox"/>
EMAC 66	<input type="checkbox"/>
EMAC 67	<input type="checkbox"/>
EMAC 68	<input type="checkbox"/>
EMAC 69	<input type="checkbox"/>
EMAC 70	<input type="checkbox"/>
EMAC 71	<input type="checkbox"/>
EMAC 72	<input type="checkbox"/>
EMAC 73	<input type="checkbox"/>
EMAC 74	<input type="checkbox"/>
EMAC 75	<input type="checkbox"/>
EMAC 76	<input type="checkbox"/>
EMAC 77	<input type="checkbox"/>
EMAC 78	<input type="checkbox"/>
EMAC 79	<input type="checkbox"/>
EMAC 80	<input type="checkbox"/>
EMAC 81	<input type="checkbox"/>
EMAC 82	<input type="checkbox"/>
EMAC 83	<input type="checkbox"/>
EMAC 84	<input type="checkbox"/>
EMAC 85	<input type="checkbox"/>
EMAC 86	<input type="checkbox"/>
EMAC 87	<input type="checkbox"/>
EMAC 88	<input type="checkbox"/>
EMAC 89	<input type="checkbox"/>
EMAC 90	<input type="checkbox"/>
EMAC 91	<input type="checkbox"/>
EMAC 92	<input type="checkbox"/>
EMAC 93	<input type="checkbox"/>
EMAC 94	<input type="checkbox"/>
EMAC 95	<input type="checkbox"/>
EMAC 96	<input type="checkbox"/>
EMAC 97	<input type="checkbox"/>
EMAC 98	<input type="checkbox"/>
EMAC 99	<input type="checkbox"/>
EMAC 100	<input type="checkbox"/>

GENERATOR 4 BREAKER BYPASS	UTILITY 4 BREAKER BYPASS	3P (ALL UNITS)	FOUR POLE (100/150A ONLY)
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

OPTIONAL ITEMS
EMAC 1
EMAC 2
EMAC 3
EMAC 4
EMAC 5
EMAC 6
EMAC 7
EMAC 8
EMAC 9
EMAC 10
EMAC 11
EMAC 12
EMAC 13
EMAC 14
EMAC 15
EMAC 16
EMAC 17
EMAC 18
EMAC 19
EMAC 20
EMAC 21
EMAC 22
EMAC 23
EMAC 24
EMAC 25
EMAC 26
EMAC 27
EMAC 28
EMAC 29
EMAC 30
EMAC 31
EMAC 32
EMAC 33
EMAC 34
EMAC 35
EMAC 36
EMAC 37
EMAC 38
EMAC 39
EMAC 40
EMAC 41
EMAC 42
EMAC 43
EMAC 44
EMAC 45
EMAC 46
EMAC 47
EMAC 48
EMAC 49
EMAC 50
EMAC 51
EMAC 52
EMAC 53
EMAC 54
EMAC 55
EMAC 56
EMAC 57
EMAC 58
EMAC 59
EMAC 60
EMAC 61
EMAC 62
EMAC 63
EMAC 64
EMAC 65
EMAC 66
EMAC 67
EMAC 68
EMAC 69
EMAC 70
EMAC 71
EMAC 72
EMAC 73
EMAC 74
EMAC 75
EMAC 76
EMAC 77
EMAC 78
EMAC 79
EMAC 80
EMAC 81
EMAC 82
EMAC 83
EMAC 84
EMAC 85
EMAC 86
EMAC 87
EMAC 88
EMAC 89
EMAC 90
EMAC 91
EMAC 92
EMAC 93
EMAC 94
EMAC 95
EMAC 96
EMAC 97
EMAC 98
EMAC 99
EMAC 100





AS BUILT BY/ DATE	TESTED BY

OPTIONAL ITEMS
EMAC 1
EMAC 2
EMAC 3
EMAC 4
EMAC 5
EMAC 6
EMAC 7
EMAC 8
EMAC 9
EMAC 10
EMAC 11
EMAC 12
EMAC 13
EMAC 14
EMAC 15
EMAC 16
EMAC 17
EMAC 18
EMAC 19
EMAC 20
EMAC 21
EMAC 22
EMAC 23
EMAC 24
EMAC 25
EMAC 26
EMAC 27
EMAC 28
EMAC 29
EMAC 30
EMAC 31
EMAC 32
EMAC 33
EMAC 34
EMAC 35
EMAC 36
EMAC 37
EMAC 38
EMAC 39
EMAC 40
EMAC 41
EMAC 42
EMAC 43
EMAC 44
EMAC 45
EMAC 46
EMAC 47
EMAC 48
EMAC 49
EMAC 50
EMAC 51
EMAC 52
EMAC 53
EMAC 54
EMAC 55
EMAC 56
EMAC 57
EMAC 58
EMAC 59
EMAC 60
EMAC 61
EMAC 62
EMAC 63
EMAC 64
EMAC 65
EMAC 66
EMAC 67
EMAC 68
EMAC 69
EMAC 70
EMAC 71
EMAC 72
EMAC 73
EMAC 74
EMAC 75
EMAC 76
EMAC 77
EMAC 78
EMAC 79
EMAC 80
EMAC 81
EMAC 82
EMAC 83
EMAC 84
EMAC 85
EMAC 86
EMAC 87
EMAC 88
EMAC 89
EMAC 90
EMAC 91
EMAC 92
EMAC 93
EMAC 94
EMAC 95
EMAC 96
EMAC 97
EMAC 98
EMAC 99
EMAC 100

- NOTES**
- FOR TRANSFER SWITCH OPTIONS SEE DRAWINGS 88008301 or 88008401 88008301.
 - PRESENT ONLY ON 120/208V, 240V 1Ø UNITS, REFERENCE DRAWING 88008401.
 - NEUTRAL PRESENT ONLY ON 3 POLE VERSIONS.

	BREAKER
	BYPASS POSITION
	ISOLATE POSITION
	UTILITY
	GEN
	LI
	GB

X = BREAKER ALIGNED



* = CUSTOMER CONNECTION
 DIMENSIONS IN [] = MILLIMETERS

- GROUND LUGS: 3 x 1C #6-2/9 AL/CU
 NEUTRAL LUGS: 3 x 1C #6-25/24 AL/CU
 UTILITY LUGS: 1 x 1C #6-25/24 AL/CU PER POLE
 LOAD AND GENERATOR POLE LUGS: 1 x 1C #3-25/24 AL/CU PER POLE INCLUDING 1/4" POLE



DRAWINGS SUBJECT TO CHANGE WITHOUT NOTICE.

1 LINE DIAGRAM & PHYSICAL LAYOUT
 AUTOMATIC TRANSFER SWITCH AND 3 BREAKER GENERATOR BYPASS SYSTEM
 MODEL 1596 85 -NCL-250
 250 A, V, 3 Ø, W, Hz

INFORMATION ON THIS DRAWING IS THE PROPERTY OF THOMSON TECHNOLOGY. IT IS NOT TO BE USED DEPARTMENTALLY TO OUR INTERESTS.

- OPTIONS INCLUDED IN BYPASS SWITCH ENCLOSURE OPTIONS
- EEHAC 1
 - EEHAC 2
 - EEHAC 3
 - EEHAC 4
 - SOLID NEUTRAL
 - 3P
 - THREE POLE
 - 4P
 - FOUR POLE

DRAWINGS AND/OR OTHER TECHNICAL INFORMATION SHOWN HEREON ARE THE PROPERTY OF THOMSON TECHNOLOGY. IT IS NOT TO BE USED DEPARTMENTALLY TO OUR INTERESTS.

DATE	06-06-18	DESIGNER	SM
DRAWING NO.	88008105	CHECKED BY	NS
SHEET	1/1	APPROVED BY	3

PROJECT	
SERIAL NUMBER	
CUSTOMER	

AS BUILT DATE	TESTED BY


REFER TO MANUAL FOR INFORMATION

LEGEND	
ISOLATION PLUG	
OPTIONAL ITEMS	


- NOTES**
- 1 - BYPASS SWITCH BREAKERS ARE MANUALLY INTERLOCKED. THE BREAKER A SLIDE BAR INTERLOCK BYPASS IS CLOSED (OR OPEN) TRANSITION (SEE CHART AT RIGHT).
 - 2 - TRANSFER SWITCH BREAKERS ARE MANUALLY INTERLOCKED SO THAT ONLY ONE BREAKER IS CLOSED AT A TIME.
 - 3 - FOR 4 BREAKER UTILITY BYPASS, TEST CIRCUITS IN BYPASS SWITCH.
 - 4 - FOR 4 BREAKER GENERATOR BYPASS, TEST CIRCUITS IN BYPASS SWITCH.
 - 5 - FOR TRANSFER SWITCH OPTIONS SEE DRAWINGS 680083101 OF 68008401 OF 680085201.
 - 6 - PRESENT ONLY ON 120/208V, 240V 1Ø UNITS. REFERENCE DRAWING 68008401.

BREAKER	INTERLOCK POSITION				
	1	2	3	4	5
UTILITY BYPASS					
TRANSFER SWITCH					
GENERATOR BYPASS					
GENERATOR ISOLATE					
LOAD					
TEST					

✗ BREAKER INTERLOCK ALLOWED



INTERIOR VIEW
* = CUSTOMER CONNECTION





FRONT VIEW


SIDE VIEW

ENCLOSURE DATA
 HEIGHT: 35" (890mm)
 WIDTH: 25" (635mm)
 DEPTH: 12" (305mm)
 COLOUR: ASA #61 GREY

CONNECTION DATA
 GROUND LUGS: 6 x 1/2" #6-2/8 AL/CU.
 LOAD, UTILITY & GENERATOR LUGS: 1 x 1/2" #3-3/8" AL/CU PER POLE.



CAUTION: WHEN THE TEST CABLE IS CONNECTED, THE TRANSFER SWITCH CONTROL CIRCUITS ARE LIVE! ONLY QUALIFIED PERSONNEL SHOULD PERFORM TEST!



THOMSON TECHNOLOGY INC.

1 LINE DIAGRAM & PHYSICAL LAYOUT
AUTOMATIC TRANSFER SWITCH AND 5 BREAKER BYPASS SYSTEM

MODEL TSBD 854-MCUL-250

250 A, 3 Ø, W, 112

DATE: 95-09-18
 DRAWING NO: 68008105
 DES: SN 18
 REV: 1/1
 3

DRAWINGS SUBJECT TO CHANGE WITHOUT NOTICE. DIMENSION ON THIS DRAWING IS THE PROPERTY OF THOMSON TECHNOLOGY. IT IS NOT TO BE USED DETRIMENTALLY TO OUR INTERESTS.

- OPTIONS INCLUDED IN BYPASS SWITCH**
- EEMAC 1
 - EEMAC 2
 - 1/2" PREFERRED GASKETING
 - FOUR POLE
 - UTILITY & BYPASS BREAKER BYPASS U4B
 - GENERATOR & BREAKER BYPASS G4B

LEGEND

- ISOLATION PLUG
- OPTIONAL ITEMS

REFER TO MANUAL FOR CABLE CONNECTION INFORMATION

AS BUILT BY / TESTED BY

AS BUILT DATE




- NOTES
- IF SN OPTION IS USED THEN BOTH NEUTRAL BLOCKS MUST BE ELECTRICALLY CONNECTED.
 - TRANSFER SWITCH BREAKERS ARE MECHANICALLY INTERLOCKED SO THAT ONLY ONE BREAKER IS CLOSED AT A TIME.
 - BYPASS SWITCH BREAKERS ARE MECHANICALLY INTERLOCKED THROUGH A SLIDE BAR INTERLOCK. BYPASS SWITCH IS OPEN TRANSITION (SEE CHART BELOW).
 - FOR TRANSFER SWITCH OPTIONS SEE DRAWINGS 680008901 or 680008701 680008901.
 - TRANSFER SWITCH BUILT IN CONFIGURATION "XL".
 - NEUTRALS PRESENT ONLY ON 3 POLE VERSIONS.

BREAKER	BYPASS POSITION		NORMAL POSITION	
	GI	LI	GI	LI
GI	X			
LI		X		
GI			X	
LI				X

X = BREAKER RESISED ALLOWED

GROUND LUGS:
 FOR 480A UNITS,
 3" x 10" 86-2/8 AL/CO.
 FOR 690A UNITS,
 6" x 10" 86-25/8 AL/CO.

LOAD, UTILITY & GENERATOR LUGS, (INCLUDING NEUTRAL LUGS IF 4 POLE)
 FOR 480 & 690A UNITS,
 1" x 25/8-35/8-35/8 AL/CO.
 25/8-35/8-35/8 AL/CO.
 25/8-35/8-35/8 AL/CO.
 25/8-35/8-35/8 AL/CO.



* = CUSTOMER CONNECTION

FRONT VIEW
 DEPTH: 12" [305]
 COLOR: ASA 401 GREY
 DIMENSIONS IN () = MILLIMETERS



DRAWINGS SUBJECT TO CHANGE WITHOUT NOTICE.

1 LINE DIAGRAM & PHYSICAL LAYOUT
 AUTOMATIC TRANSFER SWITCH AND 3 BREAKER GENERATOR BYPASS SYSTEM

MODEL 1586 BS -T - - - - - A - - - - - V - - - - - W - - - - - HZ

DIMENSION ON THIS DRAWING IS THE PROPERTY OF THOMSON TECHNOLOGY. IT IS NOT TO BE USED EXCLUSIVELY TO OUR INTERESTS.

1 SINGLE 0-SIDE 480/690A 3 & 4 P.

DRAWINGS AND/OR OTHER TECHNICAL INFORMATION SUPPLIED BY THOMSON TECHNOLOGY ARE THE PROPERTY OF THOMSON TECHNOLOGY AND ARE NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT PERMISSION IN WRITING FROM THOMSON TECHNOLOGY.

DATE: 06-09-18
 DRAWING NO.: 63009202
 SHEET: 1/1

AUTH: NS
 REV: 2

REFER TO MANUAL FOR WIRING CONNECTIONS

LEGEND
 ISOLATION PLUG
 OPTIONAL ITEMS

AS BUILT BY: TESTED BY:

TRANSFER SWITCH CONFIGURATION

OPTIONAL ITEMS

ENCLOSURE OPTIONS

INCLUDED IN BYPASS SWITCH

OPTIONS

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1

EMAC 2

SOLID NEUTRAL

THREE POLE

FOUR POLE

TRANSFER SWITCH CONFIGURATION

SL

SR

XL

XR

EMAC 1







EMAC 2

SOLID NEUTRAL

THREE POLE

- NOTES**
- 1 - BYPASS SWITCH BREAKERS ARE MECHANICALLY INTERLOCKED THROUGH A ROTOR BAR INTERLOCK. (SEE CHART AT RIGHT).
 - 2 - TRANSFER SWITCH BREAKERS ARE MECHANICALLY INTERLOCKED SO THAT ONLY ONE BREAKER IS CLOSED AT A TIME.
 - 3 - FOR 4 BREAKER UTILITY BYPASS, DELETE NB AND ASSOCIATED CIRCUITS IN BYPASS SWITCH.
 - 4 - FOR 4 BREAKER GENERATOR BYPASS DELETE NB AND ASSOCIATED CIRCUITS IN BYPASS SWITCH.
 - 5 - FOR TRANSFER SWITCH OPTIONS SEE DRAWINGS 68008601 or 68008701 68008801.
 - 6 - NEUTRAL CONTROL REQUIRED ON 120/208/240V 3 POLE MODELS SEE DRAWING 68008701.

INTERLOCK POSITION	1	2	3	4	5
UTILITY BYPASS					
GENERATOR BYPASS					
LOAD ISOLATE					
GENERATOR ISOLATE					
LOAD					



CAUTION! WHEN THE TEST CABLE IS CONNECTED, THE TRANSFER SWITCH CONTROL CIRCUITS ARE LIVE! ONLY QUALIFIED PERSONNEL SHOULD PERFORM TEST!

1 STYLE 487/686A 3 POLE ONLY



DRAWINGS SUBJECT TO CHANGE WITHOUT NOTICE.

MODEL TSB0 653-TCU-

AUTOMATIC TRANSFER SWITCH AND 5 BREAKER BYPASS SYSTEM

PROJECT: _____

DATE: _____

DRAWING NO.: _____

SHEET: _____

REV: _____

OPTIONAL INCLUDE IN BYPASS SWITCH

ENCLOSURE OPTIONS

-EMAC 1

-EMAC 2

SOLID NEUTRAL

UTILITY 4 BREAKER BYPASS

GENERATOR 4 BREAKER BYPASS

THREE POLE

TRANSFER SWITCH CONFIGURATION

-SL

-SR

-XL

-XR

LEGEND

REFER TO MANUAL FOR INFORMATION

AS BUILT BY/ DATE	TESTED BY


DRAWINGS AND/OR OTHER TECHNICAL INFORMATION SUPPLIED BY THOMSON TECHNOLOGY INC. IS THE PROPERTY OF THOMSON TECHNOLOGY. IT IS NOT TO BE USED OR REPRODUCED IN ANY MANNER WITHOUT THE WRITTEN PERMISSION OF THOMSON TECHNOLOGY.

NOTES


- 1 - BYPASS SWITCH BREAKERS ARE MECHANICALLY INTERLOCKED THROUGH A SLIDE BAR INTERLOCK TRANSITION (SEE CHART AT RIGHT).
- 2 - TRANSFER SWITCH BREAKERS ARE MECHANICALLY INTERLOCKED SO THAT ONLY ONE BREAKER IS CLOSED AT A TIME.
- 3 - FOR 4 BREAKER UTILITY BYPASS, DELETE GB AND ASSOCIATED CIRCUITS IN BYPASS SWITCH.
- 4 - FOR 4 BREAKER GENERATOR BYPASS DELETE NB AND ASSOCIATED CIRCUITS IN BYPASS SWITCH.
- 5 - FOR TRANSFER SWITCH OPTIONS SEE DRAWINGS 68008501 or 68008701 or 68008801.
- 6 - REQUIRED ONLY FOR 120/208V 240V 1Ø. SEE REFERENCE DRAWING 68008701.

BREAKER	INTERLOCK POSITION				
	1	2	3	4	5
1					
2					
3					
4					
5					

✕ = BREAKER CLOSURE ALLOWED



INTERIOR VIEW
* = CUSTOMER CONNECTION



FRONT VIEW




SIDE VIEW

ENCLOSURE DATA

HEIGHT: 76" (1930mm)
WIDTH: 69" (1753mm)
DEPTH: 41" (1041mm)
WEIGHT: 1250 lbs (567 kg)
COLOUR: ASA #61 GREY

CONNECTION DATA

GROUND LUGS: FOR 480A UNITS, AL/Cu
FOR 600A UNITS, AL/Cu
6 x 1C 2/0-350KCMH CU OR
2C 4/0-550KCMH AL/Cu
LOAD, UTILITY & GEN. UNITS;
GENERATOR LUGS: 1 x 2C 2/0-350KCMH CU OR
2C 4/0-550KCMH AL/Cu PER POLE



CAUTION: WHEN THE TEST CABLE IS CONNECTED, THE TRANSFER SWITCH CONTROL CIRCUITS ARE LIVE! ONLY QUALIFIED PERSONNEL SHOULD PERFORM TEST!



1 LINE DIAGRAM & PHYSICAL LAYOUT
AUTOMATIC TRANSFER SWITCH AND 5 BREAKER BYPASS SYSTEM

MODEL T580 851-1
A, V, 3 Ø, W, HZ

DATE: 68-05-19
DRAWING NO.: 68008208
REV: 1/1

DRAWINGS SUBJECT TO CHANGE WITHOUT NOTICE.

DISCLAIMER: ON THIS DRAWING IS THE PROPERTY OF THOMSON TECHNOLOGY. IT IS NOT TO BE USED OR REPRODUCED WITHOUT OUR INTERESTS.

DATE	BY	CHK	APP
68-05-19	SM	SM	NS
68008208	1/1		3

AS BUILT BY	TESTED BY

LEGEND
ISOLATION PLUG
OPTIONAL ITEMS

THOMSON TECHNOLOGY INC.

▽ NOTES

- 1 - BYPASS SWITCH BREAKERS ARE MECHANICALLY INTERLOCKED THROUGH A SLIDE BAR INTERLOCK. BYPASS IS CLOSED (OR OPEN) TRANSITION (SEE CHART AT RIGHT).
- 2 - TRANSFER SWITCH BREAKERS ARE MECHANICALLY INTERLOCKED SO THAT ONLY ONE BREAKER IS CLOSED AT A TIME.
- 3 - FOR 4 BREAKER UTILITY BYPASS, DELETE GB AND ASSOCIATED CIRCUITS IN BYPASS SWITCH.
- 4 - FOR 4 BREAKER GENERATOR BYPASS DELETE NB AND ASSOCIATED CIRCUITS IN BYPASS SWITCH.
- 5 - FOR TRANSFER SWITCH OPTIONS SEE SCHEMATIC DIAGRAM.
- 6 - NEUTRAL CONTROL REQUIRED ON 120/208/240V 1 OR 3 POLE MODELS.


BREAKER	INTERLOCK POSITION			
	UTILITY BYPASS	TRANSFER INTERLOCKING		
	1	2	3	4
NI		X	X	X
NB	X		X	X
LJ		X		X
GI		X	X	

X - BREAKER CLOSURE ALLOWED

CONNECTION DATA

SUPPLY/LOAD: FOR 800A UNITS:
1 - 3C 2/0-400MCM Al/Cu
PER PHASE / NEUTRAL

GROUND: FOR 800A UNITS:
9C #6-250MCM Al/Cu



FRONT VIEW

FOIL LABEL (TYPICAL)
SILVER LETTERS ON
RED BACKGROUND

WARNING

MORE THAN ONE LIVE CIRCUIT
SEE DIAGRAM

AVERTISSEMENT


PLUS D'UN CIRCUIT SOUS
TENSION VOIR SCHEMA

WARNING

DISCONNECT ALL SOURCES OF
SUPPLY BEFORE SERVICING

AVERTISSEMENT


COUPER TOUTES LES SOURCES
D'ALIMENTATION AVANT DE FAIRE
L'ENTRETIEN ET LES REPARATIONS



APPROVED FOR CONSTRUCTION
 MASTER COPY REFERENCE COPY OF _____
 MULTIPLE UNIT WORK ORDER
 RELEASED FOR INFORMATION
 AUTH. BY: _____ DATE: _____

DRAWING No.	REFERENCE DRAWINGS	No.	REVISIONS
-------------	--------------------	-----	-----------

STAND



INTERIOR VIEW (DOORS NOT SHOWN)

RHS VIEW

ENCLOSURE TYPE

- NEMA 1
- NEMA 2
C/W DRIPHOOD
- COLOUR: ASA-61 GREY

SIZE (AMPS)



- 800A
- 1000A
- 1200A
- 3 POLE ONLY
- SOLID NEUTRAL

- UTILITY 4 BREAKERS BYPASS
- GENERATOR 4 BREAKERS BYPASS

TRANSFER SWITCH CONFIGURATION

- SL
- SR
- XL
- XR

ARD 3Ø, 4W "SL" CONFIGURATION SHOWN



CAUTION: WHEN THE TEST CABLE IS CONNECTED, THE TRANSFER SWITCH CONTROL CIRCUITS ARE LIVE! ONLY QUALIFIED PERSONNEL SHOULD PERFORM TEST!


SPECIAL REQUIREMENTS:

DRAWINGS AND OR OTHER TECHNICAL INFORMATION SUPPLIED BY THOMSON TECHNOLOGY INC AS A PART OF A SALE OF EQUIPMENT ARE FOR THE PURCHASER'S USE SOLELY IN CONJUNCTION WITH THAT EQUIPMENT, UNLESS SPECIFICALLY AGREED TO OTHERWISE AS A PART OF THE TERMS OF SALE.


CUSTOMER			
OWN BY SH	AUTH BY BD	DATE 00-09-11	REV 0
DRAWING No. ELB14444_01_01_01			SHEET 1/2



ATS & 4 BREAKER BYPASS SYSTEM
MODEL TSBU-850
1-LINE DIAGRAM, LAYOUT & INSTALLATION DETAILS
800, 1000, 1200A



APPROVED FOR CONSTRUCTION
 MASTER COPY REFERENCE COPY _____ OF _____
 MULTIPLE UNIT WORK ORDER
 RELEASED FOR INFORMATION
 AUTH. BY: _____ DATE: _____



FOR TSC800 CONTROLLER OPTIONS, REFER TO PROGRAMMING SHEETS

2 SYSTEM MUST UTILIZE A SOLIDLY GROUNDED NEUTRAL

COLOUR KEY

BLACK	BK
BLUE	BE
BROWN	BN
GREEN	GN
GREY	GY
ORANGE	OR
PURPLE	PE
RED	R
WHITE	W
YELLOW	Y
SOLID/TRACER(S)	

DRAWINGS AND/OR OTHER TECHNICAL INFORMATION SUPPLIED BY THOMSON TECHNOLOGY INC AS A PART OF A SALE OF EQUIPMENT ARE FOR THE PURCHASER'S USE SOLELY IN CONJUNCTION WITH THAT EQUIPMENT, UNLESS SPECIFICALLY AGREED TO OTHERWISE AS A PART OF THE TERMS OF SALE.



SCHMATIC DIAGRAM
AUTOMATIC TRANSFER SWITCH
MODEL TS 853-TCK-800A-208
 800A 208V 3φ 4W 60Hz

CUSTOMER

DWN BY SH	AUTH BY BD	DATE 00-09-11	REV 0
DRAWING No. F1B14444 01 01 02			SHEET 2/2

FOIL LABEL
 BLACK LETTERS ON
 SILVER BACKGROUND

SERVICE DISCONNECT INSTRUCTIONS

TO DISCONNECT UTILITY AND
 GENERATOR SUPPLIES:

- *MOVE SERVICE DISCONNECT SWITCH TO THE "DISCONNECTED" POSITION
- *LOCK OFF SERVICE DISCONNECT SWITCH WITH SUITABLE PADLOCK
- *VERIFY LOAD IS DISCONNECTED VIA ILLUMINATED "SERVICE DISCONNECTED" LIGHT. IF LIGHT IS NOT ILLUMINATED, REFER TO INSTRUCTION MANUAL
- *LOCK ENCLOSURE DOOR CLOSED AND REMOVE KEY.

TO RE-ENERGIZE TRANSFER
 SWITCH:

- *REMOVE APPLICABLE PADLOCKS AND MOVE SERVICE DISCONNECT SWITCH BACK TO THE "ENERGIZED" POSITION
- *REPLACE ENCLOSURE DOOR KEY IF FUTURE ACCESS REQUIRED.
- *RESET TSC800 CONTROLLER IF DISPLAYING 'TRANSFER FAILURE'.

APPROVED FOR CONSTRUCTION
 MASTER COPY REFERENCE COPY _____ OF _____
 MULTIPLE UNIT WORK ORDER
 RELEASED FOR INFORMATION
 AUTH. BY: _____ DATE: _____

		2	CHANGE TO 3 PHASE
		1	AS BUILT
DRAWING No.	REFERENCE DRAWINGS	No.	REVISIONS

WARNING

TO ENSURE SAFETY OF PERSONNEL,
DOOR MUST BE LOCKED CLOSED
WHEN USING THE "SERVICE
DISCONNECT" SWITCH TO
ISOLATE LOAD CIRCUITS.

FASTEN DOOR SECURELY WITH
SCRWS BEFORE LOCKING

2X3/4 (TYPICAL)
WHITE LETTERS ON
BLACK BACKGROUND

SERVICE DISCONNECT

ENERGIZED DISCONNECTED

QTY = 1

SERVICE DISCONNECTED


QTY = 1

DRAWINGS AND OR OTHER TECHNICAL
INFORMATION SUPPLIED BY THOMSON
TECHNOLOGY INC AS A PART OF A
SALE OF EQUIPMENT ARE FOR THE
PURCHASER'S USE SOLELY IN
CONJUNCTION WITH THAT EQUIPMENT,
UNLESS SPECIFICALLY AGREED TO
OTHERWISE AS A PART OF THE TERMS
OF SALE.




LABEL DETAILS
SERVICE ENTRANCE
TRANSFER SWITCH

CUSTOMER			
DWN BY SH	AUTH BY BD	DATE 00-04-26	REV 2
DRAWING No. ELB13985_01_01			SHEET 2/3



FRONT VIEW (TYPICAL)



GROUND LUGS: FOR 800A UNITS:
9C #6-250MCM Al/Cu.
FOR 1000 & 1200A UNITS:
12C #6-250MCM Al/Cu.

LOAD, UTILITY & GENERATOR LUGS: FOR 800A UNITS:
1-3C 2/0-400MCM Al/Cu.
PER PHASE / NEUTRAL.
FOR 1000 & 1200A UNITS:
1-4C 3/0-500MCM Al/Cu.
PER PHASE / NEUTRAL

FOIL LABEL (TYPICAL)
SILVER LETTERS ON
RED BACKGROUND

WARNING
MORE THAN ONE LIVE CIRCUIT
SEE DIAGRAM

AVERTISSEMENT
PLUS D'UN CIRCUIT SOUS
TENSION VOIR SCHEMA


WARNING
DISCONNECT ALL SOURCES OF
SUPPLY BEFORE SERVICING

AVERTISSEMENT
COUPER TOUTES LES SOURCES
D'ALIMENTATION AVANT DE FAIRE
L'ENTRETIEN ET LES REPARATIONS

MATERIAL: 12GA. C.R.S. or H.R. P & O EXCEPT AS SPECIFIED.
CONSTRUCTION: FULLY WELDED, NEMA 3R, WEATHERPROOF.
FINISH: PAINTED EXTERIOR ENAMEL, ASA #61 GREY.

APPROVED FOR CONSTRUCTION
 MASTER COPY REFERENCE COPY _____ OF _____
 MULTIPLE UNIT WORK ORDER
 RELEASED FOR INFORMATION
AUTH. BY: _____ DATE: _____

DRAWING No.	REFERENCE DRAWINGS	No	REVISIONS
		2	CHANGE TO 3 PHASE
		1	AS BUILT



FRONT VIEW
DOOR NOT SHOWN

ENCLOSURE TYPE

- NEMA 3R (SINGLE DOOR)
- NEMA 3R (DOUBLE DOOR)

SIZE (AMPS)

- 400A (S.E. ONLY)
- 600A (S.E. ONLY)
- 800A
- 1000A
- 1200A
- 3 POLE
- 4 POLE
- SOLID NEUTRAL

TRANSFER SWITCH CONFIGURATION

- SL
- SR
- XL
- XR

SPECIAL REQUIREMENTS:

DRAWINGS AND/OR OTHER TECHNICAL INFORMATION SUPPLIED BY THOMSON TECHNOLOGY INC AS A PART OF A SALE OF EQUIPMENT ARE FOR THE PURCHASER'S USE SOLELY IN CONJUNCTION WITH THAT EQUIPMENT, UNLESS SPECIFICALLY AGREED TO OTHERWISE AS A PART OF THE TERMS OF SALE.

CUSTOMER			
OWN BY SH	AUTH BY BD	DATE 00-04-26	REV 2
DRAWING No. ELB13985_01_01		SHEET 1/3	

NOTE: STANDARD "SL" CONFIGURATION SHOWN;
UTILITY SUPPLY ON TOP, LOAD OUT LEFT;
3 ϕ /4W SYSTEM WITH SOLIDLY GROUNDED NEUTRAL


DIMENSION	SINGLE DOOR	DOUBLE DOOR
A	14"	18"
B	N/A	14"
C	12"	16"



AUTOMATIC TRANSFER SWITCH
MODEL TS 850T
PHYSICAL LAYOUT AND INSTALLATION DETAILS

SH	BD	00-10-02
SH	BD	00-06-07
BY	AUTH	DATE

*Trip units
Are fixed unless specified*



FOR TSC800 CONTROLLER OPTIONS, REFER TO PROGRAMMING SHEETS

1 SYSTEM MUST UTILIZE A SOLIDLY GROUNDED NEUTRAL

4 HIGH POLARITY MARKER

PT TAP	VOLTAGE				
	208	240	400	480	600
H1	X	X	X	X	X
H2	X	X	X	X	X
H3	X	X	X	X	X
H4	X	X	X	X	X
H5	X	X	X	X	X

COLOUR KEY	
BLACK	BK
BLUE	BE
BROWN	BN
GREEN	CN
GREY	CY
ORANGE	OR
PURPLE	PE
RED	R
WHITE	W
YELLOW	Y
SOLID/TRACER(S)	


DRAWINGS AND OR OTHER TECHNICAL INFORMATION SUPPLIED BY THOMSON TECHNOLOGY INC AS A PART OF A SALE OF EQUIPMENT ARE FOR THE PURCHASER'S USE SOLELY IN CONJUNCTION WITH THAT EQUIPMENT, UNLESS SPECIFICALLY AGREED TO OTHERWISE AS A PART OF THE TERMS OF SALE.



SCHMATIC DIAGRAM
AUTOMATIC TRANSFER SWITCH
MODEL TS 853-TCK-800B-208-SE
800A, 208V, 3Ø 4W, 60Hz

CUSTOMER			
OWN BY	AUTH BY	DATE	REV
SH	BD	00-04-26	2
DRAWING No.			SHEET
ELB13985_01_01			3/3

SH	BD	00-10-02
SH	BD	00-06-07
BY	AUTH	DATE



TS 890

TS 890

AUTOMATIC TRANSFER SWITCH

INSTALLATION, OPERATING, & SERVICE MANUAL



PM045 Rev 3 00/02/29

TABLE OF CONTENTS

1. CAUTION!	1
2. NOTE TO INSTALLER	1
3. GENERAL DESCRIPTION	3
4. GENERAL SEQUENCE OF OPERATION	3
4.1. TYPE A TRANSFER SWITCH	3
4.2. TYPE B TRANSFER SWITCH	4
4.3. SERVICE ENTRANCE RATED TRANSFER SWITCH	5
5. TYPE A AND TYPE B DEFINITION	8
6. GENERAL NOTES ON SERVICING	8
7. TRANSFER SWITCH MECHANISM DRAWING	10
8. TS 890 TRANSFER MECHANISM - 800 THROUGH 3200 AMP	11
8.1. MANUAL OPERATION	11
9. TRANSFER MODE SELECTOR	11
10. RECOMMENDED MAINTENANCE	12
11. TROUBLESHOOTING	13
12. CIRCUIT BREAKER TROUBLESHOOTING	14
13. REQUIREMENTS FOR UPSTREAM CIRCUIT PROTECTIVE DEVICES	16
14. CABLE LUG TIGHTENING TORQUE VALUES	17
15. CIRCUIT BREAKER DRAWING	18
16. DRAWOUT CHASSIS ENGINEERING DRAWING	19
17. WIRING DIAGRAM ENGINEERING DRAWING	20
18. NOTES	21

1. CAUTION!

Before opening the transfer switch enclosure to perform any service task, or to manually transfer the mechanism, it is imperative to isolate the transfer switch from any possible source of power. Failure to do so may result in serious personal injury or death due to electrical shock.

Service procedures must be undertaken by qualified personnel only!

NOTE:- All information contained in this manual is for reference only, and is subject to change without notice.


Contact Thomson Technology Inc. for clarification of current revisions or if in doubt about any matter relating to installation, operation or maintenance.

This revision Instruction Manual is intended for TS 890 Transfer Switch products which have been manufactured subsequent to the revision date. For products manufactured previous to this date contact Thomson Technology to obtain applicable manuals.

2. NOTE TO INSTALLER

To ensure satisfactory installation of this equipment be sure to observe "Recommended Connection Tightness" and "Requirements for Upstream Circuit Protective Devices" located in this manual.

All mechanical and electrical connections must be checked for tightness prior to placing this equipment in service to ensure proper operation and to validate applicable warranty coverage. If the transfer switch has programmable multi-tap voltage capability (refer to electrical schematic), confirm the transfer switch has been configured for the system voltage prior to installation.



The voltage selections and connections are shown on the electrical schematics attached to each transfer switch. The factory default settings will be indicated on the calibration label attached on the

inside of the enclosure door (supplied loose on open style models). A blank label is included to record the applicable settings if the configuration is changed from the factory default settings.

To change the transfer switch configuration the following must be accomplished:

- Change voltage taps of PT's to system voltage (refer to schematics)
- Change TSC 800 programming (refer to sections 6.2.2, 6.2.4, 6.2.5, 6.3, and 6.4 of the TSC 800 instruction manual). The following settings may require reprogramming (depending on options purchased):

- System voltage
 - System frequency
 - System phase
 - Utility undervoltage pickup (typically 90% of system voltage)
 - Utility undervoltage dropout (typically 80% of system voltage)
 - Utility overvoltage pickup (typically 110% of system voltage)
 - Utility overvoltage dropout (typically 105% of system voltage)
 - Utility underfrequency (typically 95% of system frequency)
 - Utility overfrequency (typically 105% of system frequency)
- Generator undervoltage pickup (typically 90% of system voltage)
- Generator undervoltage dropout (typically 80% of system voltage)
- Generator overvoltage pickup (typically 110% of system voltage)
- Generator overvoltage dropout (typically 105% of system voltage)
- Generator underfrequency (typically 95% of system frequency)
- Generator overfrequency (typically 105% of system frequency)

Record any changed setting on the TSC 800 Programming Data Sheets for future reference.

Complete the blank calibration label and attach to the inside of the transfer switch enclosure door.

INSTALLATION OF OPEN TYPE TRANSFER SWITCHES - Please refer to the factory for additional information.

3. GENERAL DESCRIPTION

(See **CAUTION!** on Page #1)

The automatic transfer switch employs two moulded-case switching devices which may be:

- a) non-automatic circuit interrupters ("type A" transfer switch)
- b) automatic circuit interrupters with integral trip units; ("type B" transfer switch)

In this manual, the switching devices will be referred to as "breakers". The breakers are independently operated by motor operated mechanisms within each breaker. The transfer switch provides automatic transfer of an electrical load to a standby power supply in the event of drop or loss of voltage of any or all phases of the primary power supply. Upon restoration of the primary supply, the electrical load is automatically retransferred to the primary power supply (after an adjustable time delay). All necessary control components for automatic transferring are located in the control compartment and on each associated breaker.

The transfer motor utilizes the power from the source to which the electrical load is being transferred. The mechanism provides a positive mechanical interlock to prevent both breakers from being closed at the same time. The mechanism is also designed to leave both breakers "trip free" in the closed position, permitting incorporation of overload and/or short-circuit protection in either or both breakers ("type B"). After tripping, the breaker of a "type B" transfer switch must be manually reset.

Note: For the purpose of this manual, the term UTILITY indicates the primary power, and the term GENERATOR indicates the standby power.

4. GENERAL SEQUENCE OF OPERATION

4.1. TYPE A TRANSFER SWITCH

When utility supply voltage drops below a preset nominal value (70-100% of rated adjustable) on any phase, an engine start delay circuit will be initiated and the transfer to utility supply signal will be removed (i.e. contact opening). Following expiry of the engine start delay period an engine start signal (contact closure) will be given.

Once the engine starts, the transfer switch controller will monitor the generator's output voltage. Once the generator voltage and frequency rises above preset values (70 - 100% nominal adjustable), the transfer to generator supply signal (contact closure) will be given to

the transfer switch mechanism. This will trip open the utility supply breaker and following a neutral time delay period (0 - 10 sec adjustable) will close the generator supply breaker to re-energize the load.

The generator will continue to supply the load until the utility supply has returned and the retransfer sequence is completed as follows: When the utility supply voltage is restored to above the preset values (70 - 100% of rated adjustable) on all phases, a transfer return delay circuit will be initiated. Following expiry of the transfer return timer (0 - 30 min. adjustable), the transfer to generator supply signal will be removed (contact opening). This will trip open the generator supply breaker and following a neutral time delay period (0 - 10 sec adjustable) will close the utility supply breaker to re-energize the load.

An engine cooldown timer circuit will be initiated once the load is transferred from the generator supply. Following expiry of the cooldown delay period (0 - 30 min. adjustable) the engine start signal will be removed (contact opening) to initiate stopping of the generator set.

4.2. TYPE B TRANSFER SWITCH

The general sequence of operation for a type B transfer switch is identical to the type A transfer switch except for the following conditions:

4.2.1. Overcurrent Trip of Utility Transfer Breaker

Should the utility transfer breaker (UCB) contain an overcurrent trip device and it is activated due to an overcurrent condition on the load, the transfer switch logic will issue an engine start signal and will force a transfer to the generator supply (if within normal voltage and frequency limits). The transfer to the generator supply will occur irrespective of the utility supply voltage condition. The generator will remain on load until the UCB "tripped" indicator (on the breaker) is manually reset and the utility supply is within normal limits. **Note:** Type B transfer switches will be supplied with the above logic as standard. Other optional logic configurations may be installed on the transfer switch. Contact the TTI factory for further information.

4.2.2. Overcurrent Trip of Generator Transfer Breaker

Should the generator transfer breaker (GCB) contain an overcurrent trip device and it is activated due to an overcurrent condition on the load, the transfer switch logic will cause a transfer to the utility supply (if within normal voltage and frequency limits). The transfer to the utility supply will occur irrespective of the generator supply voltage condition. The transfer switch will not transfer to the generator supply should a subsequent utility failure occur until the GCB "tripped" indicator (on the breaker) is manually reset and the generator supply is within normal limits. **Note:** Type B transfer switches will be supplied with the above logic as standard. Other optional logic configurations may be installed on the transfer switch. Contact the TTI factory for further information.

4.3. SERVICE ENTRANCE RATED TRANSFER SWITCH

(Note: This applies only to service entrance transfer switches supplied with a Padlockable Disconnect Switch. Contact TTI for other types.)

4.3.1. Normal Operation

Under normal conditions, the load is energized from the utility supply through the closed utility transfer breaker. If the utility power fails, the generator will start and the load will be re-energized via the closed generator transfer breaker.

In the normal operating mode, the Service Disconnect switch shall be in the "energized" position.

4.3.2. SERVICE DISCONNECT PROCEDURE

To perform a service disconnect (i.e. to disconnect the utility and generator supplies), the following procedure is required:

1. Move the "Service Disconnect" control switch located on the door of the transfer switch to the "Disconnected" position.
2. Verify that the "Service Disconnected" pilot light is illuminated. *If the Light is illuminated, the service has been successfully disconnected and it is safe to perform any maintenance procedures as required.* In this condition, the transfer switch is in the neutral position, with both utility and transfer breakers open. The transfer switch will remain in this condition, regardless of condition of the utility and generator supplies (i.e. if the utility power fails, the generator will not receive a start condition,

nor will the transfer switch move to the generator position). If the Light is not illuminated, further procedures are required (refer to the following procedure #4).

3. Attach safety lockout padlock to the "Service Disconnect" control switch to prevent unauthorized change in operating condition and verify transfer switch door is locked closed. If the door is not locked, turn and remove door key.

4. If the "Service Disconnected" pilot light is **not** illuminated, the service will **not** have been successfully disconnected and it is therefore **not** safe to perform any maintenance until the following additional procedures are performed:

Warning

Qualified personnel must undertake the following procedures only. Failure to do so may result in serious personal injury or death due to electrical shock.

- Open the door to the transfer switch using a suitable tool and opening the door lock with the key.
- Visually inspect the actual position of the transfer switch mechanism. If the position of the transfer switch mechanism is clearly in the "neutral position", the service has been successfully disconnected.

Notes: 1) If the position of the transfer switch mechanism is clearly in the "neutral position, the "service disconnected" pilot light may not have illuminated due to the following reasons:

- a) Utility and generator supply voltages are not present (the pilot light requires AC supply voltage to be present).
- b) The pilot light may be burnt out. The bulb should be immediately replaced with a suitably rated bulb.
- c) Failure of one or more of the sensing/logic contacts. A qualified service technician is required to trouble shoot this specific condition. Unplug the control circuit isolation plug to de-energize all AC power to the control circuits. Note: The AC power conductors will still remain energized. Once the control circuit isolation plug is removed the "Service Disconnected" pilot light will not illuminate due to loss of control power.

Note: to return the transfer switch back to normal operation, the control circuit isolation plug must be reconnected for correct operation.

- The transfer switch door should then be securely closed using a suitable tool and locked in the closed position with the key. Once the transfer switch door has been positively locked closed and secured and only then is, it is safe to perform any maintenance procedures as required.
- If the position of the transfer switch mechanism is **not** in the "neutral position" further procedures are required (refer to the following procedure)

Warning

Failure to positively lock closed and secure the transfer switch door may result in **serious personal injury or death** due to electrical shock.

- If the position of the transfer switch mechanism is **not** in the "neutral position" the transfer switch mechanism must be manually operated as follows. To operate manually, pull the manual release plunger on the mechanism, releasing the motor drive rod from motor drive arm and move the knob and yoke to the marked "**Neutral**" position.

Warning

Failure to move the mechanism to the Neutral Position may result in **serious personal injury or death** due to electrical shock.

The transfer switch door should then be securely closed using a suitable tool and locked in the closed position with the key. Once the Transfer switch door has been positively locked closed and secured and only then is, it is safe to perform any maintenance procedures as required.

Warning

Failure to positively lock closed and secure the transfer switch door may result in **serious personal injury or death** due to electrical shock.

To re-energize the load, the padlock(s) should be removed from the "Service Disconnect" control switch, and move the switch to the "Energized" position. The transfer switch will immediately return to the utility or generator supply if within normal operating limits.

5. TYPE A AND TYPE B DEFINITION

"Type A" transfer switch means an automatic transfer switch that does not employ integral overcurrent devices.

"Type B" transfer switch means an automatic transfer switch that does employ integral overcurrent protection (in at least one of its two breakers).

"Type A" transfer switches are not equipped with trip units, and require properly coordinated upstream protection. Information on closing and withstand ratings, and recommendations for maximum upstream protective devices for "type A" units are in this manual. (Some "type A" models do employ "high-magnetic" trips in the breakers, however these are set to trip at a higher than normal current for that amperage circuit, so that the possibility of tripping is very remote. Since these trips are not intended to provide overcurrent protection, but are rather employed to ensure the integrity of the transfer switch under all circumstances, they are still classed as "type A").

"Type B" transfer switches are typically equipped with standard thermal-magnetic trips which will provide the required overload and short circuit protection. "Type B" can also be built using solid state trip breakers, which can include ground fault tripping as well as overload and short circuit protection.

It should be noted that a "type B" transfer switch with overcurrent protection in only one breaker will require the same consideration for upstream protection in the feeder of the breaker with no trip (as applies to a "type A" transfer switch).

6. GENERAL NOTES ON SERVICING

(See **CAUTION!** on Page #1)


When performing any service work it is imperative that the following be observed:

- 6.1. To maintain mechanical integrity, ensure that:
 - All linkages are correctly adjusted.
 - Mechanical interlocking is correct - it should not be possible to close a breaker without first opening the other breaker.
 - All fasteners are adequately tightened.
 - The operating linkages are not damaged or bent, and that all bearing points operate freely.
- 6.2. To maintain electrical integrity, ensure that:

- All electrical connections, especially power connections, are clean and adequately tightened. Corroded or loose power connections will cause destructive heating, and may cause premature tripping in the type "B" units.
 - All insulating devices are in place and in good condition.
 - No moisture or other contamination is present.
 - Electrical conductors are adequately secured away from moving parts.
- 6.3. To maintain operational integrity, ensure that:
- All control devices are in good condition and correctly calibrated.
 - All control devices are adequately secured in their plug-in fixtures.

Service work should be undertaken only by qualified personnel. Failure to correctly maintain an automatic transfer switch may represent a hazard to life and equipment. Full operational testing must be done prior to placing a transfer switch in service subsequent to any maintenance or repair. Any service work involving electrical components requires high-potential testing to ensure that required insulation levels have been maintained.

7. TRANSFER SWITCH MECHANISM DRAWING



© ENGINEER PRODUCTS INC. 02/91 VSD Rev. D

8. TS 890 TRANSFER MECHANISM - 800 THROUGH 3200 AMP

The transfer mechanism consists of two electrically operated breakers and a mechanical interlock.

The transfer switch mechanism has three possible positions:

- a) The utility breaker closed and the generator breaker open;
- b) The generator breaker closed and the utility breaker open;
- c) Both the utility and the generator breakers open; but **NEVER** both the utility and generator breakers closed at the same time.

8.1. MANUAL OPERATION

(See **CAUTION!** on Page#1)

Isolate the transfer switch from both sources of power before opening the enclosure for manual switching!

9. TRANSFER MODE SELECTOR

This is a two position selector switch that selects the required mode of operation of the transfer switch as described below.

- 9.1. **AUTO:** This selects automatic operation of the transfer switch. The transfer breakers will automatically open/close as detailed in the sequence of operation.
- 9.2. **MAN:** This position inhibits automatic operation. The transfer switch breakers must be manually operated via pushbuttons located on the face of the circuit breakers to open/close them as required.

To transfer manually to generator - turn the transfer mode selector to MANUAL, trip T/S utility breaker, close T/S generator breaker, using breaker trip/close pushbuttons.

To transfer manually to utility - trip T/S generator breaker, close T/S utility breaker using breaker trip/close pushbuttons.

10. RECOMMENDED MAINTENANCE

(See **CAUTION!** on Page # 1)

- 10.1. DO NOT perform dielectric tests on the equipment with the control components in the circuit.
- 10.2. Check if control components are tight in sockets.
- 10.3. Periodically inspect all terminals (load, line and control) for tightness. Re-torque all bolts, nuts and other hardware. Clean or replace any contact surfaces which are dirty, corroded or pitted.
- 10.4. Transfer switches should be in clean, dry and moderately warm locations. If signs of moisture are present, dry and clean transfer switch. If there is corrosion, try to clean it off. If cleaning is unsuitable replace the corroded parts. Should dust and/or debris gather on the transfer switch, brush, vacuum, or wipe clean. DO NOT blow dirt into the breaker or terminals.
- 10.5. Test the transfer switch operation. While the unit is exercising, check for freedom of movement, hidden dirt or corrosion and any excessive wear on the mechanical operating parts.
- 10.6. Check all adjustable control components (time delay and voltage sensing relays) for correct settings.

11. TROUBLESHOOTING

(See CAUTION! on Page #1)

Symptom

- will not re-transfer to utility source upon restoration

- will not transfer to generator source upon failure of utility source

- transfer to generator source without a power failure in the utility source

- generator does not start up or stop when it should

- no time delay when there should be

- power is not available at the load terminals but the utility or generator breaker appears to be closed to a live source

Possible Causes

- control wiring isolation plug is removed

- a test mode has been activated (check TSC 800 status LCD display)
- transfer mode selector is not in "auto" position
- utility voltage or frequency is outside the pre-programmed limits (check utility source for adequate voltage & frequency)
- a loose control connection
- faulty circuit breaker (refer to Circuit Breaker Troubleshooting)
- defective TSC 800 controller (verify output signals with circuit board mounted diagnostic LED's)

- control wiring isolation plug is removed

- generator set not producing enough voltage/frequency or output circuit breaker open
- warmup time delay function has not timed out yet (verify TSC 800 timer setting)
- transfer mode selector is not in "auto" position
- a loose control connection
- faulty circuit breaker (refer to Circuit Breaker Troubleshooting)
- defective TSC 800 controller (verify output signals with circuit board mounted diagnostic LED's)

- a test mode has been activated (check TSC 800 status LCD display)
- defective TSC 800 controller (verify output signals with circuit board mounted diagnostic LED's)

- verify remote engine control panel is set for automatic mode

- verify time delay function in the TSC 800 program setting as per programming sheets as supplied with the transfer switch

- the breaker's trip unit (Type B style only) has tripped on a fault on the system. Correct the fault, and manually reset the breaker in the transfer switch.

DEFECTIVE COMPONENTS

Return defective components to Thomson Technology Inc. for repair. Be sure to advise model and serial number of the transfer switch.

12. CIRCUIT BREAKER TROUBLESHOOTING

MALFUNCTIONS

The circuit breaker cannot be opened locally.

- Open push-button locked.
- Faulty mechanism or main circuits bonded.

The circuit breaker cannot be manually closed.

- Circuit breaker closing on short-circuit.
- Fault trip indicator-button not reset. (Type B T/S's)
- Circuit breaker not fully connected. (drawout type only)
- Anti-pumping function.

- Circuit breaker not charged.

- Closing release XF continuously supplied.

- Shunt release MX supplied.

- Undervoltage release (instantaneous or delayed) not supplied or faulty.

- Circuit breaker locked in "open" position.

- Circuit breaker interlocked.

- Geared motor supply voltage too low (<0.85 Un).

The circuit breaker does not recharge electrically.

It is impossible to insert the racking handle to connect or to disconnect the circuit breaker.

- There is a padlock or a key-lock for connected or disconnected position. There is a racking interlock.
- The extraction rails or the breaker is not completely pushed in.

PROBABLE CAUSES

CORRECTIVE ACTIONS

- Remove the locking.
- Contact TTI Service Department.

- Clear the fault. Check circuit breaker condition before putting back into operation.

- Reset fault trip indicator-button.

- Connect circuit breaker fully.

- Cut the closing release XF power supply, then resupply the XF.

- Check the geared motor power supply (U>0.85 Un). Check the power supply circuit. Attempt a manual recharging. Replace the geared motor if necessary. (Contact TTI Service Dept.)

- Cut the closing release XF power supply and try again to close the breaker only if it is ready to close.

- Locate the causes of this power supply. Cut the MX power supply, then try to close with the XF.

- Supply the MN at U>0.85 Un, then try to close with the XF. If impossible, check with the escutcheon removed, that the MN is drawing properly. If not, replace it.

- Remove the locking.

- Check whether this refusal to close is not normal.

- Apply a voltage U<0.85 Un. Check the geared motor electrical circuit. Attempt to recharge manually. If problem: mechanism is faulty. Contact TTI Service Dept. If okay: geared motor faulty. Replace it.

- Remove disabling.

- Push the rails or the breaker completely in.

MALFUNCTIONS

PROBABLE CAUSES

CORRECTIVE ACTIONS

It is impossible to extract the right side rail (on chassis alone) or the breaker.	<ul style="list-style-type: none"> - The racking handle is remained inserted. - The breaker is not completely disconnected. - There is a padlock or a key-lock for connected or disconnected position. There is a racking interlock. 	<ul style="list-style-type: none"> - Remove the racking handle and put it in its storage. - Disconnect the breaker. - Remove disabling.
It is impossible to extract the circuit breaker whenever it is charged.	<ul style="list-style-type: none"> - There is an extraction locking when breaker is charged. 	<ul style="list-style-type: none"> - Discharge the circuit breaker (open, close then open again the circuit breaker). - If the circuit breaker is equipped with MN or MNR or MNRI: <ul style="list-style-type: none"> - cut the supply of MCH - come back in test position - supply the MN (or if it is impossible, remove the front cover and then release MN). - close the circuit breaker. - draw out the circuit breaker.
It is impossible to rack in the circuit breaker.	<ul style="list-style-type: none"> - The chassis does not correspond with the circuit breaker. - The plastic ties which hold clusters during transport are not removed. - The clusters positions are not correct. - There is a safety shutters locking. 	<ul style="list-style-type: none"> - Fit fouling-plate on your chassis and breakers to avoid new mistakes. - Remove the plastic ties. - Put them in order again. - Remove this locking.

13. REQUIREMENTS FOR UPSTREAM CIRCUIT PROTECTIVE DEVICES

Short Circuit Current Rating (Amps RMS Sym)

STANDARD MODELS (Type A)

Basic Model	Maximum Voltage	Rated Current (A)	Closing Rating (kA peak)	Short Circuit Current Rating (kA RMS)
TS 890 - 800A	600	800	105	50
TS 890 - 1000A	600	1000	105	50
TS 890 - 1200A	600	1200	105	50
TS 890 - 1600A	600	1600	105	50
TS 890 - 2000A	600	2000	105	50
TS 890 - 2500A	600	2500	105	50
TS 890 - 3200A	600	3200	105	50

STANDARD MODELS (Type B)

Basic Model	Maximum Voltage	Rated Current (A)	Closing Rating (kA peak)	Short Circuit Current Rating (kA RMS)
TS 890 - 800B	600	800	105	150
TS 890 - 1000B	600	1000	105	150
TS 890 - 1200B	600	1200	105	150
TS 890 - 1600B	600	1600	105	150
TS 890 - 2000B	600	2000	143	143
TS 890 - 2500B	600	2500	143	143
TS 890 - 3200B	600	3200	143	143

Please refer to the factory for further information on upstream protection requirements, if required.

INSTALLATION OF OPEN TYPE TRANSFER SWITCHES - Please refer to the factory for additional information.


14. CABLE LUG TIGHTENING TORQUE VALUES

TIGHTENING TORQUE IN INCH POUNDS

<u>LUG TYPE</u>	<u>CABLE CLAMP</u>
TA - 2/0	180
TA - 3/0	250
TA - 4/0	250
TA - 250	325
TA - 350	325
TA - 500	375
TA - 600	375
TA - 800	375
TA - 750	375
TA - 800	500
TA - 1000	500

15. CIRCUIT BREAKER DRAWING

circuit-breaker
disjoncteur



16. DRAWOUT CHASSIS ENGINEERING DRAWING

chassis
châssis

arc chute cover
capot sur chambres
de coupure

handling handgrip
poignée de manutention

2 disconnected position
carriage switches
2 contacts de position
"débroché"

auxillaries and control unit
connection block
borniers raccordement
des auxiliaires et de
l'unité de contrôle

door interlock
verrouillage
de porte

pull-out handgrip
poignée d'extraction

racking handle storage
rangement de la manivelle

functional position indicator "connected",
"test" and "disconnected"
témoin de position fonctionnelle "embroché",
"test" et "débroché".



terminal shield
capot bornier

4 connected position
carriage switches
4 contacts de position
"embroché"

safety shutters
volets isolants

padlockable slide
sabot de verrouillage
des volets

racking interlock
verrouillage
embrochage débrochage
porge ouverte

padlocking facilities for
connected or disconnected
position
verrouillage par cadenas en
position "embroché" ou
"débroché"

keylocks for "connected"
or "disconnected" positions
verrouillage par serrure en position
"embroché" ou "débroché"

racking handle
manivelle d'embrochage

18. NOTES

FOL LABEL (TYPICAL)
SILVER LETTERS ON
RED BACKGROUND

WARNING
MORE THAN ONE LIVE CIRCUIT
SEE DIAGRAM

AVERTISSEMENT
PLUS D'UN CIRCUIT SOUS
TENSION VOIR SCHEMA

WARNING
DISCONNECT ALL SOURCES OF
SUPPLY BEFORE SERVICING

AVERTISSEMENT
COUPER TOUTES LES SOURCES
D'ALIMENTATION AVANT DE FAIRE
L'ENTRETIEN ET LES REPARATIONS

2 x 6" (TYPICAL)

NP1

258-342
480V AUTOMATIC
TRANSFER SWITCH
(FEED TO PDC #3)

3/4 x 2" (TYPICAL)

TMS

TRANSFER
MODE

AUTO MANUAL

1 x 3" (TYPICAL)

UCB


UTILITY
TRANSFER
BREAKER

GCB

GENERATOR
TRANSFER
BREAKER

NOTES:

- 1) SWITCHBOARD SUPPLIED IN ONE PIECE.
 - 2) FRONT AND REAR ACCESS REQUIRED.
 - 3) EXTERIOR PAINT ASA #61 GREY.
 - 4) MAIN BUS RATING 2000A, 480, BRACED AT 75KA
 - 5) ALL BUS WILL BE COPPER.
 - 6) UTILITY CIRCUIT BREAKER IS M/G MASTERPACT
3P, 2000, NON-AUTO, ELECTRICALLY OPERATED,
FIXED TYPE.
 - 7) GENERATOR CIRCUIT BREAKER IS M/G MASTERPACT
3P, 2000, NON-AUTO, ELECTRICALLY OPERATED,
FIXED TYPE.
 - 8) AUTO TRANSFER SWITCH WIRING SHALL
BE #18-14 AWG TEW.
 - 9) NAMEPLATES TO BE BLACK WITH WHITE LETTERS.
 - 10) ENCLOSURE TYPE NEMA 1 CONSTRUCTION.
 - 11) GROUND LUGS 12 X #8 - 250MCM
- 2000A**
- 12) EMERGENCY SOURCE CABLES TOP ENTRY,
LUGS 2 HOLE LONG BARRELL = 1 X 1000MCM PER PHASE
 - 13) LOAD CABLES TOP ENTRY,
LUGS 2 HOLE LONG BARRELL = 3 X 1000MCM PER PHASE
 - 14) UTILITY CABLES BOTTOM ENTRY,
LUGS 2 HOLE LONG BARRELL = 6 X 1000MCM PER PHASE



FRONT VIEW
FINISH ASA #61 GREY

EQUIPMENT M
LOCATION: M

APPROVED FOR CONSTRUCTION


MASTER COPY REFERENCE COPY _____ OF _____

MULTIPLE UNIT WORK ORDER

RELEASED FOR INFORMATION

AUTH. BY: _____ DATE: _____

DRAWING No.	REFERENCE DRAWINGS	No.	REVISIONS
		2	AS BUILT
		1	CUSTOMER MODIFICATION



DOC.#: 258-342101

DRAWINGS AND OR OTHER TECHNICAL INFORMATION SUPPLIED BY THOMSON TECHNOLOGY INC AS A PART OF A SALE OF EQUIPMENT ARE FOR THE PURCHASER'S USE SOLELY IN CONJUNCTION WITH THAT EQUIPMENT, UNLESS SPECIFICALLY AGREED TO OTHERWISE AS A PART OF THE TERMS OF SALE.


CUSTOMER			
DWN BY MC	AUTH BY BD	DATE 00-05-11	REV 1
DRAWING No. ELB14004_01_01_01			SHEET 1/2

O: 258-342
CC ROOM NO 2

LM	BD	00-08-03	
MC	BD	00-06-19	
BY	AUTH	DATE	




AUTOMATIC TRANSFER SWITCH
MODEL TS 890
PHYSICAL LAYOUT
2000A/FOOTNER FOREST




APPROVED FOR CONSTRUCTION
 MASTER COPY REFERENCE COPY _____ OF _____
 MULTIPLE UNIT WORK ORDER
 RELEASED FOR INFORMATION
 AUTH. BY: _____ DATE: _____

DRAWING No. _____ REFERENCE DRAWINGS No. _____ 1 AS BUILT REVISIONS



*Side Access
Rear Access*



TRANSFER TO
UTILITY TIMER
TDPU = 3 SEC

TRANSFER TO
GENERATOR TIMER
TDPU = 3 SEC

LEGEND	
CC	BREAKER CLOSING COIL
GCB	GENERATOR TRANSFER BREAKER
GT	TRANSFER TO GENERATOR TIMER
GX	LOAD ON GENERATOR RELAY
M	BREAKER CHARGING MOTOR
PL12	WIRE CONNECTING PLUG
TC	BREAKER TRIP COIL
TMS	TRANSFER MODE SWITCH
TSC	TRANSFER SWITCH CONTROLLER
UCB	UTILITY TRANSFER BREAKER
UT	TRANSFER TO UTILITY TIMER
UX	LOAD ON UTILITY RELAY

FOR TSC800 CONTROLLER OPTIONS,
REFER TO PROGRAMMING SHEETS

DOC# 258-342101

COLOUR KEY	
BLACK	BK
BLUE	BL
BROWN	BN
GREEN	GN
GREY	GY
ORANGE	OR
PURPLE	PE
RED	R
WHITE	W
YELLOW	Y
SOLID/TRACER(S)	

AS BUILT BY/ AS BUILT DATE	TESTED BY
DRAWINGS AND OR OTHER TECHNICAL INFORMATION SUPPLIED BY THOMSON TECHNOLOGY INC AS A PART OF A SALE OF EQUIPMENT ARE FOR THE PURCHASER'S USE SOLELY IN CONJUNCTION WITH THAT EQUIPMENT, UNLESS SPECIFICALLY AGREED TO OTHERWISE AS A PART OF THE TERMS OF SALE.	



SCHMATIC DIAGRAM
AUTOMATIC TRANSFER SWITCH
TS 893-2000A-480-3W-75-E
2000A, 480V, 3Ø 3W, 60Hz

CUSTOMER			
OWN BY	AUTH BY	DATE	REV
MC	BD	00-05-11	1
DRAWING No. ELB14004_01_01_02			SHEET 2/2