

**PARTS BULLETIN**

Original Issue Date: **6/94**  
 Model: **All Cummins Brand Generator Sets and Power Units**  
 Market: **Standby**  
 Subject: **Cummins to Kohler Part Number Cross Reference**

Part numbers for Cummins brand generator sets and power units manufactured by Kohler Co. have a corresponding Kohler Co. part number. Refer to the nameplate when identifying units manufactured by Kohler. Cummins generator sets and power units manufactured by Kohler have 6-digit specification numbers beginning 123 or 124.

Use this cross reference table to identify the correct Kohler part number when given a Cummins part number for Kohler product.

Cummins Part Number	Kohler Part Number	Description
3902331	253513	Flywheel
3903251	253266	Gasket
3903669	253051	Bracket, support
3903670	253052	Support Eng.RH
3903671	253053	Support Eng.LH
3903672	253056	Skid
3903673	253057	Suprt Eng Rear
3903674	253058	Support Rad. RH
3903675	253059	Support Rad. LH
3903676	253060	Shroud Fan
3903677	253061	Roof, housing
3903678	253062	Housing, panel
3903679	253063	Bracket, mounting
3903680	253064	Support, housng
3903681	253065	Shroud Housing
3903682	253066	Roof
3903683	253067	Shroud Radiator
3903684	253068	Skid
3903685	253071	Cover, radiator
3903686	253072	Door, housing
3903687	253074	Support, eng Front
3903688	253075	Support, eng Rear
3903689	253076	Roof
3903690	253077	Guard, fan top
3903691	253078	Guard, fan side
3903692	253079	Panel, filler
3903693	253080	Skid
3903694	253081	Support, housing
3903695	253082	Fan
3903696	253083	Box, meter
3903697	253084	Panel, meter
3903698	253085	Over, meter

Cummins Part Number	Kohler Part Number	Description
3903699	253088	Skid
3903700	253089	Panel
3903701	253090	Box
3903702	253091	Plate
3903703	253092	Latch, flush
3903705	253094	Fan
3903706	253095	Elbow
3903707	253096	Door, housing
3903708	253097	Meter, frequency
3903818	253093	Spacer, fan
3903869	253098	Damper, vibro
3903870	253099	Ammeter
3903871	253100	Ammeter
3903872	253101	Gauge, oil pressure
3903873	253102	Gauge, water temp.
3903874	253103	Voltmeter
3903875	A-253104	Cleaner Assy., air
3903876	A-253105	Cleaner Assy., air
3903877	A-253106	Cleaner Assy., air
3903878	253107	Element, air
3903879	253108	Element, air
3903880	253109	Guard, fan LS
3903881	253110	Plate, cover
3903882	253054	Rail Skid
3903883	253055	Crossmember
3903884	253069	Rail Skid, RH
3903885	253070	Rail Skid, LH
3903886	253073	Rail Skid
3903887	253074	Support
3903888	253086	Rail Skid
3903889	290357	Actuator
3903890	253194	Name Plate

Routing	Service Manager	Sales Manager	Parts Manager	Technician No. 1	Technician No. 2	Technician No. 3	Return This to
Initial Here							

Cummins Part Number	Kohler Part Number	Description
3903891	253195	Decal
3903892	253197	Nameplate
3903893	253198	Nameplate
3903894	253123	Packing
3903895	253124	Packing
3903896	A-253125	Radiator Assy.
3903897	A-253126	Radiator Assy.
3903898	253127	Bracket, air cleaner
3903899	253128	Voltmeter, AC
3903900	253129	Bottle, overflow
3903901	A-253229	Engine Assy.
3903902	A-253230	Engine Assy.
3903903	A-253232	Engine Assy.
3903904	253133	Cap, rain
3903905	253134	Cap, rain
3903906	253135	Bracket, air cleaner
3903907	253136	Mount, air cleaner
3903908	A-253233	Engine Assy.
3903949	253258	Decal
3903950	253259	Tag, instruction
3903951	253140	Kit, air cleaner
3903952	253240	Switch, rotary
3903953	253241	Lens, cliplite
3903954	253242	Lens, cliplite
3903955	253144	Kit, silencer
3903956	253317	Bracket, tank mount
3903957	253318	Strap, tank
3903958	A-253319	Pan Sub-Assy.
3903959	253320	Box, meter
3903960	253321	Cable, throttle
3903961	253322	Switch, high temp.
3903962	253323	Switch, pressure
3903963	253324	Connector
3903964	253424	Stud
3903965	271219	Rod, throttle
3903966	259432	Solenoid
3903967	253156	Package Assy.
3903968	253157	Package Assy.
3903969	253158	Package Assy.
3903970	253159	Package Assy.
3903971	253160	Package Assy.
3903972	253328	Harness, wiring
3903973	253329	Voltmeter, battery
3903974	253330	Strip Terminal
3903975	253164	Connector
3903976	253165	Elbow, reducer
3903977	253166	Pipe Reducer
3903978	253167	Elbow, air cleaner
3903979	253331	Harness, wiring
3903980	253332	Lamp
3903981	253335	Bracket, relay
3903982	253336	Bracket, meter
3903983	253172	Hose, upper radiator
3903984	253337	Bracket, panel mtg.

Cummins Part Number	Kohler Part Number	Description
3903985	253338	Bracket, throttle
3903986	253339	Bolt "U"
3903987	A-253343	Regulator Assy.
3903988	253347	Harness Wiring
3903990	253129	Bottle, radiator over
3903996	253345	Bracket Spring
3903997	253348	Button Plug
3903998	253349	Harness Wiring
3903999	A-253351	Panel, annunciator
3904000	253355	Line, suction
3904001	253358	Nameplate
3904002	253359	Nameplate
3904003	253262	Nameplate
3904004	253263	Nameplate
3904005	253187	Silencer (Residential)
3904006	253188	Silencer (Critical)
3904007	253189	Silencer (Residential)
3904008	253190	Silencer (Critical)
3904009	253191	Cap, rain
3904010	253192	Pipe, stack
3904011	253362	Harness Wiring
3904012	253363	Hose, lower radiator
3904013	253199	Bracket, meter
3904014	253375	Bottle, overflow
3904015	253201	Tachometer
3904016	253314	Panel, silkscrn
3904017	253203	Panel
3904018	253204	Panel, NFPA
3904019	253205	Switch, ignition
3904020	253364	Hook, lifting
3904021	A-253365	Panel Assy.
3904022	253366	Panel, silkscreen
3904023	253367	Pipe Stack
3904024	253368	Rack Battery
3904025	253369	Battery
3904026	253371	Spacer, generator
3904027	253372	Skid
3904060	253481	Hose, air cleaner
3904108	253373	Latch
3904109	253215	Heated Oil Pan
3904110	253216	Heater, engine water
3904111	253217	Takeoff, power
3904112	253218	Takeoff, power
3904113	253219	Adapter
3904114	253220	Bracket, cont. panel
3904115	253221	Bracket, cont. panel
3904116	253222	Bracket, cont. panel
3904117	253223	Bracket, mounting
3904118	253224	Breaker, circuit
3904119	253225	Breaker, circuit
3904120	253226	Breaker, circiut
3904121	253234	Spacer, fan
3904122	253236	Silencer (Critical)
3904123	253237	Silencer (Industrial)

Cummins Part Number	Kohler Part Number	Description
3904124	253239	Silencer (Critical)
3904125	253250	Roof, housing
3904126	253251	Roof, housing
3904127	253260	Support, junct. box
3904128	253261	Cover, side
3904129	253265	Silencer (Industrial)
3904131	253267	Roof
3904132	253268	Plug
3904133	253270	Indicator
3904135	253272	Harness, wiring
3904136	A-253273	Box Assy., meter
3904137	253274	Transformer
3904138	A-253276	Board Assy., circuit
3904139	253278	Heater, frost plug
3904140	253307	Stud, holddown
3904141	253308	Adapter, exhaust
3904142	253309	Pipe, exhaust
3904143	253310	Bracket, muffler
3904144	253311	Reducer
3904145	A-253312	Panel Sub-Assy.
3904146	253313	Harness, wiring
3904147	253315	Tank, fuel
3904466	A-253606	Starter Assy.
3904588	253376	Cap, overflow
3904589	A-253377	Engine Assy.
3904590	A-253378	Engine Assy.
3904591	A-253379	Engine Assy.
3904592	A-253380	Engine Assy.
3904593	253381	Bracket, air cleaner
3904594	253382	Elbow
3904595	253383	Panel, rear
3904596	A-253384	Panel Assy.
3904597	253387	Bracket, air cleaner
3904598	253388	Bracket, air cleaner
3904599	253389	Hose, molded
3904600	253390	Panel, wire harness
3904601	253391	Silencer (Industrial)
3904602	253392	Silencer (Critical)
3904603	253397	Cover, side
3904604	253398	Support Junct. Box
3904605	253399	Plug
3904606	253400	Bracket
3904607	A-253401	Panel Assy.
3904608	A-253402	Board Assy., circuit
3904609	253404	Harness, wiring
3904610	253409	Element, air Filter
3904611	241600	Relay
3904612	269958	Relay
3904613	269416	Rectifer, unibridge
3904614	269359	SCR
3904615	223316	Fuse,10 Amp
3904616	240978	Switch
3904617	241308	Switch
3904618	286332	Spring, throttle

Cummins Part Number	Kohler Part Number	Description
3904619	291891	Solenoid
3904620	A-282778	Board Assy., circuit
3904621	238736	Meter, hour
3904622	250512	Switch, thermal
3904623	269356	Knob Pointer
3904625	283375	Switch, toggle
3904626	264390	Sender
3904627	268298	Sender
3904790	253342	Knob Pointer
3904791	259821	Switch, select
3904792	268310	Bulb, light
3904793	282814	Voltmeter, aC
3904794	282897	Gauge, oil pressure
3904795	282898	Gauge, water temp.
3904796	295069	Meter, frequency
3904797	241481	Switch, high temp.
3904798	271662	Switch
3904799	290090	Switch
3904800	243273	Fuse, 3 Amp
3904801	248362	Relay
3904802	282896	Fuse, 4 Amp
3904803	283645	Fuse, 15 Amp
3904804	287524	Switch, pushbutton
3904805	A-292302	Board Assy., circuit
3904806	268042	Switch
3904807	253412	Spring, throttle
3904808	A-253000	Drawing Assy.
3904809	B-253000	Drawing Assy.
3904811	D-253000	Drawing Assy.
3904813	F-253000	Drawing Assy.
3904814	G-253000	Drawing Assy.
3904815	H-253000	Drawing Assy.
3904816	J-253000	Drawing Assy.
3904817	K-253000	Drawing Assy.
3904818	L-253000	Drawing Assy.
3904821	P-253000	Drawing Assy.
3904822	R-253000	Drawing Assy.
3904823	S-253000	Drawing Assy.
3904824	T-253000	Drawing Assy.
3904825	U-253000	Drawing Assy.
3904868	X-253000	Drawing Assy.
3904869	Y-253000	Drawing Assy.
3904870	Z-253000	Drawing Assy.
3904871	AA-253000	Drawing Assy.
3904872	AB-253000	Drawing Assy.
3904873	AC-253000	Drawing Assy.
3904874	AD-253000	Drawing Assy.
3904875	253415	Cover, controller box
3904876	253417	Harness, wiring
3904877	A-257061	Rotor Assy.
3904878	257011	Excitor Field Assy.
3904879	A-257029	Rotor Assy.
3904880	257064	Stator
3904881	257040	Stator

Cummins Part Number	Kohler Part Number	Description
3904882	257012	Bracket, end
3904883	257006	Ring, tolerance
3904884	253420	Fan, suction
3904885	253421	Fan, pusher
3904886	253422	Bracket, solenoid
3904887	253423	Bracket, solenoid
3904888	253428	Heater, engine water
3904889	290257	Actuator
3904890	253430	Bracket, actuator
3904891	253432	PTO 11.5" 1 Plt
3904892	253433	PTO 11.5" 2 Plt
3904893	253436	Harness, wire
3904894	253437	Heater, oil 240 V
3904895	253439	Knob
3904896	237277	Stud
3904897	X-797-15	Hose, flex. exhaust
3904899	X-386-36	Hose
3904900	X-380-4	Pin Roll
3904901	X-426-9	Clamp, hose
3904902	X-211-6	Elbow, street
3904903	264390	Sender, oil pressure
3904904	268298	Sender, water. temp.
3904905	291891	Solenoid
3904908	259919	Vibromount
3904909	X-283-7	Terminal
3904910	268042	Switch, toggle
3904913	X-672-14	Clamp
3904914	X-507-1	Hose, radiator
3904915	X-522-47	Tubing, steel
3904916	A-279379	Assy. Air
3904917	279380	Mount, air cleaner
3904918	X-507-3	Hose, radiator
3904919	253416	Clip, speed
3904920	X-786-39	Breaker, circuit
3904921	X-786-40	Breaker , circuit
3904922	X-786-29	Breaker , circuit
3904925	X-786-28	Breaker, circuit
3904926	291269	Heater, strip
3904927	253440	Plate, mounting
3904928	253441	Strip, marker
3904929	A-253442	Connection Assy.
3904930	259632	Bumper
3904931	X-6033-2	Grommet
3904932	253341	Ammeter
3904934	259414	Transformer, current
3904935	282954	Ammeter
3904936	A-253443	Potentiometer Assy.
3904937	X-6040-2	Channel, 'U'
3904938	279315	Cover Junct. Box
3904939	253444	Nameplate
3904942	253449	Bracket, housing
3904943	253450	Rail, side
3904944	253451	Rail, side
3904945	253452	Support, radiator

Cummins Part Number	Kohler Part Number	Description
3905226	253454	Pipe, exhaust
3905227	253455	Controler, elect.
3905228	271097	Joint, ball
3905229	X-352-53	Stud
3905230	286867	Connector, acc.
3905231	X-468-1	Tie Cable
3905232	290358	Magnetic Pickup
3905236	X-217-6	Pipe
3905237	X-216-24	Coupling
3905238	253462	Cover, Junct. Box
3905239	253467	Nameplate
3905240	253469	Nameplate
3905241	A-253477	Cleaner Assy. Air
3905242	253479	Bracket, air cleaner
3905243	253480	Box, junction
3905245	253482	Cap, rain
3905246	253483	Bracket, air cleaner
3905247	253484	Bracket, air cleaner
3905248	253485	Mount, air cleaner
3905249	253374	Clip
3905250	X-426-3	Clamp, hose
3905251	250081	Clamp, hose
3905252	244210	Damper Vibration
3905253	290418	Strap, ground
3905254	X-426-6	Clamp, hose
3905255	X-352-51	Stud
3905256	290864	Strap, muffler
3905257	290865	Strap, muffler
3905258	X-426-2	Clamp, hose
3905259	X-426-1	Clamp, hose
3905260	X-545-42	Battery Cables
3905261	X-545-44	Battery Cables
3905262	X-545-45	Battery Cables
3905263	X-545-46	Battery Cables
3905264	274200	Stud
3905265	288614	Clamp, battery
3905266	288582	Tray, battery
3905267	253413	Diagram Wiring
3905268	253486	Harness, wiring
3905269	A-253487	Controller Assy.
3905270	253488	Strip Marker
3905271	253489	Harness, wiring
3905272	A-253490	Panel Assy.
3905273	253492	Switch Push
3905274	253493	Switch Push
3905275	253495	Diagram,Wiring
3905276	253496	Diagram,Wiring
3905277	253497	Diagram,Wiring
3905278	253498	Diagram,Wiring
3905279	253499	Kit, hardware
3905280	253500	Kit, hardware
3905281	253501	Kit, hardware
3905282	M-253000	Drawing Assy.
3905283	N-253000	Drawing Assy.

Cummins Part Number	Kohler Part Number	Description
3905284	V-253000	Drawing Assy.
3905285	W-253000	Drawing Assy.
3905286	253502	Transformer, current
3905287	253503	Transformer, current
3905288	X-256-3	Valve, drain
3905289	X-377-11	Connector, cable
3905290	290435	Decal
3905291	259365	Decal
3905292	C-253000	Drawing Assy.
3905293	E-253000	Drawing Assy.
3905294	253414	Diagram, wiring
3905295	X-339-8	Clip, wire
3905296	X-593-3	Grommet
3905297	X-6033-3	Grommet
3905298	269359	SCR Powerpack
3905299	240978	Switch, oil Pressure
3905300	241308	Switch, oil Pressure
3905301	269375	Lamp
3905302	282972	Relay
3905303	A-282778	Circuit Board
3905304	238426	Holder, fuse
3905431	253271	Decal
3905506	253506	Diagram,Interconnect
3905507	241623	Sensor, speed
3905508	X-301-23	Plug
3905509	240976	Switch, temperature
3905510	257070	Bracket, sensor mtg.
3905511	257077	Actuator, magnetic
3905512	271662	Switch, pressure
3905513	290090	Switch, temperature
3905514	B-287742	Board Assy. Circuit
3905515	253508	Bracket, spring
3905516	259490	SCR Pack
3905517	253512	Wiring Diagram
3905518	AE-253000	Dwg Assembly
3905519	A-257457	Rotor Assy.
3905520	A-257454	Rotor Assy.
3905521	X-758-2	Bearing
3905522	A-257444	Rotor Assy.
3905523	257018	Generator Adapter
3905524	257015	Drive, disc Arm.
3905525	257020	Fan
3905526	X-400-132	Spacer
3905527	257046	Gen. Fan Guard
3905528	257442	Speed Clip
3905529	AF-253000	Assy. Drawing
3905530	AG-253000	Assy. Drawing
3905531	253514	Wire Harness
3905532	253515	Wire Harness
3905533	AH-253000	Assy. Drawing
3905534	253516	Bracket, meter panel
3905535	X-284-23	Grommet
3905536	223022	Vibro Damper
3905537	253519	House Rear Panel

Cummins Part Number	Kohler Part Number	Description
3905538	253520	Roof
3905539	253522	Harness, wiring
3905540	253523	Harness, wiring
3905541	AJ-253000	Assy. Drawing
3905542	AK-253000	Assy. Drawing
3905543	AL-253000	Assy. Drawing
3905544	X-5-17	Screw
3905545	X-794-2	Pop Rivet
3905546	X-6051-2	Screw
3905547	X-6052-1	Screw
3905548	X-6053-1	Hex. Nut
3905549	X-51-47	Screw
3905550	X-786-31	Circuit Breaker
3905551	X-49-2	Screw
3905552	X-786-16	Circuit Breaker
3905553	X-786-38	Circuit Breaker
3905554	X-50-46	Screw
3905555	259686	Wire Harness
3905556	X-6050-6	Screw
3905557	238451	Plate, serial No.
3905558	A-257202	Alternator Assy.
3905559	A-257200	Alternator Assy.
3905561	253524	Connector Assy.
3905562	253525	Fan, sucker
3905563	253526	Blower
3905564	253527	Shroud, fan
3905565	253528	Fan Assembly
3905566	253529	Fan Assembly
3905567	253532	Decal
3905568	X-426-5	Clamp, hose
3905569	X-641-5	Hose, air Intake
3905570	255224	Voltmeter
3905571	253535	Guard Fan (Top)
3905572	253536	Guard Fan (RH)
3905573	253637	Guard Fan (LH)
3905574	253538	Support Radiator
3905575	253539	Support Radiator
3905576	A-253540	Panel Assembly
3905577	253541	Harness, wiring
3905578	268371	Relay, cranking
3905580	291657	Adapter
3905581	253542	Diagram, wiring
3905582	AL-253000	Drawing Assembly
3905583	AM-253000	Drawing Assembly
3905584	AN-253000	Drawing Assembly
3905946	AP-253000	Drawing Assembly
3905947	A-257489	Rotor Assembly
3905948	AR-253000	Drawing Assembly
3905949	A-257203	Alternator Assembly
3905950	A-257300	Alternator Assembly
3905951	A-257460	Rotor Assembly
3905952	257065	Stator Assembly
3905953	257164	Stator Assembly
3905954	257167	Bracket, end

Cummins Part Number	Kohler Part Number	Description
3905955	257172	Exciter Field Assy.
3905956	257168	Ring, tolerance
3905957	X-758-6	Bearing, ball
3905958	A-257445	Rectifier Assembly
3905959	257175	Adapter, generator
3905960	257102	Disc, arm Drive
3905961	257173	Fan, generator
3905962	257179	Guard, fan
3905963	AS-253000	Drawing, assembly
3905964	AT-253000	Drawing, assembly
3905965	A-253545	Panel Assy. 12 V
3905966	A-253546	Panel Assy. 24V
3905967	253547	Bracket, mounting
3905968	253554	Bracket, actuator
3905969	AU-253000	Drawing, assembly
3905970	AV-253000	Drawing, assy.
3905971	AW-253000	Drawing, assy.
3905972	AX-253000	Drawing, assy.
3905973	253555	Door, supprt-LH
3905974	253556	Door, supprt-RH
3905975	253557	Brace, radiator
3905976	253558	Support, engine
3905977	253559	Support, engine
3905978	X-352-54	Stud
3905979	253560	Harness, wiring
3905982	255282	Frame, air Duct
3905983	AY-253000	Drawing, assy.
3905984	X-426-13	Clamp, hose
3905985	253565	Support, radiator
3905986	253566	Support, radiator
3905987	253567	Shroud, fan
3905988	253568	Guard, fan LS
3905989	253569	Guard, fan RS
3905990	253570	Guard, fan top
3905991	253571	Bracket, housing
3905992	253572	Hose, molded
3905993	235495	Spring, governor
3905994	253573	Silencer, exhaust
3905995	253574	Adapter, exhaust
3905996	AZ-253000	Drawing, assy.
3905997	BA-253000	Drawing, assy.
3905998	253580	Harness, wiring
3905999	253581	Bracket, rad. Supp.
3906000	253582	Bracket, rad. Supp.
3906001	253583	Bracket, rad. supp.
3906002	253584	Connector
3906003	289372	Clamp, exhaust
3906004	253585	Shroud, fan
3906005	253586	Mount, rubber
3906006	X-400-139	Spacer
3906007	B-253402	Board Assy., circuit
3906009	A-255345	Radiator Assy.
3906010	A-255350	Radiator Assy.
3906011	B-253319	Panel Assembly

Cummins Part Number	Kohler Part Number	Description
3906012	B-253490	Panel Assembly
3906013	253604	Pickup, magnetic
3906014	253609	Ammeter
3906015	253610	Transformer
3906016	253613	Silencer
3906017	253614	Silencer
3906018	253618	Pipe, exhaust
3906019	253602	Nameplate
3906020	255344	Fan, blower
3906021	255341	Fan, shroud
3906022	A-257509	Rotor Assembly
3906023	253620	Fan, blower
3906024	253622	Nameplate
3906025	A-253623	Engine Assembly
3907071	253628	Fan, sucker
3907072	253629	Fan, sucker
3907073	A-253630	Engine Assembly
3907074	253632	Guard, fan
3907075	253633	Harness, wiring
3907076	253636	Bracket, shroud
3907077	253637	Bracket, shroud
3907078	253640	Box, junction
3907079	253641	Bracket, cont. panel
3907080	253642	Cover, side
3907081	253643	Bracket, cont. panel
3907082	253644	Bracket, cont. panel
3907083	253645	Box, junction
3907086	253646	Brace
3907087	253647	Bracket
3907088	253662	Cleaner, air
3907089	BC-253000	Drawing Assembly
3907090	BD-253000	Drawing Assembly
3907091	253663	Cleaner, air
3907092	253664	Cleaner, air
3907093	253665	Hose, molded
3907094	253666	Hose, hump
3907095	253667	Hose, molded
3907096	253668	Cap
3907097	253669	Bracket, air Ccleaner
3907098	BE-253000	Drawing, assembly
3907099	BF-253000	Drawing, assembly
3907100	253674	Band, mounting
3907101	253676	Vibromount
3907102	253677	Bracket, cont. Panel
3907103	253695	Panel, silkscreen
3907104	253679	Collar, snubbing
3907105	A-253680	Panel Assembly
3907106	A-253681	Panel Assembly
3907107	A-253682	Panel Assembly
3907108	A-253683	Panel Assembly
3907109	BG-253000	Drawing Assembly
3907110	BH-253000	Drawing Assembly
3907111	253694	Bracket, cont. panel
3907112	B-253193	Charger Assy.

Cummins Part Number	Kohler Part Number	Description
3907113	253701	Cable, throttle
3907114	241739	Diode
3907115	255262	Resistor
3907116	253703	Door
3907118	253598	Panel
3907119	268015	Switch, Run/Off
3907120	253600	Panel
3907121	253326	Panel
3907122	282830	Terminal Strip
3907123	253386	Alarm Horn
3907124	241736	Relay, alarm Horn
3907125	246115	Terminal Strip
3907126	223096	Terminal Strip
3907127	X-6048-2	Jumper
3907128	153659	Bushing, reducer
3907129	253705	Hose, radiator
3907130	X-672-7	Clamp
3907131	253708	Box, junction
3907132	253709	Panel, junction box
3907133	253710	Plate, inner
3907134	253711	Cover, junction box
3907136	BJ-253000	Drawing Assembly
3907137	A-257302	Alternator Assy.
3907138	257166	Stator Assembly
3907139	244613	Vibromount
3907140	253713	Fan, blower
3907141	255393	Fan
3907142	253714	Shroud, radiator
3907143	255392	Cover, radiator
3907144	BK-253000	Drawing Assembly
3907145	253716	Guard, fan Top
3907146	253717	Guard, fan RH
3907147	253718	Guard, fan LH
3907148	253719	Support, radiator LH
3907149	253720	Support, radiator RH
3907150	A-255362	Radiator Assy.
3907866	253723	Plug, plastic
3907867	255402	Skid
3907868	286020	Damper, vibro
3907869	286019	Damper, vibro
3907870	255400	Damper, vibro
3907872	253727	Spacer
3907873	280133	Cable
3907874	X-545-7	Cable
3907875	X-545-24	Cable
3907876	253731	Roof
3907877	255427	Door
3907878	255425	Shroud
3907880	253734	Nameplate
3907881	253735	Nameplate
3907882	253739	Pipe, exhaust
3907883	X-797-18	Hose, flex. exhaust
3907884	253740	Connector
3907885	253741	Connector

Cummins Part Number	Kohler Part Number	Description
3907886	X-426-14	Clamp, hose
3907887	BE-253000	Sheet 2-inst Dr
3907888	BF-253000	Sheet 2-inst Dr
3907891	253742	Guard, fan
3907892	253743	Switch, temperature
3907893	253744	Cap, radiator
3907894	X-25-108	Washer
3907895	253745	Nameplate
3907896	253747	Spacer
3907897	253748	Spacer
3907898	253749	Shroud
3907900	253751	Harness
3907901	X-400-37	Spacer
3907902	287945	Terminal Compound
3907903	253756	Crossmember
3907904	253757	Skid
3907905	253759	Crossmember
3907906	253761	Panel Instrument
3907907	253764	Roof
3907908	253765	Roof
3907909	253766	Bracket, shroud
3907910	253767	Bracket
3907911	253768	Rail
3907912	253769	Rail
3907913	253771	Door, housing
3907914	BL-253000	Assembly Dwg.
3907915	255391	Shroud
3907916	253773	Adapter, exhaust
3907917	253775	Crossmember
3907918	253776	Support, engine
3907919	253777	Support, engine
3907920	BM-253000	Drawing Assembly
3907921	253779	Bracket, panel
3907922	253780	Plate, cover
3907923	253792	Box, junction
3907924	A-253812	Radiator Assy.
3907925	253794	Cover, junction box
3907926	253795	Lead Assembly
3907927	253797	Hose, molded
3907928	253798	Lead Assembly
3907929	253799	Lead Assembly
3907930	253800	Bracket, air cleaner
3907931	253807	Plate, inner
3907932	253808	Panel, junction Box
3907933	253813	Shroud, fan
3907934	253819	Panel, housing
3907935	253820	Panel, housing
3907936	X-386-48	Line, fuel
3907937	X-380-1	Connector, hose
3907938	X-386-70	Line, fuel
3907939	253825	Fan, sucker
3907940	253826	Spacer, fan
3907941	253827	Yoke, end
3907942	253828	Bolt, eye

Cummins Part Number	Kohler Part Number	Description
3907943	253829	Bar, lifting
3907944	253830	Bar, lifting
3909705	253831	Pin, locking
3909706	253832	Rod, lifting
3909707	CA-253000	Drawing Assembly
3909709	253839	Support, radiator
3909710	253840	Bracket, radiator
3909711	253841	Bracket, radiator
3909712	253842	Bracket, radiator
3909713	253843	Bracket, radiator
3909714	253844	Bracket, radiator Grd
3909715	253845	Bracket, radiator Grd
3909716	253846	Guard, fan
3909717	253847	Guard, fan
3909718	253848	Guard, fan
3909719	253849	Crossmember
3909720	253850	Crossmember
3909721	253851	Support, engine
3909722	253852	Rod, tie
3909723	CB-253000	Drawing, assy.
3909724	CC-253000	Drawing, assy.
3909725	CD-253000	Drawing, assy.
3909726	287962	Lamp, test switch
3909727	241737	Relay
3909728	253858	Stud
3909729	A-253860	Diode Assembly
3909730	253861	Shroud, rod
3909731	253862	Guard, fan
3909732	253863	Guard, fan
3909733	253864	Guard, fan
3909734	255584	Support, radiator
3909735	255585	Support, radiator
3909736	253867	Fan
3909737	253870	Fan, sucker
3909738	253871	Shroud, fan
3909739	253872	Spacer, fan
3909741	253874	Hose, radiator
3909742	253875	Tube, steel
3909743	253873	Hose, radiator
3909744	253877	Switch, toggle
3909745	CE-253000	Drawing, assy.
3909746	B-253680	Panel Assembly
3909747	B-253681	Panel Assembly
3909748	A-253859	Radiator
3909749	255582	Hose
3909750	255583	Hose
3909752	253902	Support, radiator
3909753	253903	Support, radiator
3909754	253904	Hose, radiator
3909755	253905	Hose, radiator
3909756	253906	Shroud, radiator
3909757	253907	Support, engine
3909758	253908	Support, engine
3909759	253909	Bracket, rad. support

Cummins Part Number	Kohler Part Number	Description
3909760	253910	Bracket, rad. support
3909761	253911	Bracket, rad. support
3909762	253912	Shroud, fan
3909763	253913	Bracket, support
3909764	253914	Bracket, support
3909765	253915	Guard Fan (RS)
3909766	253916	Guard Fan (LS)
3909767	253917	Guard Fan (Top)
3909768	253919	Rail, side (RH)
3909769	253920	Rail, side (LH)
3909770	253921	Roof, housing
3909771	253922	Panel, rear
3909772	253923	Door, housing
3909773	CG-253000	Drawing, assy.
3909774	253932	Tube, air Intake
3909775	CF-253000	Drawing, assy.
3909776	253936	Panel, instrument
3909777	250719	Breaker, circuit
3909778	253937	Clip
3909779	253938	Shroud
3909780	253939	Cover, battery
3909781	253950	Bracket, mounting
3909782	253951	Guard, radiator
3909783	253952	Guard, radiator
3909784	CH-253000	Drawing, assy.
3909785	253955	Rack, battery
3909786	CJ-253000	Drawing, assy.
3909787	253957	Cover, radiator
3909788	253959	Rack, battery
3909789	253962	Support, rear
3909790	255523	Harness, wiring
3909791	C-253680	Panel Assembly
3909792	C-253681	Panel Assembly
3909793	250719	Breaker, circuit
3909794	A-253196	Charger Assembly
3909795	A-257262	Alternator Assy.
3909796	253966	Harness, wiring
3909797	A-253967	Panel Assembly
3909798	B-253384	Panel Assembly
3909799	A-253971	Contact Assy.
3909800	253972	Diagram, wiring
3909801	253975	Bracket, panel mtg.
3909802	CK-253000	Drawing, assy.
3909803	259391	Relay
3909804	A-253974	Control Assy.
3909805	269955	Harness, wiring
3909806	253979	Bracket, air cleaner
3909807	253980	Pipe, stack
3909808	253981	Pipe, stack
3909809	253982	Pipe, stack
3909810	253983	Pipe, stack
3909811	253984	Pipe, stack
3909812	253989	Adapter, exhaust
3909813	253990	Cap, rain

Cummins Part Number	Kohler Part Number	Description
3909814	253993	Silencer, industrial
3909815	253995	Take-off, power
3909816	254003	Bracket, throttle
3909817	254004	Cleaner, air
3909818	254005	Tube
3909819	254006	Cap, rain
3909820	254007	Elbow, rubber
3909821	254008	Cleaner, air
3909822	254009	Tube
3909823	254010	Cap, rain
3909824	254011	Elbow, rubber
3909825	254012	Band, mounting
3909826	254013	Clamp
3909827	254014	Tube, crossover
3909828	CL-253000	Drawing, assy.
3909829	254018	Lever, throttle
3909830	CM-253000	Drawing, assy.
3909831	CN-253000	Drawing, assy.
3909832	CP-253000	Drawing, assy.
3909833	254021	Elbow, rubber
3909834	254022	Fan, sucker
3909835	254023	Fan, blower
3909836	A-254024	Radiator, assy.
3909837	X-400-146	Spacer
3909839	254025	Rail, side
3909840	254026	Rail, side
3909841	254028	Harness, wiring
3909842	A-253998	Panel Assembly
3909843	A-253999	Panel Assembly
3909844	Bb-253000	Drawing, assy.
3909845	Cr-253000	Drawing, assy.
3909846	254029	Roof, housing
3909847	254030	Roof, housing
3909848	254031	Shroud, housing
3909849	254032	Door, housing
3909850	254033	Rail, side
3909851	254034	Rail, side
3909852	254035	Bracket, rear mtg.
3909853	254039	Clamp, battery
3909854	X-545-56	Cable, battery
3909855	X-545-57	Cable, battery
3909856	255600	Switch, float
3909857	254041	Relay
3909858	254042	Relay
3909859	254043	Relay
3909860	255723	Roof
3909861	254045	Shroud, rear
3909862	A-257301	Alternator Assy.
3909863	254046	Shroud, rear
3909864	254047	Cover, radiator
3909865	254048	Support, engine
3909866	254049	Support, engine
3909867	283917	Transformer
3909868	283918	Transformer

Cummins Part Number	Kohler Part Number	Description
3909869	283919	Transformer
3909870	X-270-1	Rheostat
3909871	X-467-3	Rheostat
3909872	283869	Nameplate
3909873	254050	Harness, wiring
3909874	254051	Harness, wiring
3909875	254053	Box, junction
3909876	254054	Cover, side
3909877	254055	Bracket
3909878	254056	Bracket
3909879	CS-253000	Drawing, assy.
3909880	254061	Fan, sucker
3909881	254062	Fan, blower
3909882	254063	Spacer, fan
3909883	254064	Spacer, fan
3911010	257597	Stator Assy.
3911011	A-257594	Rotor Assy.
3911012	X-786-3	Breaker
3911013	X-786-5	Breaker
3911014	254065	Bracket
3911015	254066	Hose
3911016	254067	Roof
3911017	254069	Cleaner, air
3911018	254070	Cleaner, air
3911019	254071	Fuse
3911020	292821	Holder, fuse
3911021	254073	Harness, wiring
3911022	X-786-34	Breaker
3911023	254077	Bracket
3911024	254078	Tube
3911025	254079	Panel, rear
3911026	254082	Bracket
3911027	254083	Bracket
3911028	254084	Bracket
3911029	254085	Gasket
3911030	254086	Bracket
3911031	254087	Clamp, hose
3911032	254087	Clamp, hose
3911033	257622	Rotor Assy.
3911034	254088	Connector
3911035	254089	Transformer
3911036	254090	Transformer
3911037	254091	Transformer
3911038	CT-253000	Drawing, assy.
3911040	254092	Bracket
3911041	254098	Bracket
3911042	C-253276	Board Assy.
3911043	CX-253000	Drawing, assy.
3911044	254100	Hose, hump
3911045	A-255607	Radiator Assy.
3911046	A-255604	Radiator Assy.
3911047	A-255608	Radiator Assy.
3911051	254104	Fan, blower
3911052	283919	Transformer

Cummins Part Number	Kohler Part Number	Description
3911053	B-292302	Board
3911054	258381	Breaker, circuit
3911055	X-786-27	Breaker, circuit
3911056	X-786-30	Breaker, circuit
3911057	X-786-15	Breaker, circuit
3911058	X-786-18	Breaker, circuit
3911059	X-786-33	Breaker, circuit
3911060	X-786-35	Breaker, circuit
3911061	253964	Kit
3911062	253696	Nameplate
3911063	B-282778	Board
3911064	257538	Stator
3911065	254118	Harness
3911066	254120	Harness
3911067	254124	Drawing
3911068	CU-253000	Drawing
3911069	CZ-253000	Drawing
3911070	254136	Fan
3911071	254137	Fan
3911072	254138	Fan
3911073	254139	Fan
3911074	254141	Fan
3911075	254142	Fan
3911076	254143	Kit
3911077	254144	Shroud
3911078	254146	Fan
3911079	254149	Fan
3911080	254154	Bracket, spring
3911081	DA-253000	Drawing, assy.
3911082	DB-253000	Drawing, assy.
3911083	233442	Solenoid
3911084	A-254159	Radiator, assy.
3911085	254160	Bracket, rad.
3911086	254161	Bracket, rad.
3911087	254162	Guard, fan
3911088	254163	Guard, fan
3911089	254164	Guard, fan
3911090	X-25-96	Washer
3911091	254166	Support, engine
3911092	254167	Support, engine
3911093	254168	Support, rad.
3911094	254169	Support, rad.
3911095	254170	Diag., wiring
3911096	254171	Diag., wiring
3911097	254172	Diag., intercon
3911098	DC-253000	Drawing, assy.
3911099	DD-253000	Drawing, assy.
3911100	254177	Shroud, fan
3911101	254178	Mount, vibration
3911102	X-352-63	Stud
3911103	254180	Guard, fan
3911104	254181	Guard, fan
3911105	254182	Guard, fan
3911106	254185	Mount, rubber

Cummins Part Number	Kohler Part Number	Description
3911107	254186	Bracket, radiator
3911108	254187	Bracket, radiator
3911110	X-25-121	Washer
3911111	255828	Diagram, wiring
3911112	254165	Spacer, fan
3911113	254189	Fan, sucker
3911114	254190	Fan, blower
3911115	254132	Panel, rear
3911116	DE-253000	Drawing, assy.
3911117	DF-253000	Drawing, assy.
3911118	DG-253000	Drawing, assy.
3911119	A-257695	Alternator
3911120	A-257693	Alternator
3911121	A-257749	Assy., rotor
3911122	A-257747	Assy., rotor
3911123	257767	Assy., stator
3911124	257768	Assy., stator
3911125	A-257708	Alternator
3911126	A-257647	Alternator
3911127	A-257648	Alternator
3911128	X-352-63	Stud
3911129	A-257751	Assy., rotor
3911130	A-257670	Assy., rotor
3911131	A-257671	Assy., rotor
3911132	257769	Assy., stator
3911133	257687	Assy., stator
3911134	257688	Assy., stator
3911135	254125	Diag., wiring
3911136	A-257649	Alternator
3911137	A-257672	Assy., rotor
3911138	257689	Assy., stator
3911141	254198	Strip, marker
3911142	254197	Strip, marker
3911143	A-254199	Charger, battery
3911144	A-255929	Box, meter
3911145	255930	Box, meter
3911146	DK-253000	Drawing, assy.
3911147	254204	Tachometer
3911148	254208	Bracket, mounting
3911149	254209	Lever, actuator
3911150	255746	Actuator, gov.
3911151	255750	Pickup, magnetic
3911152	255932	Box, control
3911153	254210	Cable, pickup
3911154	254211	Cable, power
3911155	254212	Cable, actuator
3911156	254675	Kit, angle Bolt
3911157	254676	Kit, angle Bolt
3911158	254216	Pin, clevis
3911159	254217	Lever, shut-off
3911160	255934	Box, meter
3911161	254127	Strip, marker
3911162	254130	Harness, wiring
3911163	254229	Joint, ball

Cummins Part Number	Kohler Part Number	Description
3911164	254238	Panel, front
3911165	254231	Harness, wiring
3911166	254232	Harness, wiring
3911167	254234	Harness, wiring
3911168	254233	Harness, wiring
3911169	A-254239	Assy., panel
3911170	254133	Panel, silkscreen
3911174	254249	Shroud, front
3911175	254250	Shroud, rear
3911176	254251	Roof
3911178	A-254128	Assy., panel
3911179	292836	Harness, cable
3911180	254243	Harness, wiring
3911181	254252	Roof
3911182	DL-235000	Drawing, assy.
3911183	254247	Frame, air Duct
3911184	254244	Heater, block
3912261	254245	Heater, block
3912262	254246	Heater, block
3912263	255858	Assy., resistor
3912264	254248	Skid
3912265	X-545-58	Cable, battery
3912266	X-545-51	Cable, battery
3912267	254253	Roof
3912268	254254	Roof
3912269	254255	Panel, filler
3912270	254256	Panel, filler
3912271	254257	Door
3912272	254258	Door
3912273	X-786-22	Breaker, circuit
3912274	254262	Support
3912275	254263	Bracket, front
3912276	X-786-7	Breaker, circuit
3912277	254264	Shroud, rear
3912278	254265	Bracket
3912279	254126	Panel, front
3912280	254129	Panel, silkscreen
3912281	235496	Spring
3912282	254179	Plate, adapter
3912283	A-254272	Assy., radiator
3912284	262309	Diag., wiring
3912285	A-254275	Assy., radiator
3912286	254276	Support, radiator
3912287	254277	Bracket, radiator
3912288	254278	Bracket, radiator
3912289	254279	Guard, fan Top
3912290	254280	Guard, LH Fan
3912291	254281	Guard, RH Fan
3912292	254282	Tube, radiator
3912293	254283	Tube, radiator
3912294	254284	Shroud, fan
3912295	254285	Crossmember
3912296	254286	Plate
3912297	254287	Housing, panel

Cummins Part Number	Kohler Part Number	Description
3912298	254288	Door, housing
3912299	254289	Latch
3912300	254290	Roof, housing
3912301	254291	Roof, housing
3912302	254292	Panel, front
3912303	254293	Panel, filler
3912304	254294	Panel, filler
3912305	254295	Support
3912306	254296	Support
3912309	254297	Decal
3912310	254298	Support, LH
3912311	254299	Support, RH
3912312	DM-253000	Drawing, assy.
3912313	DN-253000	Drawing, assy.
3912314	X-6069-6	Screw, H.C.
3912315	X-6211-2	Nut, lock
3912316	X-6211-3	Nut, lock
3912317	X-6052-10	Screw, H.C.
3912318	DP-253000	Drawing, assy.
3912319	A-254308	Assy., panel
3912321	DR-253000	Drawing, assy.
3912322	A-255769	Assy., radiator
3912323	DS-253000	Drawing, assy.
3912324	DT-253000	Drawing, assy.
3912325	254323	Panel, rear
3912326	254327	Bracket, cable
3912327	254328	Hose, radiator
3912328	254329	Cable, throttle
3912329	254330	Cable, throttle
3912330	254333	Mount, rubber
3912332	254338	Fan, blower
3912333	254339	Fan, sucker
3912334	X-786-32	Breaker, circuit
3912335	254131	Fan, blower
3912336	254334	Fan, blower
3912337	254340	Bracket, cable
3912338	254341	Cable, throttle
3912339	254342	Bracket, support
3912340	254344	Clamp, hose
3912341	287812	Switch, toggle
3912342	255976	Assy., resistor
3912343	255256	Body, connector
3912345	254346	Bracket, hous.
3912346	CY-253000	Drawing, assy.
3912347	254347	Bracket
3912348	254348	Bracket, spring
3912349	X-400-128	Spacer
3912350	253760	Vibromount
3912353	D-253680	Assy., panel
3912354	D-253681	Assy., panel
3912355	255264	Kit, water temp.
3912356	254352	Guard, radiator
3912357	D-253276	Assy., circuit Board
3912358	258805	Bracket,, support

Cummins Part Number	Kohler Part Number	Description
3912359	255307	Pipe, exhaust
3912360	254356	Guard, fan
3912361	254357	Guard, fan
3912362	254382	Harness, wiring
3912363	A-254380	Assy., panel
3912364	254371	Adapter, exhaust
3912365	254368	Harness, wiring
3912366	C-253319	SubAssy., panel
3912367	254362	Box, meter
3912368	254363	Box, meter
3912369	A-254364	Box, meter
3912370	254366	Panel, rear
3912371	254361	Cover, box
3912372	255241	Switch
3912373	A-254367	Assy., panel
3912374	254188	Fan, sucker
3912375	X-786-23	Breaker, circuit
3912376	295339	Ammeter
3912377	254383	Plate
3912378	X-786-49	Breaker, circuit
3912379	254381	Harness, wiring
3912380	254385	Rail
3912381	254386	Rail
3912382	254387	Skid
3912383	254390	Bracket
3912384	254392	Diagram, wiring
3912385	254393	Diagram, wiring
3912386	258783	Power Package
3912387	254394	Relay Assembly
3912388	254395	Panel Sub-assembly
3912389	292985	Frame, air duct
3912390	292988	Frame, air duct
3912391	254396	Bracket, cable

Cummins Part Number	Kohler Part Number	Description
3912392	254397	Decal
3912393	292990	Frame, air duct
3912394	292989	Frame, air duct
3912395	280997	Lever
3912396	254398	Bracket
3912397	254399	Bracket
3912398	291507	Brace
3912399	EB-255000	Drawing
3912400	254401	Harness, wiring
3912401	254402	Harness, wiring
3912402	254403	Harness, wiring
3912403	DU-253000	Drawing
3912404	DV-253000	Drawing
3912405	DW-253000	Drawing
3912406	DX-253000	Drawing
3912407	A-254418	Circuit Board
3912408	254419	Harness, wiring
3912409	254420	Diagram, wiring
3912410	254421	Support
3912411	254422	Support
3912412	279047	Tag, hang
3912413	254425	Battery
3912414	254427	Stud
3912415	A-254428	Radiator
3912416	254429	Support
3912417	254430	Support
3912418	254431	Shroud, fan
3912419	DY-253000	Drawing
3912420	254433	Shroud, fan
3912421	254434	Shroud, fan
3912422	A-254439	Radiator
3912423	A-254440	Radiator
3912424	254443	Rod, gov. adjustment
3912425	254444	Bracket