

NOTE: PROGRAM DIGITAL INPUTS FOR
ACTIVE HIGH OR ACTIVE LOW
(NORMALLY CLOSED OR
NORMALLY OPEN)

THIS SHEET IS TO BE USED AS REFERENCE ONLY.
PLEASE REFER TO LEB5255 OR RENR7902 FOR THE MOST
COMPLETE AND ACCURATE INFORMATION.

